



C-600 Series Gigabit Managed Switch

CLI Reference Guide

Software Release
V6.54.3314



SC60010

C-600 24 Port PoE Lighting Managed Switch

How to Use This Guide

This guide includes detailed information on the switch hardware, including network ports, power, cabling requirements, as well as plug-in modules and transceivers. This guide also provides general installation guidelines and recommended procedures. To deploy this switch effectively and ensure trouble-free operation it is recommended to first read the relevant sections in this guide so that you are familiar with all its hardware components.

Who Should Read This Guide?

This guide is for network administrators who are responsible for operating and maintaining network equipment. The guide assumes a basic working knowledge of LANs (Local Area Networks), the Internet Protocol (IP), and Simple Network Management Protocol (SNMP).

How This Guide is Organized

This guide describes the switch's command line interface (CLI). For more detailed information on the switch's key features or information about the web browser management interface refer to the *Web Management Guide*.

Related Documentation

This guide focuses on switch software configuration through the CLI. For information on how to manage the switch through the Web management interface, see the following guide:

Web Management Guide

For information on how to install the switch, see the following guide:

Quick Start Guide

Content

| | |
|--|------------|
| HOW TO USE THIS GUIDE..... | III |
| 1-1 LOGIN..... | 2 |
| 1-2 COMMANDS OF CLI..... | 3 |
| 1-3 GLOBAL COMMANDS OF CLI | 4 |
| CHAPTER 2 CABLEDIAG COMMAND..... | 7 |
| CHAPTER 3 CLEAR COMMAND | 8 |
| CHAPTER 4 CONFIGURE COMMAND | 16 |
| CHAPTER 5 COPY COMMAND | 125 |
| CHAPTER 6 DEBUG COMMAND | 126 |
| CHAPTER 7 DELETE COMMAND | 127 |
| CHAPTER 8 DIR COMMAND | 128 |
| CHAPTER 9 DISABLE COMMAND..... | 129 |
| CHAPTER 10 DO COMMAND | 130 |
| CHAPTER 11 DOT1X COMMAND | 131 |
| CHAPTER 12 ENABLE COMMAND..... | 132 |
| CHAPTER 13 FIRMWARE COMMAND | 133 |
| CHAPTER 14 IP COMMAND | 134 |
| CHAPTER 15 NO COMMAND | 135 |
| CHAPTER 16 PING COMMAND | 136 |
| CHAPTER 17 RELOAD COMMAND | 138 |
| CHAPTER 18 SEND COMMAND | 139 |
| CHAPTER 19 SHOW COMMAND..... | 140 |
| CHAPTER 20 TERMINAL..... | 201 |
| CHAPTER 21 TRACEROUTE | 203 |
| CHAPTER 29 CLI COMMAND REFERENCES | 204 |
| 29-1 PRIVILEGE LEVEL | 204 |
| 29-2 COMMAND MODES | 205 |

The following description is the brief of the network connection.

-- Locate the correct DB-9 (RS-232) cable with female DB-9 connector. RS-232 cable is used for connecting a terminal or terminal emulator to the Managed Switch's RJ45 port to access the command-line interface.

-- Attach the RJ45 serial port on the switch's front panel which used to connect to the switch for console configuration

-- Attach the other end of the DB-9 cable to an ASCII terminal emulator or PC Com-1, 2 port. For example, PC runs Microsoft Windows HyperTerminal utility.

-- At "Com Port Properties" Menu, configure the parameters as below: (see the next section)

| | |
|--------------|--------|
| Baud rate | 115200 |
| Stop bits | 1 |
| Data bits | 8 |
| Parity | N |
| Flow control | none |

1-1 Login

The command-line interface (CLI) is a text-based interface. User can access the CLI through either a direct serial connection to the device or a Telnet session (Default IP address: [192.168.2.1](#)). The default user and password to login into the Managed Switch are listed below:

Username: **admin**

Password: **admin**

Note: <none> means empty string

After you login successfully, the prompt will be shown as "<sys_name>#". See the following two figures. It means you behave as an administrator and have the privilege for setting the Managed Switch. If log as not the administrator, the prompt will be shown as "<sys_name>>", it means you behave as a guest and are only allowed for setting the system under the administrator. Each CLI command has its privilege

```
Username: admin
Password:
SC60010#
```

1-2 Commands of CLI

The CLI is divided into several modes. If a user has enough privilege to run a particular command, the user has to run the command in the correct mode. To see the commands of the mode, please input “?” after the system prompt, then all commands will be listed in the screen. The command modes are listed as follows:

Command Modes

| MODE | PROMPT | COMMAND FUNCTION IN THIS MODE |
|------------------------|-------------------------------------|---|
| exec | <sys_name># | Display current configuration, diagnostics, maintenance |
| config | <sys_name>(config)# | Configure features other than those below |
| Config-if | <sys_name>(config-interface)# | Configure ports |
| Config-if-vlan | <sys_name>(config-if-vlan)# | Configure static vlan |
| Config-line | <sys_name>(config-line)# | Line Configuration |
| Config-impc-profile | <sys_name>(config-impc-profile)# | IPMC Profile |
| Config-snmp-host | <sys_name>(config-snmp-host)# | SNMP Server Host |
| Config-stp-aggr | <sys_name>(config-stp-aggr)# | STP Aggregation |
| Config-dhcp-pool | <sys_name>(config-dhcp-pool)# | DHCP Pool Configuration |
| Config-rfc2544-profile | <sys_name>(config-rfc2544-profile)# | RFC2544 Profile |

Commands reside in the corresponding modes could run only in that mode. If a user wants to run a particular command, the user has to change to the appropriate mode. The command modes are organized as a tree, and users start in enable mode. The following table explains how to change from one mode to another.

Change Between Command Modes

| MODE | ENTER MODE | LEAVE MODE |
|------------------|--|------------|
| exec | -- | -- |
| config | Configure terminal | exit |
| config-interfcae | Interface <port-type> <port-type-list> | exit |
| config-vlan | Interface vlan <vlan_list> | exit |

1-3 Global Commands of CLI

```

SC60010# ?
    CableDiag    Cable Diagnostic keyword
    clear         Reset functions
    configure     Enter configuration mode
    copy         Copy from source to destination
    debug        Debugging functions
    delete       Delete one file in flash: file system
    dir          Directory of all files in flash: file system
    disable      Turn off privileged commands
    do           To run exec commands in config mode
    dot1x        IEEE Standard for port-based Network Access
Control
    enable       Turn on privileged commands
    exit        Exit from EXEC mode
    firmware     Firmware upgrade/swap
    help        Description of the interactive help system
    ip          IPv4 commands
    logout      Exit from EXEC mode
    more        Display file
    no          Negate a command or set its defaults
    ping        Send ICMP echo messages
    reload      Reload system.
    send        Send a message to other tty lines
    show        Show running system information
    terminal    Set terminal line parameters
    traceroute  traceroute program

```

Exit

Exit from EXEC mode.

Syntax:

exit

Parameter:

None.

Example:

```
SC60010(config)# exit
SC60010#
```

Help

Description of the interactive help system.

Syntax:

help

Parameter:

None.

Example:

```
SC60010# help
Help may be requested at any point in a command by entering
a question mark '?'. If nothing matches, the help list will
be empty and you must backup until entering a '?' shows the
available options.
Two styles of help are provided:
1. Full help is available when you are ready to enter a
   command argument (e.g. 'show ?') and describes each
   possible
   argument.
2. Partial help is provided when an abbreviated argument is
   entered
   and you want to know what arguments match the input
   (e.g. 'show pr?'.)
```


logout

Exit from EXEC mode.

Syntax:

logout

Parameter:

none

Example:

```
SC60010# logout

press ENTER to get started
```

more

Display file

Syntax:

logout

Parameter:

<Path> File in FLASH or on TFTP server

Example:

```
SC60010# more
```

end

Go back to EXEC mode.

Syntax:

end

Example:

```
(config)# end
SC60010#
```

Cable Diagnostic keyword

Syntax:

CableDiag interface GigabitEthernet <port_type_id>

Parameter:

| | |
|-----------------------------|-------------------------|
| Interface | Interface keyword |
| GigabitEthernet | 1 Gigabit Ethernet Port |
| <port_type_id> | Port ID in 1/1-26 |

Example:

```
SC60010# CableDiag interface GigabitEthernet 1/1
Starting Cable Diagnostic - Please wait
Interface          Link Status   Test Result   Length
-----
GigabitEthernet 1/1  Link Down    detect error or check cable
length is between 7-120 meters
SC60010# CableDiag interface GigabitEthernet 1/1
Starting Cable Diagnostic - Please wait
Interface          Link Status   Test Result   Length
-----
GigabitEthernet 1/1  Link Down    detect error or check cable
length is between 7-120 meters
SC60010#
```

Table : CLEAR Commands

| Command | Function |
|----------------------------|---|
| <code>access</code> | Access management |
| <code>access-list</code> | Access list |
| <code>dot1x</code> | IEEE Standard for port-based Network Access Control |
| <code>ip</code> | Interface Internet Protocol config commands |
| <code>ipv6</code> | IPv6 configuration commands |
| <code>lacp</code> | Clear LACP statistics |
| <code>lldp</code> | Clears LLDP statistics. |
| <code>logging</code> | Syslog |
| <code>mac</code> | MAC Address Table |
| <code>mvr</code> | Multicast VLAN Registration configuration |
| <code>sflow</code> | Statistics flow. |
| <code>spanning-tree</code> | STP Bridge |
| <code>statistics</code> | Clear statistics for a given interface |

access

Access management.

Syntax:

```
clear access management statistics
```

Parameter:

management Access management configuration.

statistics Statistics data.

Example:

```
SC60010# clear access management statistics
SC60010#
```

access-list

Access list.

Syntax:

Clear access-list ace statistics

Parameter:

ace Access list entry

statistics Traffic statistics

Example:

```
SC60010# clear access-list ace statistics
SC60010#
```

dot1x

IEEE Standard for port-based Network Access Control.

Syntax

Clear dot1x statistics

Clear dot1x statistics interface GigabitEthernet < PORT_TYPE_LIST >

Parameter

statistics Clears the statistics counters

interface Interface

GigabitEthernet 1 Gigabit Ethernet Port

PORT_TYPE_LIST Port list in 1/1-26 for Gigabitethernet

EXAMPLE

```
SC60010# clear dot1x statistics interface GigabitEthernet 1/1-26
SC60010#
```

ip

Interface Internet Protocol config commands

Syntax

clear ip arp

clear ip dhcp detailed statistics { server | client | snooping | relay | helper | all } [interface (<port_type> [<in_port_list>])]

clear ip dhcp relay statistics

clear ip dhcp server binding <ip>

clear ip dhcp server binding { automatic | manual | expired }

clear ip dhcp server statistics

clear ip dhcp snooping statistics [interface (<port_type> [<in_port_list>])]

clear ip igmp snooping [vlan <v_vlan_list>] statistics

clear ip statistics [system] [interface vlan <v_vlan_list>] [icmp] [icmp-msg <type>]

Parameter

| | |
|--------------------------|-------------------------------------|
| arp | Clear ARP cache |
| dhcp | Dynamic Host Configuration Protocol |
| igmp | Internet Group Management Protocol |
| statistics | Traffic statistics |
| relay | DHCP relay agent configuration |
| snooping | DHCP snooping |
| interface | Select an interface to configure |
| GigabitEthernet | 1 Gigabit Ethernet Port |
| vlan | IPv4 traffic interface |
| <vlan_list> | VLAN identifier(s): VID |

EXAMPLE

```
SC60010# clear ip arp
SC60010# clear ip dhcp detailed statistics all
interface GigabitEthernet 1/1-26
SC60010# clear ip dhcp relay statistics
SC60010# clear ip dhcp server binding 192.168.1.11
SC60010# clear ip dhcp server binding automatic
SC60010# clear ip dhcp server statistics
SC60010# Clear ip dhcp snooping statistics interface
GigabitEthernet 1/1-26
SC60010# clear ip igmp snooping vlan 1 statistics
SC60010# clear ip statistics system interface
SC60010# clear ip statistics system interface vlan 1
icmp icmp-msg 2
```

ipv6

IPv6 configuration commands.

Syntax

clear ipv6 mld snooping [vlan <v_vlan_list>] statistics

clear ipv6 neighbors

clear ipv6 statistics [system] [interface vlan <v_vlan_list>] [icmp] [icmp-msg <type>]

Parameter

| | |
|--------------------------|---|
| mld | Multicasat Listener Discovery |
| neighbors | Ipv6 neighbors |
| statistics | Traffic statistics |
| snooping | Snooping MLD |
| statistics | Running MLD snooping counters |
| vlan | Ipv6 interface traffic |
| <vlan_list> | VLAN identifier(s): VID |
| icmp | IPv6 ICMP traffic |
| icmp-msg | IPv6 ICMP traffic for designated message type |
| interface | Select an interface to configure |
| system | IPv6 system traffic |
| < 0~255> | ICMP message type ranges from 0 to 255 |

EXAMPLE

```
SC60010# clear ipv6 mld snooping vlan 3 statistics
SC60010# clear ipv6 neighbors
SC60010# Clear ipv6 statistics system icmp icmp-msg 2
```

larp

Clear LACP statistics

Syntax

Clear larp statistics

Parameter

statistics Clear all LACP statistics

EXAMPLE

```
SC60010# clear larp statistics
SC60010#
```

lldp

Clears LLDP statistics.

Syntax

Clear lldp statistics

Clear lldp statistics | begin | exclude | include >< LINE >

Parameter

statistics Clears LLDP statistics.
| Output modifiers
begin Begin with the line that matches
exclude Exclude lines that match
include Include lines that match
<LINE> String to match output lines

EXAMPLE

```
SC60010# clear lldp statistics | begin LINE
SC60010#
```

logging

Syslog.

Syntax

```
clear logging [ info ] [ warning ] [ error ] [ switch <switch_list> ]
```

Parameter

| | |
|----------------|-------------|
| error | Error |
| info | Information |
| warning | Warning |

EXAMPLE

```
SC60010# clear logging info error warning
SC60010#
```

mac

MAC Address Table.

Syntax

```
Clear mac address-table
```

Parameter

| | |
|----------------------|--------------------------|
| address-table | Flush MAC Address table. |
|----------------------|--------------------------|

EXAMPLE

```
SC60010# clear mac address-table
SC60010#
```

mvr

Multicast VLAN Registration configuration.

Syntax

```
clear mvr [ vlan <v_vlan_list> | name <mvr_name> ] statistics
```

Parameter

| | |
|--------------------------|-------------------------------|
| name | MVR multicast name |
| statistics | Running MVR protocol counters |
| vlan | MVR multicast vlan |
| < word16 > | MVR multicast VLAN name |
| <vlan_list> | MVR multicast VLAN list |

EXAMPLE

```
SC60010# clear mvr vlan 25 statistics
SC60010#
```

sflow

Statistics flow.

Syntax

```
clear sflow statistics { receiver [ <receiver_index_list> ] | samplers [ interface [ <samplers_list> ] ( <port_type>
[ <v_port_type_list> ] ) ] }
```

Parameter

| | |
|----------------------------------|---|
| interface | Interface |
| receiver | Clear statistics for receiver. |
| <port_type> | GigabitEthernet |
| <Samplers : option> | runtime |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010# clear sflow statistics interface
GigabitEthernet 1/1-26
```

spanning-tree

STP Bridge.

Syntax

```
clear spanning-tree { { statistics [ interface ( <port_type> [ <v_port_type_list> ] ) ] } | { detected-protocols
[ interface ( <port_type> [ <v_port_type_list_1> ] ) ] } }
```

Parameter

| | |
|-------------------------------|---|
| detected-protocols | Set the STP migration check |
| statistics | STP statistics |
| interface | Choose port |
| <port_type> | GigabitEthernet |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010# clear spanning-tree detected-protocols interface GigabitEthernet  
1/1-26
```

statistics

Clear statistics for a given interface

Syntax

clear statistics interface <port_type> <port_type_list>

clear statistics <port_type> <port_type_list>

Parameter

<port_type> GigabitEthernet

<port_type_list> Port list in 1/1-26 for Gigabitethernet

EXAMPLE

```
SC60010# clear statistics GigabitEthernet 1/1-26  
SC60010#
```

Table : CONFIGURE Commands

| Command | Function |
|----------------|---|
| terminal | Configure from the terminal |
| aaa | Authentication, Authorization and Accounting |
| access | Access management |
| access-list | Access list |
| aggregation | Aggregation mode |
| banner | Define a login banner |
| clock | Configure time-of-day clock |
| default | Set a command to its defaults |
| dms | Enable DMS Maste |
| do | To run exec commands in config mode |
| dot1x | IEEE Standard for port-based Network Access Control |
| enable | Modify enable password parameters |
| end | Go back to EXEC mode |
| exit | Exit from Configuration mode |
| event | Trap event severity level |
| green-ethernet | Green ethernet (Power reduction) |
| gvrp | Enable GVRP feature |
| help | Description of the interactive help system |
| hostname | Set system's network name |
| interface | Select an interface to configure |
| ip | Internet Protocol |
| ipmc | IPv4/IPv6 multicast configuration |

| | |
|--------------------------------------|---|
| ipv6 | IPv6 configuration commands |
| lACP | LACP settings |
| line | Configure a terminal line |
| lldp | LLDP configurations. |
| logging | Syslog |
| loop-protect | Loop protection configuration |
| mac | MAC table entries/configuration |
| monitor | Set monitor configuration. |
| mvr | Multicast VLAN Registration configuration |
| no | Negate a command or set its defaults |
| non-stop-poe | Enable Non-Stop PoE Status |
| ntp | Configure NTP |
| poe | power over ethernet |
| port-security | Enable/disable port security globally. |
| Privilege | Command privilege parameters |
| qos | Quality of Service |
| radius-server | Configure RADIUS |
| rmon | Remote Monitoring |
| sflow | Statistics flow. |
| smtp | Set email information |
| snmp-server | Set SNMP server's configurations |
| spanning-tree | Spanning Tree protocol |
| switch2go-management | Switch2go Management configuration |
| system | Set the SNMP server's configurations |
| tacacs-server | Configure TACACS+ |
| upnp | Set UPnP's configurations |

| | |
|-----------------------|------------------------------------|
| <code>username</code> | Establish User Name Authentication |
| <code>vlan</code> | VLAN commands |
| <code>voice</code> | Voice appliance attributes |
| <code>web</code> | Web |

terminal

Configure from the terminal.

Syntax

configure terminal

EXAMPLE

```
SC60010# configure terminal
SC60010(config)#
```

aaa

Authentication, Authorization and Accounting.

SYNTAX

```
aaa authentication login { console | telnet | ssh | http } { { local | radius | tacacs } [ { local | radius | tacacs } ] [ { local | radius | tacacs } ] }
```

Parameter

| | |
|-----------------------|-------------------|
| authentication | Authentication |
| login | Login |
| console | Configure Console |
| http | Configure HTTP |
| ssh | Configure SSH |

| | |
|---------------|---------------------------------------|
| telnet | Configure Telnet |
| local | Use local database for authentication |
| radius | Use RADIUS for authentication |
| tacacs | Use TACACS+ for authentication |

EXAMPLE

```
SC60010 (config) # aaa authentication login http radius
SC60010 (config) #
```

access

Access management.

SYNTAX

access management

access management <access_id> <access_vid> <start_addr> [to <end_addr>] { [web] [snmp] [telnet] | all }

Parameter

| | |
|-------------------|---|
| management | Access management configuration |
| < 1-16 > | ID of access management entry |
| < 1-4094 > | The VLAN ID for the access management entry |
| < ipv4_addr > | Start IPv4 address |
| < ipv6_addr > | Start IPv6 address |
| all | All services |
| snmp | SNMP service |
| telnet | TELNET/SSH service |
| to | End address of the range |
| web | Web service |

EXAMPLE

```

SC60010(config)# access management 10 3 192.168.1.1 all
SC60010(config)#

```

access-list

Table : configure – access-list Commands

| Command | Function |
|--------------|-------------------|
| ace | Access list entry |
| rate-limiter | Rate limiter |

ace

Access list entry.

SYNTAX

access-list ace{ update<1-256> | <1-256> } [action< deny | filter | permit >]

access-list ace{ update<1-256> | <1-256> } [dmac-type < any | broadcast | multicast | unicast >]

access-list ace{ update<1-256> | <1-256> } [frametype < any | arp | etype | ipv4 | ipv4-icmp | ipv4-tcp | ipv4-udp | ipv6 | ipv6-icmp | ipv6-tcp | ipv6-udp >]

access-list ace{ update<1-256> | <1-256> } [ingress] [ingress interface { <port_type> <port_type_id> | <port_type> <port_type_list> } | any }

access-list ace{ update<1-256> | <1-256> } [logging [disable]]

access-list ace{ update<1-256> | <1-256> } [lookup [disable]]

access-list ace{ update<1-256> | <1-256> } [mirror [disable]]

access-list ace{ update<1-256> | <1-256> } [next { <1-256> | last }]

access-list ace{ update<1-256> | <1-256> } [policy <0-255> [policy-bitmask <0x0-0xFF>]]

access-list ace{ update<1-256> | <1-256> } [rate-limiter { <1-16> | disable }]

access-list ace{ update<1-256> | <1-256> } [redirect | interface { <port_type> <port_type_id> | <port_type> <port_type_list> } | disable }]

access-list ace{ update<1-256> | <1-256> } [shutdown]

access-list ace{ update<1-256> | <1-256> } [tag { tagged | untagged | any }]

access-list ace{ update<1-256> | <1-256> } [tag-priority { <0-7> | any }]

access-list ace{ update<1-256> | <1-256> } [vid { <1-4095> | any }]

Parameter

| | |
|---------------------|--|
| action | Access list action |
| dmac-type | The type of destination MAC address |
| frametype | Frame type |
| ingress | Ingress |
| logging | Logging frame information |
| lookup | Second lookup |
| mirror | Mirror frame to destination mirror port |
| next | insert the current ACE before the next ACE ID |
| policy | Policy |
| rate-limiter | Rate limiter |
| redirect | Redirect frame to specific port |
| shutdown | Shutdown incoming port |
| tag | Tag |
| tag-priority | Tag priority |
| vid | VID field |
| deny | Deny |
| filter | Filter |
| permit | Permit |
| any | Don't-care the type of destination MAC address |
| broadcast | Broadcast destination MAC address |
| multicast | Multicast destination MAC address |
| unicast | Unicast destination MAC address |

| | |
|-------------------------------|---|
| any | Don't-care the frame type |
| arp | Frame type of ARP |
| etype | Frame type of etype |
| ipv4 | Frame type of IPv4 |
| ipv4-icmp | Frame type of IPv4 ICMP |
| ipv4-tcp | Frame type of IPv4 TCP |
| ipv4-udp | Frame type of IPv4 TCP |
| ipv6 | Frame type of IPv4 |
| ipv6-icmp | Frame type of IPv6 ICMP |
| ipv6-tcp | Frame type of IPv6 TCP |
| ipv6-udp | Frame type of IPv6 UDP |
| interface | Select an interface to configure |
| <port_type> | Gigabitethernet |
| * | All switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet port |
| <port_type_id> | Port ID in the format of switch-no/port-no ex, 1/1-26 for Gigabitethernet |
| <port_type> | * or Gigabitethernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 |
| any | Don't-care the ingress interface |
| <0-255> | Policy ID |
| policy-bitmask | The bitmask for policy ID |
| <0x0-0xFF> | The value of policy bitmask |
| <1-4095> | The value of VID field |
| <0-7> | The value of tag priority |

EXAMPLE

```
SC60010(config)# access-list ace 10 action deny
SC60010(config)#
```

rate-limiter

Rate limiter.

SYNTAX

```
access-list rate-limiter [ <1~16> ] { pps <0-3276700> | 100kbps <0-10000> }
```

Parameter

| | |
|---------------------------------------|----------------------|
| 100kbps | 100k bits per second |
| <RateLimiterList : 1~16> | Rate limiter ID |
| <PpsRate : 0-3276700> | Rate value |
| <0-10000> | Rate value |

EXAMPLE

```
SC60010(config)# access-list rate-limiter 100kbps
111
SC60010(config)#
```

aggregation

Aggregation mode.

SYNTAX

```
aggregation mode { [ dmac ] [ ip ] [ dmac ] [ port ] }
```

Parameter

| | |
|-------------|--|
| mode | Traffic distribution mode |
| dmac | Destination MAC affects the distribution |

| | |
|-------------|-------------------------------------|
| ip | IP address affects the distribution |
| port | IP port affects the distribution |
| smac | Source MAC affects the distribution |

EXAMPLE

```
SC60010(config)# aggregation mode ip port dmac smac
SC60010(config)#
```

banner

Define a login banner

SYNTAX

banner [motd] <banner>

banner exec <banner>

banner login <banner>

Parameter

<LINE> c banner-text c, where 'c' is a delimiting character

exec Set EXEC process creation banner

login Set login banner

motd Set Message of the Day banner

EXAMPLE

```
SC60010(config)# banner exec LINE
Enter TEXT message. End with the character 'L'.
L
SC60010(config)#
```

clock

Configure time-of-day clock.

SYNTAX

```
clock set <icliDate> <icliTime>
```

```
clock summer-time <word16> date [ <start_month_var> <start_date_var> <start_year_var> <start_hour_var>  
<end_month_var> <end_date_var> <end_year_var> <end_hour_var> [ <offset_var> ] ]
```

```
clock summer-time <word16> recurring [ <start_week_var> <start_day_var> <start_month_var>  
<start_hour_var> <end_week_var> <end_day_var> <end_month_var> <end_hour_var> [ <offset_var> ] ]
```

```
clock timezone <word_var> <hour_var> [ <minute_var> ]
```

Parameter

set set clock

summer-time Configure summer (daylight savings) time

timezone Configure time zone

<date> yyyy/mm/dd

<time> hh:mm:ss

<2000-2097> Year to start

hh:mm Time to start (hh:mm)

<1-12> Month to end

<1-31> Date to end

<2000-2097> Year to end

hh:mm Time to end (hh:mm)

<1-1440> Offset to add in minutes

<1-5> Week number to start

<1-7> Weekday to start

<1-12> Month to start

EXAMPLE

```
SC60010(config)# clock set 2016/09/30 10:22:03
2016-09-30T10:22:03+00:00
SC60010(config)# do show clock
System Time      : 2016-09-30T10:22:48+00:00
```

default

Set a command to its defaults

SYNTAX

```
default access-list rate-limiter [ <rate_limiter_list> ]
```

Parameter

| | |
|-------------------------------------|-----------------|
| access-list | Access list |
| rate-limiter | Rate limiter |
| <RateLimiterId : 1-16> | Rate limiter ID |

EXAMPLE

```
SC60010(config)# default access-list rate-limiter 3
SC60010(config)#
```

dms

Enable DMS Maste

SYNTAX

```
dms mode [ disabled | enabled | high-priority ]
```

Parameter

| | |
|----------------------|---------------------------|
| mode | DMS mode |
| disabled | DMS mode is disabled |
| enabled | DMS mode is enabled |
| high-priority | DMS mode is high priority |

EXAMPLE

```
SC60010(config)# dms mode high-priority
SC60010(config)#
```

do

To run exec commands in config mode.?

SYNTAX

```
do <LINE >{[<LINE >]}
```

Parameter

<LINE> Exec Command

EXAMPLE

```
SC60010(config)# do show vlan
VLAN  Name                               Ports
-----
-----
1     default                               GigabitEthernet 1/1, GigabitEthernet 1/2,
GigabitEthernet 1/3,
                                           GigabitEthernet 1/4, GigabitEthernet 1/5
SC60010(config)#
```

dot1x

IEEE Standard for port-based Network Access Control.

SYNTAX

```
dot1x authentication timer inactivity <v_10_to_100000>
```

```
dot1x authentication timer re-authenticate <v_1_to_3600>
```

dot1x feature { [guest-vlan] [radius-qos] [radius-vlan] }*1

dot1x guest-vlan <value>

dot1x guest-vlan supplicant

dot1x max-reauth-req <value>

dot1x re-authentication

dot1x system-auth-control

dot1x timeout quiet-period <v_10_to_1000000>

dot1x timeout tx-period <v_1_to_65535>

Parameter

| | |
|------------------------------|---|
| authentication | Authentication |
| feature | Globally enables/disables a dot1x feature functionality |
| guest-vlan | Guest VLAN |
| max-reauth-req | Guest VLAN ID used when entering the Guest VLAN. |
| re-authentication | Set Re-authentication state |
| system-auth-control | Set the global NAS state |
| timeout | timeout |
| timer | timer |
| inactivity addresses. | Time in seconds between check for activity on successfully authenticated MAC addresses. |
| re-authenticate | The period between re-authentication attempts in seconds |
| <10-1000000> | seconds |
| <1-3600> | seconds |
| guest-vlan | Globally enables/disables state of guest-vlan |
| radius-qos | Globally enables/disables state of RADIUS-assigned QoS. |
| radius-vlan | Globally enables/disables state of RADIUS-assigned VLAN. |
| <1-4095> | The number of times a Request Identity EAPOL frame is sent |

without response before considering entering the Guest VLAN.

supplicant

The switch remembers if an EAPOL frame has been received on the port for the life-time of the port. Once the switch considers whether to enter the Guest VLAN, it will first check if this option is enabled or disabled. If disabled (unchecked; default), the switch will only enter the Guest VLAN if an EAPOL frame has not been received on the port for the life-time of the port. If enabled (checked), the switch will consider entering the Guest VLAN even if an EAPOL frame has been received on the port for the life-time of the port.

<1-255>

number of times

quiet-period

Time in seconds before a MAC-address that failed authentication gets a new authentication chance.

tx-period

the time between EAPOL retransmissions.

<10-1000000>

seconds

<1-65535>

seconds

EXAMPLE

```
SC60010(config)# dot1x authentication timer inactivity 1000
SC60010(config)# dot1x feature guest-vlan radius-qos radius-vlan
SC60010(config)# dot1x guest-vlan 33
SC60010(config)# dot1x max-reauth-req 3
SC60010(config)# dot1x re-authentication
SC60010(config)# dot1x system-auth-control
SC60010(config)# dot1x timeout quiet-period 3000
```


enable

Modify enable password parameters.

SYNTAX

```
enable password [ <level> <1-15> ] <WORD>
```

```
enable secret { 0 | 5 } [ < level> <1-15> ] <WORD>
```

Parameter

| | |
|---------------------|---|
| password | Assign the privileged level clear password |
| secret | Assign the privileged level secret |
| WORD | The UNENCRYPTED (cleartext) password |
| level | Set exec level password |
| <1-15> | Level number |
| 0 | Specifies an UNENCRYPTED password will follow |
| 5 | Specifies an ENCRYPTED secret will follow |

EXAMPLE

```
SC60010(config)# enable password level 10 999
SC60010(config)#
```

event

Trap event severity level.

SYNTAX

```
event group [ ACL | ACL-Log | AUTO-SAVING | Access-Mgmt | Auth-Failed | Cold-Start | Config-Info | DMS |
Firmware-Upgrade | Import-Export | LACP | Link-Status | Login | Logout | Loop-Protect | Mgmt-IP-Change |
Module-Change | NAS | Password-Change | PoE-Auto-Check | Port-Security | Spanning-Tree | Warm-Start ]
[ ( ipush | smtp | syslog | trap ) (disable | enable ) ] [ level <0-7> ]
```

Parameter

| | |
|-------------------------|-------------------------------|
| ACL | Group ID ACL |
| ACL-Log | Group ID ACL Log |
| AUTO-SAVING | Group ID Auto Saving |
| Access-Mgmt | Group ID Access Management |
| Auth-Failed | Group ID Auth Fail |
| Cold-Start | Group ID Cold Start |
| Config-Info | Group ID Config Info |
| DMS | Group ID DMS |
| Firmware-Upgrade | Group ID Firmware Upgrade |
| Import-Export | Group ID Import Export |
| LACP | Group ID LACP |
| Link-Status | Group ID Link Status |
| Login | Group ID Login |
| Logout | Group ID Logout |
| Loop-Protect | Group ID Loop Protect |
| Mgmt-IP-Change | Group ID Management IP Change |
| Module-Change | Group ID Module Change |
| NAS | Group ID NAS |
| Password-Change | Group ID Password Change |
| PoE-Auto-Check | Group ID PoE Auto Check |
| Port-Security | Group ID Port Security |
| Spanning-Tree | Group ID Spanning Tree |
| Warm-Start | Group ID Warm Start |
| ipush | ipush mode |
| level | Severity level |
| smtp | smtp mode |

| | |
|--------------------|---|
| syslog | syslog mode |
| trap | trap mode |
| disable | ipush mode disable |
| enable | ipush mode enable |
| <0-7> | <0> Emergency ,<1> Alert ,<2> Critical ,<3> Error ,<4> Warning ,<5> Notice ,<6> Informationl ,<7> Debug |
| disable | smtp/ syslog/ trap mode disable |
| enable | smtp/ syslog/ trap mode enable |

EXAMPLE

```
SC60010(config)# event group Config-Info level 6
SC60010(config)#
```

green-ethernet

Green ethernet (Power reduction)

SYNTAX

green-ethernet eee optimize-for-power

Parameter

| | |
|---------------------------|---|
| eee | Powering down of PHYs when there is no traffic. |
| optimize-for-power | Set if EEE shall be optimized for least power consumption (else optimized for least traffic latency). |

EXAMPLE

```
SC60010(config)# green-ethernet eee optimize-for-power
SC60010(config)#
```

gvrp

Enable GVRP feature

SYNTAX

gvrp

gvrp max-vlans <1-4095>

gvrp time { [join-time <1-20>] [leave-time <60-300>] [leave-all-time <1000-5000>] }*1

Parameter

time config gvrp timer value in units of centi seconds [cs]

EXAMPLE

```
SC60010(config)# gvrp max-vlans 333
SC60010(config)# gvrp time join-time 13 leave-all-time 3000 leave-time 200
SC60010(config)#
```

hostname

Set system's network name.

SYNTAX

hostname < WORD >

Parameter

WORD This system's network name.

EXAMPLE

```
SC60010(config)# hostname abc
abc(config)#
```

interface

Select an interface to configure.

SYNTAX

interface (<port_type> [<plist>])

interface vlan <vlist>

Parameter

| | |
|-------------------------------|---|
| <port_type> | GigabitEthernet |
| vlan | VLAN interface configurations |
| <vlan_list> | List of VLAN interface numbers, 1-4095 |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010(config)# interface GigabitEthernet 1/1-8
SC60010(config-if)# poe weekday Fri hour 22
SC60010(config-if)# SC60010(config)# interface vlan 3
SC60010(config-if-vlan)# ip address dhcp
SC60010(config-if-vlan)#
```

ip

Internet Protocol.

SYNTAX

ip arp inspection

ip arp inspection entry interface <port_type> <in_port_type_id> <vlan_var> <mac_var> <ipv4_var>

ip arp inspection translate [interface <port_type> <in_port_type_id> <vlan_var> <mac_var> <ipv4_var>]

ip arp inspection vlan <in_vlan_list>

ip arp inspection vlan <in_vlan_list> logging { deny | permit | all }

ip dhcp excluded-address <low_ip> [<high_ip>]

ip dhcp pool <pool_name>

ip dhcp relay

ip dhcp relay information option

ip dhcp relay information policy { drop | keep | replace }

ip dhcp server

ip dhcp snooping

ip dns proxy

ip helper-address <v_ipv4_ucast>

ip http secure-redirect

ip http secure-server

ip igmp host-proxy [leave-proxy]

ip igmp snooping

ip igmp snooping vlan <v_vlan_list>

ip igmp ssm-range <v_ipv4_mcast> <ipv4_prefix_length>

ip igmp unknown-flooding

ip name-server { <v_ipv4_addr> | dhcp [interface vlan <v_vlan_id>] }

ip route <v_ipv4_addr> <v_ipv4_netmask> <v_ipv4_gw>

ip routing

ip source binding interface <port_type> <in_port_type_id> <vlan_var> <ipv4_var> <mac_var>

ip ssh

ip verify source

ip verify source translate

Parameter

| | |
|-----------------------|-------------------------------------|
| arp | Address Resolution Protocol |
| dhcp | Dynamic Host Configuration Protocol |
| dns | Domain Name System |
| helper-address | DHCP relay server |

| | |
|-----------------------------|--|
| http | Hypertext Transfer Protocol |
| igmp | Internet Group Management Protocol |
| name-server | Domain Name System |
| route | Add IP route |
| routing | Enable routing for IPv4 and IPv6 |
| source | source command |
| ssh | Secure Shell |
| verify | verify command |
| inspection | ARP inspection |
| entry | arp inspection entry |
| interface | arp inspection entry interface config |
| <port_type> | Port type in Fast, Giga ethernet |
| <port_type_id> | Port ID in the format of switch-no/port-no |
| <vlan_id> | Select a VLAN id to configure |
| <mac_ucast> | Select a MAC address to configure |
| <ipv4_ucast> | Select an IP Address to configure |
| deny | log denied entries |
| permit | log permitted entries |
| all | log all entries |
| translate | arp inspection translate all entries |
| vlan | arp inspection vlan setting |
| <vlan_list> | arp inspection vlan list |
| relay | DHCP relay agent information |
| information | DHCP information option <Option 82> |
| option | DHCP option |
| information | DHCP information option(Option 82) |

| | |
|-----------------------------|---|
| policy | Policy for handling the receiving DHCP packet already include the information option |
| drop | Drop the package when receive a DHCP message that already contains relay information |
| keep | Keep the original relay information when receive a DHCP message that already contains it |
| replace | Replace the original relay information when receive a DHCP message that already contains it |
| server | Enable DHCP server |
| snooping | DHCP snooping |
| proxy | DNS proxy service |
| secure-redirect | Secure HTTP web redirection |
| secure-server | Secure HTTP web server |
| snooping | Snooping IGMP |
| <word16> | Profile name in 16 char's |
| vlan | IGMP VLAN |
| ssm-range | IPv4 address range of Source Specific Multicast |
| <ipv4_mcast> | Valid IPv4 multicast address |
| <4-32> | Prefix length ranges from 4 to 32 |
| unknown-flooding | Flooding unregistered IPv4 multicast traffic |
| <ipv4_ucast> | A valid IPv4 unicast address |
| dhcp | Dynamic Host Configuration Protocol |
| interface | Select an interface to configure |
| vlan | VLAN Interface |
| <vlan_id> | VLAN identifier(s): VID |
| <ipv4_addr> | Network |
| <ipv4_netmask> | Netmask |
| <ipv4_addr> | Gateway |
| binding | ip source binding |

| | |
|-----------------------------|---|
| interface | ip source binding entry interface config |
| <port_type> | * or Gigabitethernet |
| * | All switches or All ports |
| Gigabitethernet | 1 Gigabitethernet Port |
| <port_type_id> | Port ID in the format of switch-no/port-no, ex 1/1-26 for Gigabitethernet |
| <vlan_id> | Select a VLAN id to configure |
| <ipv4_ucast> | Select an IP Address to configure |
| <ipv4_netmask> | Select a subnet mask to configure |
| <mac_ucast> | Select a MAC address to configure |
| source | verify source |
| limit | limit command |
| <0-2> | the number of limit |
| translate | ip verify source translate all entries |
| login | ARP inspection vlan logging mode config |

EXAMPLE

```

SC60010(config)# ip arp inspection
SC60010(config)# ip dhcp relay
SC60010(config)# ip dns proxy
SC60010(config)# ip helper-address 192.168.1.1
SC60010(config)# ip http secure-server
SC60010(config)# ip igmp snooping vlan 3
SC60010(config)# ip name-server 192.168.1.6
SC60010(config)# ip route 192.168.1.1 255.255.255.0 192.168.1.100
SC60010(config)# ip routing
SC60010(config)# ip ssh
SC60010(config)# ip verify source translate
IP Source Guard:
    Translate 0 dynamic entries into static entries.

```

ipmc

IPv4/IPv6 multicast configuration.

SYNTAX

ipmc profile

ipmc profile <profile_name>

ipmc range <entry_name> { <v_ipv4_mcast> [<v_ipv4_mcast_1>] | <v_ipv6_mcast> [<v_ipv6_mcast_1>] }

Parameter

| | |
|---------------------------|--|
| profile | IPMC profile configuration |
| range | A range of IPv4/IPv6 multicast addresses for the profile |
| < word16 > | Range entry name in 16 char's |
| <ipv4_mcast> | Valid IPv4 multicast address |
| <ipv6_mcast> | Valid IPv6 multicast address |

EXAMPLE

```
SC60010(config)# ipmc profile test
SC60010(config-ipmc-profile)#
```

ipv6

IPv6 configuration commands

SYNTAX

ipv6 mld host-proxy [leave-proxy]

ipv6 mld snooping

ipv6 mld snooping vlan <v_vlan_list>

ipv6 mld ssm-range <v_ipv6_mcast> <ipv6_prefix_length>

ipv6 mld unknown-flooding

ipv6 route <v_ipv6_subnet> { <v_ipv6_ucast> | interface vlan <v_vlan_id> <v_ipv6_addr> }

Parameter

| | |
|---------------------------------|---|
| mld | Multicasat Listener Discovery |
| route | Configure static routes |
| host-proxy | MLD proxy configuration |
| snooping | Snooping MLD |
| ssm-range | IPv6 address range of Source Specific Multicast |
| unknown-flooding | Flooding unregistered IPv6 multicast traffic |
| leave-proxy | MLD proxy for leave configuration |
| vlan | MLD VLAN |
| <vlan_list> | VLAN identifier(s): VID |
| <ipv6_mcast> | Valid IPv6 multicast address |
| X:X:X:X::X/<0-128> | IPv6 prefix x:x::y/z |

EXAMPLE

```
SC60010(config)# ipv6 mld host-proxy leave-proxy
SC60010(config)# ipv6 mld snooping vlan 1
SC60010(config)#
```

lACP

LACP settings.

SYNTAX

```
lACP system-priority <1-65535>
```

Parameter

| | |
|------------------------|---|
| system-priority | System priority |
| <1-65535> | Priority value, lower means higher priority |

EXAMPLE

```
SC60010(config)# lacp system-priority 333
SC60010(config)#
```

line

Configure a terminal line.

SYNTAX

```
line { <0~16> | console 0 | vty <0~15> }
```

Parameter

| | |
|---------------------|-----------------------|
| <0~16> | List of line numbers |
| console | Console terminal line |
| 0 | Console Line number |
| vtty | Virtual terminal |
| <0~15> | List of vty numbers |

EXAMPLE

```
SC60010(config)# line console 0
SC60010(config-line)#
```

lldp

LACP configurations.

SYNTAX

```
lldp holdtime <2-10>
```

```
lldp med datum { wgs84 | nad83_navd88 | nad83_mllw }
```

```
lldp med fast <1-10>
```

```
lldp med location-tlv altitude { meters | floors } <word11>
```

lldp med location-tlv civic-addr { country | state | county | city | district | block | street | leading-street-direction | trailing-street-suffix | street-suffix | house-no | house-no-suffix | landmark | additional-info | name | zip-code | building | apartment | floor | room-number | place-type | postal-community-name | p-o-box | additional-code } <string250>

lldp med location-tlv elin-addr <dword25>

lldp med location-tlv latitude { north | south } <word8>

lldp med location-tlv longitude { west | east } <word9>

lldp med media-vlan policy-list <range_list>

lldp med media-vlan-policy <0-31> { voice | voice-signaling | guest-voice-signaling | guest-voice | softphone-voice | video-conferencing | streaming-video | video-signaling } { tagged <vlan_id> | untagged } [l2-priority <0-7>] [dscp <0-63>]

lldp reinit <1-10>

lldp timer <5-32768>

lldp transmission-delay <1-8192>

Parameter

| | |
|---------------------------|--|
| holdtime | Sets LLDP hold time (The neighbor switch will discarded the LLDP information after "hold time" multiplied with "timer" seconds). |
| med | Media Endpoint Discovery. |
| reinit | LLDP tx reinitialization delay in seconds. |
| timer | Sets LLDP TX interval (The time between each LLDP frame transmitted in seconds). |
| transmission-delay | Sets LLDP transmission-delay. LLDP transmission delay (the amount of time that the transmission of LLDP frames will delayed after LLDP configuration has changed) in seconds.) |
| <2-10> | 2-10 seconds. |

| | |
|---------------------------------|--|
| <1-10> | 1-10 seconds. |
| <5-32768> | 5-32768 seconds. |
| <1-8192> | 1-8192 seconds. |
| datum | Datum (geodetic system) type. |
| fast | Number of times to repeat LLDP frame transmission at fast start. |
| location-tlv | LLDP-MED Location Type Length Value parameter. |
| media-vlan-policy | Use the media-vlan-policy to create a policy, which can be assigned to an interface. |
| nad83_mllw | Mean lower low water datum 1983 |
| nad83_navd88 | North American vertical datum 1983 |
| wgs84 | World Geodetic System 1984 |
| altitude | Altitude parameter |
| meter | Altitude value |
| floors | Altitude value |
| civic-addr | Civic address information and postal information |
| country | The two-letter ISO 3166 country code in capital ASCII letters - Example: DK, DE or US. |
| state | National subdivisions (state, canton, region, province, prefecture). |
| county | County, parish, gun (Japan), district. |
| city | City, township, shi (Japan) - Example: Copenhagen. |
| district | City division, borough, city district, ward, chou (Japan). |
| block | Neighbourhood, block. |
| street | Street - Example: Poppelvej. |
| leading-street-direction | Leading street direction - Example: N. |
| trailing-street-suffix | Trailing street suffix - Example: SW. |

| | |
|------------------------------|---|
| street-suffix | Street suffix - Example: Ave, Platz. |
| house-no | House number - Example: 21. |
| house-no-suffix | House number suffix - Example: A, 1/2. |
| landmark | Landmark or vanity address - Example: Columbia University. |
| additional-info | Additional location info - Example: South Wing. |
| name | Name (residence and office occupant) - Example: Flemming Jahn. |
| zip-code | Postal/zip code - Example: 2791. |
| building | Building (structure) - Example: Low Library. |
| apartment | Unit (Apartment, suite) - Example: Apt 42. |
| floor | Floor - Example: 4. |
| room-number | Room number - Example: 450F. |
| place-type | Place type - Example: Office. |
| postal-community-name | Postal community name - Example: Leonia. |
| p-o-box | Post office box (P.O. BOX) - Example: 12345. |
| additional-code | Additional code - Example: 1320300003. |
| <string250> | Value for the corresponding selected civic address. |
| elin-addr | Emergency Location Identification Number, (e.g. E911 and others), such as defined by TIA or NENA. |
| <dword25> | ELIN value |
| north | Setting latitude direction to north. |
| south | Setting latitude direction to south. |
| <word8> | Latitude degrees (0.0000-90.0000). |
| policy-list | Assignment of policies. |
| <range_list> | Policies to assign to the interface. |
| <0-31> | Policy id for the policy which is created. |
| voice | Create a voice policy. |

| | |
|------------------------------|---|
| voice-signaling | Create a voice signaling policy. |
| guest-voice-signaling | Create a guest voice signaling policy. |
| guest-voice | Create a guest voice policy. |
| softphone-voice | Create a softphone voice policy. |
| video-conferencing | Create a video conferencing policy. |
| streaming-video | Create a streaming video policy. |
| video-signaling | Create a video signaling policy. |
| tagged | The policy uses tagged frames. |
| <vlan_id> | The VLAN the policy uses tagged frames. |
| untagged | The policy uses un-tagged frames. |
| l2-priority | Layer 2 priority. |
| <0-7> | Priority 0-7 |
| dscp | Differentiated Services Code Point. |
| <0-63> | DSCP value 0-63. |

EXAMPLE

```

SC60010(config)# lldp holdtime 5
SC60010(config)# lldp med fast 5
SC60010(config)# lldp reinit 3
SC60010(config)# lldp timer 555
SC60010(config)# lldp transmission-delay 333
Note: According to IEEE 802.1AB-clause 10.5.4.2 the transmission-delay must
not be larger than LLDP timer * 0.25. LLDP timer changed to 13332

```

logging

Syslog.

SYNTAX

```
logging host { <ipv4_ucast> | <hostname> }
```


logging on

logging port

Parameter

| | |
|---------------------------|-------------------------------|
| host | host |
| <ipv4_ucast> | IP address of the log server |
| <hostname> | Domain name of the log server |
| on | Enable syslog server |
| port | Service port number |

EXAMPLE

```
SC60010 (config) # logging on
SC60010 (config) #
```

loop-protect

Loop protection configuration.

SYNTAX

loop-protect

loop-protect shutdown-time <0-604800>

loop-protect transmit-time <1-10>

Parameter

| | |
|-------------------------|--|
| shutdown-time | Loop protection shutdown time interval |
| <0-604800> | Shutdown time in second |
| transmit-time | Loop protection transmit time interval |
| <1-10> | Transmit time in second |

EXAMPLE

```
SC60010(config)# loop-protect
SC60010(config)# loop-protect shutdown-time 333
SC60010(config)# loop-protect transmit-time 3
SC60010(config)#
```

mac

MAC table entries/configuration.

SYNTAX

```
mac address-table aging-time <0,10-1000000>
```

```
mac address-table static <mac_addr> vlan <vlan_id> interface <port_type> <port_type_list>
```

Parameter

| | |
|-------------------------------|---|
| address-table | Mac Address Table |
| aging-time | Mac address aging time |
| <0,10-1000000> | Aging time in seconds, 0 disables aging |
| static | Static MAC address |
| <mac_addr> | 48 bit MAC address: xx:xx:xx:xx:xx:xx |
| vlan | VLAN keyword |
| <vlan_id> | VLAN IDs 1-4095 |
| interface | Select an interface to configure |
| <port_type> | Port type * or Gigabitethernet |
| * | All switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010(config)# mac address-table aging-time 3333
SC60010(config)#
```

monitor

Set monitor configuration.

SYNTAX

```
monitor destination interface <port_type> <port_type_id>
```

```
monitor source { interface <port_type> <port_type_list> | cpu } { both | rx | tx }
```

Parameter

| | |
|-------------------------------|--|
| destination | The destination port. That is the port that trafficed should be mirrored to. |
| interface | Interface to mirror traffic to. |
| source | The source port. That is the source port to be mirrored to the destination port. |
| interface | Mirrot interface traffic. |
| <port_type> | 1 Gigabit Ethernet port |
| * | All switches or all ports |
| <port_type_list> | Port list in 1/1-26. |
| cpu | Mirrot CPU traffic. |
| both | Setting source port to both will mirror both ingress and egress traffic. |
| rx | Setting source port to rx will mirror bothingress traffic. |
| tx | Setting source port to tx will mirror both egress traffic. |
| <port_type> | Port type in Gigabitethernet |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010(config)# monitor destination interface GigabitEthernet 1/8
SC60010(config)# monitor source cpu both
SC60010(config)#
```

mvr

Multicast VLAN Registration configuration.

SYNTAX

mvr

mvr name <mvr_name> channel <profile_name>

mvr name <mvr_name> frame priority <cos_priority>

mvr name <mvr_name> frame tagged

mvr name <mvr_name> igmp-address <v_ipv4_ucast>

mvr name <mvr_name> last-member-query-interval <ipmc_lmqi>

mvr name <mvr_name> mode { dynamic | compatible }

mvr vlan <v_vlan_list> [name <mvr_name>]

mvr vlan <v_vlan_list> channel <profile_name>

mvr vlan <v_vlan_list> frame priority <cos_priority>

mvr vlan <v_vlan_list> frame tagged

mvr vlan <v_vlan_list> igmp-address <v_ipv4_ucast>

mvr vlan <v_vlan_list> last-member-query-interval <ipmc_lmqi>

mvr vlan <v_vlan_list> mode { dynamic | compatible }

Parameter

| | |
|-----------------------|---------------------------------|
| name | MVR multicast name |
| <word16> | MVR multicast VLAN name |
| channel | MVR channel configuration |
| <word16> | Profile name in 16 char's |
| frame | MVR control frame in TX |
| priority | Interface CoS priority |
| <0-7> | CoS priority ranges from 0 to 7 |

| | |
|-----------------------------------|--|
| tagged | Tagged IGMP/MLD frames will be sent |
| igmp-address | MVR address configuration used in IGMP |
| <ipv4_ucast> | A valid IPv4 unicast address MVR multicast VLAN name |
| last-member-query-interval | Last Member Query Interval in tenths of seconds |
| <0-31744> | 0 - 31744 tenths of seconds |
| mode | MVR mode of operation |
| dynamic | Dynamic MVR operation mode |
| compatible | Compatible MVR operation mode |
| vlan | MVR multicast vlan |
| <vlan_list> | MVR multicast VLAN list |
| channel | MVR channel configuration |
| <word16> | Profile name in 16 char's |
| frame | MVR control frame in TX |
| priority | Interface CoS priority |
| <0-7> | CoS priority ranges from 0 to 7 |
| igmp-address | MVR address configuration used in IGMP |
| <ipv4_ucast> | A valid IPv4 unicast address |
| <vlan_list> | MVR multicast VLAN list |
| last-member-query-interval | Last Member Query Interval in tenths of seconds |
| <0-31744> | 0 - 31744 tenths of seconds |
| compatible | Compatible MVR operation mode |

EXAMPLE

```
SC60010(config)# mvr vlan 10 mode dynamic
SC60010(config)#
```

no

Negate a command or set its defaults

Table : configure – no Commands

| Command | Function |
|----------------|---|
| aaa | Authentication, Authorization and Accounting |
| access | Access management |
| access-list | Access list |
| aggregation | Aggregation mode |
| banner | Define a login banner |
| clock | Configure time-of-day clock |
| dot1x | IEEE Standard for port-based Network Access Control |
| enable | Modify enable password parameters |
| green-ethernet | Green ethernet (Power reduction) |
| gvrp | Enable GVRP feature |
| hostname | Set system's network name |
| interface | none |
| ip | Internet Protocol |
| ipmc | IPv4/IPv6 multicast configuration |
| ipv6 | IPv6 configuration commands |
| lacp | LACP settings |
| lldp | LLDP configurations. |
| logging | Syslog |
| loop-protect | Loop protection configuration |
| mac | MAC table entries/configuration |
| monitor | Set monitor configuration. |
| mvr | Multicast VLAN Registration configuration |
| non-stop-poe | Disable Non-Stop PoE Status |
| ntp | Configure NTP |
| poE | Power Over Ethernet |
| port-security | Enable/disable port security globally. |
| Privilege | Command privilege parameters |
| qos | Quality of Service |
| radius-server | Configure RADIUS |
| rmon | Remote Monitoring |
| sflow | Statistics flow. |
| snmp-server | Enable SNMP server |
| spanning-tree | STP Bridge |

| | |
|--------------------------------------|--------------------------------------|
| switch2go-management | SwitchAlert Management configuration |
| system | Set the SNMP server's configurations |
| tacacs-server | Configure TACACS+ |
| upnp | Set UPnP's configurations |
| username | Establish User Name Authentication |
| vlan | Vlan commands |
| voice | Voice appliance attributes |
| web | Web |

aaa

Authentication, Authorization and Accounting

SYNTAX

```
no aaa authentication login { console | telnet | ssh | http }
```

Parameter

| | |
|-----------------------|-----------------|
| authentication | Authentication |
| login | Login |
| console | Disable Console |
| http | Disable HTTP |
| ssh | Disable SSH |
| telnet | Disable Telnet |

EXAMPLE

```
SC60010(config)# no aaa authentication login ssh
SC60010(config)#
```

access

Access management

SYNTAX

```
no access management [<1~16>]
```

no access management

Parameter

management Access management configuration

<1~16> ID of access management entry

EXAMPLE

```
SC60010(config)# no access management
SC60010(config)#
```

access-list

Access list

SYNTAX

no access-list ace <1~256>

Parameter

ace Access list entry

<AceId : 1-256> ACE ID

EXAMPLE

```
SC60010(config)# access-list ace 1
SC60010(config)#
```

aggregation

Aggregation mode

SYNTAX

no aggregation mode

Parameter

mode Traffic distribution mode

EXAMPLE


```
SC60010(config)# no aggregation mode
SC60010(config)#
```

banner

Define a login banner

SYNTAX

no banner [motd]

no banner exec

no banner login

Parameter

exec Set EXEC process creation banner

login Set login banner

motd Set Message of the Day banner

EXAMPLE

```
SC60010(config)# no banner login
SC60010(config)#
```

clock

Configure time-of-day clock

SYNTAX

no clock summer-time

no clock timezone

Parameter

summer-time Configure summer (daylight savings) time

timezone Configure time zone

EXAMPLE

```
SC60010(config)# no clock summer-time
SC60010(config)# no clock timezone
SC60010(config)#
```

dot1x

IEEE Standard for port-based Network Access Control

SYNTAX

```
no dot1x authentication timer inactivity
no dot1x authentication timer re-authenticate
no dot1x feature { [ guest-vlan ] [ radius-qos ] [ radius-vlan ] }
no dot1x guest-vlan [supplicant]
no dot1x max-reauth-req
no dot1x re-authentication
no dot1x system-auth-control
no dot1x timeout quiet-period
no dot1x timeout tx-period
```

Parameter

| | |
|--------------------------|---|
| authentication | Authentication |
| feature | Globally enables/disables a dot1x feature functionality |
| guest-vlan | Guest VLAN |
| max-reauth-req | The number of time a Request Identity EAPOL frame is sent without response before considering entering the Guest VLAN. |
| re-authentication | Set Re-authentication state |

| | |
|----------------------------|---|
| system-auth-control | Set the global NAS state |
| timeout | timeout |
| timer | timer |
| inactivity | Time in seconds between check for activity on successfully authenticated MAC addresses. |
| re-authenticate | The period between re-authentication attempts in seconds |
| guest-vlan | Globally enables/disables state of guest-vlan |
| radius-qos | Globally enables/disables state of RADIUS-assigned QoS. |
| radius-vlan | Globally enables/disables state of RADIUS-assigned VLAN. |
| supplicant | The switch remembers if an EAPOL frame has been received on the port for the life-time of the port. Once the switch considers whether to enter the Guest VLAN, it will first check if this option is enabled or disabled. If disabled (unchecked; default), the switch will only enter the Guest VLAN if an EAPOL frame has not been received on the port for the life-time of the port. If enabled (checked), the switch will consider entering the Guest VLAN even if an EAPOL frame has been received on the port for the life-time of the port. |
| quiet-period | Time in seconds before a MAC-address that failed authentication gets a new authentication chance. |
| tx-period | the time between EAPOL retransmissions. |

EXAMPLE

```
SC60010(config)# no dot1x authentication timer inactivity
SC60010(config)# no dot1x feature guest-vlan radius-qos radius-vlan
SC60010(config)# no dot1x guest-vlan supplicant
SC60010(config)# no dot1x max-reauth-req
SC60010(config)# no dot1x re-authentication
SC60010(config)# no dot1x system-auth-control
SC60010(config)# no dot1x timeout tx-period
SC60010(config)#
```

enable

Modify enable password parameters

SYNTAX

```
no enable password [ level <1-15> ]
```

```
no enable secret [0|5 { level <1-15> }]
```

Parameter

| | |
|---------------------|---|
| password | Assign the privileged level clear password |
| secret | Assign the privileged level secret |
| 0 | Specifies an UNENCRYPTED password will follow |
| 5 | Specifies an ENCRYPTED password will follow |
| level | Set exec level password |
| <1-15> | Level number |

EXAMPLE

```
SC60010(config)# no enable secret level 15
SC60010(config)# no enable password level 15
SC60010(config)#
```

Green-ethernet

Green ethernet (Power reduction)

SYNTAX

```
no green-ethernet eee optimize-for-power
```

Parameter

| | |
|---------------------------|---|
| eee | Powering down of PHYs when there is no traffic. |
| optimize-for-power | Set if EEE shall be optimized for least power consumption (else optimized for least traffic latency). |

EXAMPLE

```
SC60010(config)# no green-ethernet eee optimize-for-power
SC60010(config)#
```

gvrp

Enable GVRP feature.

SYNTAX

```
gvrp
```

```
gvrp max-vlans <maxvlans>
```

```
gvrp time { [ join-time <jointime> ] [ leave-time <leavetime> ] [ leave-all-time <leavealltime> ] }*1
```

Parameter

| | |
|-----------------------|--|
| max-vlans | Number of simultaneously VLANs that GVRP can control |
| time | Config GARP protocol timer parameters. IEEE 802.1D-2004, clause 12.11. |
| join-time | Set GARP protocol parameter JoinTime. See IEEE 802.1D-2004, clause 12.11 |
| leave-all-time | Set GARP protocol parameter LeaveAllTime. See IEEE 802.1D-2004, clause 12.11 |

leave-time

Set GARP protocol parameter LeaveTime. See IEEE 802.1D-2004, clause 12.11

EXAMPLE

```
SC60010(config)#no gvrp max-vlans 1
SC60010(config)#no gvrp time join-time 10
SC60010(config)#no gvrp time leave-all-time 2000
SC60010(config)#no gvrp time leave-time 70
SC60010(config)#
```

hostname

Set system's network name.

SYNTAX

no hostname

EXAMPLE

```
SC60010(config)# no hostname
SC60010(config)#
```

interface**SYNTAX**

no interface vlan < vlan_list >

Parameter

vlan Vlan interface configurations

<vlan_list> Vlan list

EXAMPLE

```
SC60010(config)# no interface vlan 10
SC60010(config)#
```

Ip

Set system's network name.

SYNTAX

no ip arp inspection

no ip arp inspection entry interface Gigabitethernet <port_type_id> <vlan_id> <mac_ucast> <ipv4_ucast>

no ip arp inspection vlan <vlan_list> [logging]

no dhcp excluded-address [<ip_address> [<ip_address>]]

no dhcp pool <WORD>

no ip dhcp relay [information {option| policy }]

no ip dhcp server

no ip dhcp snooping

no ip dns proxy

no ip helper-address

no ip http secure-redirect

no ip http secure-server

no ip igmp host-proxy [leave-proxy]

no ip igmp snooping

no ip igmp snooping vlan [<vlan_list>]

no ip igmp ssm-range

no ip igmp unknown-flooding

no ip name-server

no ip route <ipv4_addr> <ipv4_netmask> <ipv4_addr>

no ip routing

**no ip source binding interface Gigabitethernet <port_type_id> <vlan_id>
<ipv4_ucast>{ <ipv4_netmask>|<mac_ucast>}**

no ip ssh

no ip verify source

Parameter

| | |
|-----------------------------|--|
| arp | Address Resolution Protocol |
| inspection | ARP inspection |
| entry | arp inspection entry |
| interface | arp inspection entry interface config |
| GigabitEthernet | 1 Gigabit Ethernet Port |
| <port_type_id> | Port ID in the format of switch-no/port-no, 1/1-26 for Gigabitetherne |
| <vlan_id> | Select a VLAN id to configure |
| <mac_ucast> | Select a MAC address to configure |
| <ipv4_ucast> | Select an IP Address to configure |
| vlan | arp inspection vlan setting |
| <vlan_list> | arp inspection vlan list |
| logging | ARP inspection vlan logging mode config |
| dhcp | Dynamic Host Configuration Protocol |
| excluded-address | Prevent DHCP from assigning certain address |
| <ip_address> | Low IP address and High IP address |
| <WORD> | Pool name in 32 characters |
| pool | Configure DHCP address pools |
| relay | DHCP relay agent configuration |
| server | enable DHCP server |
| snoping | DHCP snooping |
| information | DHCP information option(Option 82) |
| option | DHCP option |
| policy | Policy for handling the receiving DHCP packet already include the information option |
| snooping | DHCP snooping |

| | |
|-----------------------------|---|
| dns | Domain Name System |
| proxy | DNS proxy service |
| helper-address | None. |
| http | Hypertext Transfer Protocol |
| secure-redirect | Secure HTTP web redirection |
| secure-server | Secure HTTP web server |
| igmp | Internet Group Management Protocol |
| host-proxy | IGMP proxy configuration |
| leave-proxy | IGMP proxy for leave configuration |
| snooping | Snooping IGMP |
| vlan | IGMP VLAN |
| <vlan_list> | VLAN identifier(s): VID |
| ssm-range | IPv4 address range of Source Specific Multicast |
| unknown-flooding | Flooding unregistered IPv4 multicast traffic |
| name-server | Domain Name System |
| Route | none |
| <ipv4_addr> | Network |
| <ipv4_netmask> | Netmask |
| <ipv4_gateway> | Gateway |
| routing | Disable routing for IPv4 and IPv6 |
| source | source command |
| binding | ip source binding |
| interface | ip source binding entry interface config |
| Gigabitethernet | 1 Gigabitethernet port |
| <port_type_id> | Port ID in the format of switch-no/port-no, ex., 1/1-26 for Gigabitethernet |

| | |
|-----------------------------|-----------------------------------|
| <vlan_id> | Select a VLAN id to configure |
| <ipv4_ucast> | Select an IP Address to configure |
| <ipv4_netmask> | Select a subnet mask to configure |
| <mac_ucast> | Select a MAC address to configure |
| ssh | Secure Shell |
| verify | verify command |
| source | verify source |

EXAMPLE

```

SC60010(config)# no ip arp inspection vlan 3 logging
SC60010(config)# no ip dhcp relay information option
SC60010(config)# no ip dns proxy
SC60010(config)# no ip helper-address
SC60010(config)# no ip http secure-redirect
SC60010(config)# no ip igmp snooping
SC60010(config)# no ip name-server
SC60010(config)# no ip routing
SC60010(config)# no ip ssh
SC60010(config)# no ip verify source
SC60010(config)#

```

ipmc

IPv4/IPv6 multicast configuration

SYNTAX

no ipmc profile <Profilename : word16>

no ipmc range <Entryname : word16>

Parameter

profile IPMC profile configuration

<Profilename : word16> Profile name in 16 char's

range A range of IPv4/IPv6 multicast addresses for the profile

<Entryname : word16> Range entry name in 16 char's

EXAMPLE

```
SC60010(config)# no ipmc profile
```

ipv6

IPv6 configuration commands

SYNTAX

no ipv6 mld host-proxy [leave-proxy]

no ipv6 mld snooping

no ipv6 mld snooping [vlan <vlan_list>]

no ipv6 mld ssm-range

no ipv6 mld unknown-flooding

no ipv6 route <ipv6_subnet> { <ipv6_ucast> | interface vlan <vlan_id> <ipv6_linklocal> }

Parameter

| | |
|----------------------------|---|
| mld | Multicasat Listener Discovery |
| host-proxy | MLD proxy configuration |
| leave-proxy | MLD proxy for leave configuration |
| snooping | Snooping MLD |
| vlan | MLD VLAN |
| <vlan_list> | VLAN identifier(s): VID |
| ssm-range | IPv6 address range of Source Specific Multicast |
| unknown-flooding | Flooding unregistered IPv6 multicast traffic |
| route | Configure static routes |
| <ipv6_subnet> | IPv6 prefix x:x::y/z |

| | |
|-------------------------------|--|
| <ipv6_ucast> | IPv6 unicast address (except link-local address) of next-hop |
| interface | Select an interface to configure |
| vlan | VLAN Interface |
| <vlan_id> | VLAN identifier(s): VID |
| <ipv6_linklocal> | IPv6 link-local address of next-hop |

EXAMPLE

```
SC60010(config)# no ipv6 mld snooping
SC60010(config)#
```

lACP

LACP settings

SYNTAX

no lACP system-priority <1-65535>

Parameter

| | |
|------------------------|---|
| system-priority | System priority |
| <1-65535> | Priority value, lower means higher priority |

EXAMPLE

```
SC60010(config)# no lACP system-priority 10000
SC60010(config)#
```

lldp

LLDP configurations..

SYNTAX

- no lldp holdtime**
- no lldp med datum**
- no lldp med fast**

no lldp med location-tlv altitude

no lldp med location-tlv civic-addr { country | state | county | city | district | block | street | leading-street-direction | trailing-street-suffix | street-suffix | house-no | house-no-suffix | landmark | additional-info | name | zip-code | building | apartment | floor | room-number | place-type | postal-community-name | p-o-box | additional-code }

no lldp med location-tlv elin-addr

no lldp med location-tlv latitude

no lldp med location-tlv longitude

no lldp med media-vlan-policy <0~31>

no lldp reinit

no lldp timer

no lldp transmission-delay

Parameter

| | |
|---------------------------|--|
| holdtime | Sets LLDP hold time (The neighbor switch will discarded the LLDP information after "hold time" multiplied with "timer" seconds). |
| med | Media Endpoint Discovery. |
| reinit | Sets LLDP reinitialization delay. |
| timer | Sets LLDP TX interval (The time between each LLDP frame transmitted in seconds). |
| tlv-select | Which optional TLVs to transmit. |
| transmission-delay | Sets LLDP transmission-delay. LLDP transmission delay (the amount of time that the transmission of LLDP frames will delayed after LLDP configuration has changed) in seconds.) |
| datum | Set datum to default value. |
| fast | Set fast repeat count to default value. |

| | |
|---------------------------------|--|
| location-tlv | LLDP-MED Location Type Length Value parameter. |
| media-vlan-policy | Use the media-vlan-policy to create a policy, which can be assigned to an interface. |
| altitude | Setting altitude to default. |
| civic-addr | Civic address information and postal information |
| elin-addr | Set elin address to default value. |
| latitude | Setting Latitude parameter to default. |
| longitude | Setting longitude to default. |
| additional-code | Additional code - Example: 1320300003. |
| additional-info | Additional location info - Example: South Wing. |
| apartment | Unit (Apartment, suite) - Example: Apt 42. |
| block | Neighbourhood, block. |
| building | Building (structure) - Example: Low Library. |
| city | City, township, shi (Japan) - Example: Copenhagen. |
| country | The two-letter ISO 3166 country code in capital ASCII letters - Example: DK, DE or US. |
| county | County, parish, gun (Japan), district. |
| district | City division, borough, city district, ward, chou (Japan). |
| floor | Floor - Example: 4. |
| house-no | House number - Example: 21. |
| house-no-suffix | House number suffix - Example: A, 1/2. |
| landmark | Landmark or vanity address - Example: Columbia University. |
| leading-street-direction | Leading street direction - Example: N. |
| name | Name (residence and office occupant) - Example: Flemming Jahn. |
| p-o-box | Post office box (P.O. BOX) - Example: 12345. |
| place-type | Place type - Example: Office. |

| | |
|-------------------------------|--|
| postal-community-name | Postal community name - Example: Leonia. |
| room-number | Room number - Example: 450F. |
| state | National subdivisions (state, canton, region, province, prefecture). |
| street | Street - Example: Poppelvej. |
| street-suffix | Street suffix - Example: Ave, Platz. |
| trailing-street-suffix | Trailing street suffix - Example: SW. |
| zip-code | Postal/zip code - Example: 2791. |
| <0~31> | Policy to delete. |

EXAMPLE

```

SC60010(config)# no lldp holdtime
SC60010(config)# no lldp med location-tlv civic-addr floor
SC60010(config)# no lldp reinit
SC60010(config)# no lldp timer
SC60010(config)# no lldp transmission-delay
SC60010(config)#

```

logging

Syslog.

SYNTAX

no logging host

no logging on

Parameter

host host

on Enable syslog server

EXAMPLE

```
SC60010(config)# no logging host
SC60010(config)# no logging on
SC60010(config)#
```

loop-protect

Loop protection configuration

SYNTAX

no loop-protect

no loop-protect shutdown-time

no loop-protect transmit-time

Parameter

shutdown-time Loop protection shutdown time interval

transmit-time Loop protection transmit time interval

EXAMPLE

```
SC60010(config)# no loop-protect shutdown-time
SC60010(config)# no loop-protect transmit-time
SC60010(config)#
```

mac

MAC table entries/configuration

SYNTAX

no mac address-table aging-time [<0,10-1000000>]

no mac address-table static <mac_addr> vlan <vlan_id> interface {*[Gigabitethernet [<port_type_list>]}

Parameter

address-table Mac table entries configuration/table

| | |
|-------------------------------|---|
| aging-time | Mac address aging time |
| <0,10-1000000> | Aging time in seconds, 0 disables aging |
| static | Static MAC address |
| <mac_addr> | 48 bit MAC address: xx:xx:xx:xx:xx:xx |
| vlan | VLAN keyword |
| <vlan_id> | VLAN IDs 1-4095 |
| interface | Select an interface to configure |
| Gigabitethernet | 1 Gigabit Ethernet port |
| <port_type_list> | Port list in 1/1-26 for Gigaethernet |

EXAMPLE

```
SC60010(config)# no mac address-table aging-time 10000
SC60010(config)#
```

monitor

Set monitor configuration.

SYNTAX

no monitor destination

no monitor source { interface Gigabitethernet <port_type_list> | cpu}

Parameter

Destination

source The source port(s). That is the ports to be mirrored to the destination port.

cpu Mirror CPU traffic.

interface Mirror Interface traffic.

Gigabitethernet 1 Gigabit Ethernet Port

<port_type_list> Port list in 1/1-26 for Gigabitethernet

EXAMPLE

```
SC60010(config)# no monitor destination
SC60010(config)# no monitor source cpu
SC60010(config)#
```

mvr

Multicast VLAN Registration configuration.

SYNTAX

no mvr

no mvr name <word16> channel

no mvr name <word16> frame priority

no mvr name <word16> frame tagged

no mvr name <word16> igmp-address

no mvr name <word16> last-member-query-interval

no mvr name <word16> mode

no mvr vlan <vlan_list>

no mvr vlan <vlan_list> channel

no mvr vlan <vlan_list> frame priority

no mvr vlan <vlan_list> frame tagged

no mvr vlan <vlan_list> igmp-address

no mvr vlan <vlan_list> last-member-query-interval

no mvr vlan <vlan_list> mode [{channel | frame | igmp-address | last-member-query-interval}]

Parameter

name MVR multicast name

<word16> MVR multicast VLAN name

| | |
|-----------------------------------|---|
| channel | MVR channel configuration |
| frame | MVR control frame in TX |
| priority | Interface CoS priority |
| tagged | Tagged IGMP/MLD frames will be sent |
| igmp-address | MVR address configuration used in IGMP |
| last-member-query-interval | Last Member Query Interval in tenths of seconds |
| mode | MVR mode of operation |
| vlan | MVR multicast vlan |
| <vlan_list> | MVR multicast VLAN list |

EXAMPLE

```
SC60010(config)# no mvr vlan 12 mode
SC60010(config)#
```

Non-stop-poe

Disable Non-Stop PoE Status

SYNTAX

no non-stop-poe

no non-stop-poe | { begin | exclude | include } LINE

Parameter

| | |
|----------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| LINE | String to match output lines |

EXAMPLE

```
SC60010(config)# no non-stop-poe
Non-Stop-PoE Status : Disable
SC60010(config)#
```

ntp

Configure NTP.

SYNTAX

no ntp

no ntp server <1-5>

Parameter

server Configure NTP server

<1-5> index number

EXAMPLE

```
SC60010(config)# no ntp server 2
SC60010(config)#
```

poe

Power Over Ethernet.

SYNTAX

no poe [(management mode) | ping-check | { [profile] (id <1-16>) } | reboot-chip]

Parameter

management POE_MANAGEMENT_MODE_HELP

ping-check Enable POE Ping Check.

profile erase poe scheduling profile

reboot-chip erase all poe reboot scheduling

mode mode

id erase poe scheduling profile id

<1-16> profile id from 1 to 16

EXAMPLE

```
SC60010(config)# no poe profile id 1
SC60010(config)#
```

port-security

Enable/disable port security globally.

SYNTAX

no port-security

no port-security aging

no port-security aging time

Parameter

aging Enable/disable port security aging.

time Time in seconds between check for activity on learned MAC addresses.

EXAMPLE

```
SC60010(config)# no port-security aging time
SC60010(config)#
```

privilege

Command privilege parameters

SYNTAX

no privilege <word> level <0-15> <line128>

Parameter

| | |
|------------------------|--|
| <word> | Valid words are 'config-vlan' 'configure' 'dhcp-pool' 'exec' 'if-vlan' 'interface' 'ipmc-profile' 'line' 'snmps-host' 'stp-aggr' |
| level | Set privilege level of command |
| <0-15> | Privilege level |
| <line128> | Initial valid words and literals of the command to modify, in 128 characters |

EXAMPLE

```
SC60010(config)# no privilege config-vlan
SC60010(config)#
```

qos

Quality of Service

SYNTAX

no qos map cos-dscp <0-7> dpl 0-1

no qos map [dscp-classify | dscp-cos | dscp-egress-translation | dscp-ingress-translation] [<0-63> | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | be | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va]

no qos qce 1-256

no qos storm [broadcast | multicast | unicast]

Parameter

| | |
|--------------------------------|---------------------------------|
| map | Global QoS Map/Table |
| qce | QoS Control Entry |
| storm | Storm policer |
| cos-dscp | Map for COS to DSCP |
| dscp-classify | Map for DSCP classify enable |
| dscp-cos | Map for DSCP to COS |
| dscp-egress-translation | Map for DSCP egress translation |

| | |
|---------------------------------|--|
| dscp-ingress-translation | Map for DSCP ingress translation |
| <0~7> | Specific class of service or range |
| dpl | Specify drop precedence level |
| 0~1 | Specific drop precedence level or range |
| <0~63> | Specific DSCP or range |
| af11 | Assured Forwarding PHB AF11(DSCP 10) |
| af12 | Assured Forwarding PHB AF12(DSCP 12) |
| af13 | Assured Forwarding PHB AF13(DSCP 14) |
| af21 | Assured Forwarding PHB AF21(DSCP 18) |
| af22 | Assured Forwarding PHB AF22(DSCP 20) |
| af23 | Assured Forwarding PHB AF23(DSCP 22) |
| af31 | Assured Forwarding PHB AF31(DSCP 26) |
| af32 | Assured Forwarding PHB AF32(DSCP 28) |
| af33 | Assured Forwarding PHB AF33(DSCP 30) |
| af41 | Assured Forwarding PHB AF41(DSCP 34) |
| af42 | Assured Forwarding PHB AF42(DSCP 36) |
| af43 | Assured Forwarding PHB AF43(DSCP 38) |
| be | Default PHB(DSCP 0) for best effort traffic |
| cs1 | Class Selector PHB CS1 precedence 1(DSCP 8) |
| cs2 | Class Selector PHB CS2 precedence 2(DSCP 16) |
| cs3 | Class Selector PHB CS3 precedence 3(DSCP 24) |
| cs4 | Class Selector PHB CS4 precedence 4(DSCP 32) |
| cs5 | Class Selector PHB CS5 precedence 5(DSCP 40) |
| cs6 | Class Selector PHB CS6 precedence 6(DSCP 48) |
| cs7 | Class Selector PHB CS7 precedence 7(DSCP 56) |
| ef | Expedited Forwarding PHB(DSCP 46) |

| | |
|------------------|--------------------------|
| va | Voice Admit PHB(DSCP 44) |
| 1~256 | QCE ID |
| broadcast | Police broadcast frames |
| multicast | Police multicast frames |
| unicast | Police unicast frames |

EXAMPLE

```
SC60010(config)# no qos storm unicast
SC60010(config)#
```

radius-server

Configure RADIUS.

SYNTAX

no radius-server attribute {32 | 4 | 95}

no radius-server deadtime

no radius-server host { <word1-255> | <ipv4_ucast> | <ipv6_ucast> } [auth-port <0-65535>] [acct-port <0-65535>]

no radius-server key

no radius-server retransmit

no radius-server timeout

Parameter

Attribute

deadtime Time to stop using a RADIUS server that doesn't respond

host Specify a RADIUS server

key Set RADIUS encryption key

retransmit Specify the number of retries to active server

timeout Time to wait for a RADIUS server to reply

EXAMPLE

```
SC60010(config)# no radius-server attribute 4
SC60010(config)# no radius-server deadtime
SC60010(config)# no radius-server key
SC60010(config)# no radius-server retransmit
SC60010(config)# no radius-server timeout
SC60010(config)#
```

rmon

Remote Monitoring.

SYNTAX

no rmon alarm <alarm : 1-65535>

no rmon event<event : 1-65535>

Parameter

alarm Configure an RMON alarm

event Configure an RMON event

<alarm : 1-65535> Alarm entry ID

<event: 1-65535> Event entry ID

EXAMPLE

```
SC60010(config)# no rmon alarm 1000
SC60010(config)#
```

sflow

Statistics flow.

SYNTAX

no sflow agent-ip

no sflow collector-address

no sflow collector-port

no sflow max-datagram-size

no sflow timeout

Parameter

| | |
|--------------------------|---|
| agent-ip | Sets the agent IP address used as agent-address in UDP datagrams to 127.0.0.1. |
| collector-address | Collector address |
| collector-port | Collector UDP port |
| max-datagram-size | Maximum datagram size. |
| timeout | Receiver timeout measured in seconds. The switch decrements the timeout once per second, and as long as it is non-zero, the receiver receives samples. Once the timeout reaches 0, the receiver and all its configuration is reset to defaults. |

EXAMPLE

```
SC60010(config)# no sflow agent-ip
SC60010(config)# no sflow collector-address
SC60010(config)# no sflow collector-port
SC60010(config)# no sflow max-datagram-size
SC60010(config)# no sflow timeout
SC60010(config)#
```

snmp-server

Enable SNMP server.

SYNTAX

no snmp-server

no snmp-server access <Groupname : word32> model { v1 | v2c | v3 | any } level { auth | noauth | priv }

no snmp-server community v2c
no snmp-server community v3 <Community : word127>
no snmp-server contact
no snmp-server engined-id local
no snmp-server host <Conf : word32>
no snmp-server location
no snmp-server security-to-group model { v1 | v2c | v3 } name <Securityname : word32>
no snmp-server trap
no snmp-server user <Username : word32> engine-id <Engineid : word10-32>
no snmp-server version
no snmp-server view <Viewname : word32> <Oidsubtree : word255>

Parameter

| | |
|-----------------------------------|--|
| access | access configuration |
| <Groupname : word32> | group name |
| model | security model |
| v1 | v1 security model |
| v2c | v2c security model |
| v3 | v3 security model |
| any | any security model |
| level | security level |
| auth | authNoPriv Security Level |
| noauth | noAuthNoPriv Security Level |
| priv | authPriv Security Level |
| community | Set the SNMP community |
| contact | Clear the SNMP server's contact string |
| engined-id | Set SNMP engine ID |

| | |
|---|---|
| host | Set SNMP host's configurations |
| location | Clear the SNMP server's location string |
| security-to-group | security-to-group configuration |
| trap | Set trap's configurations |
| user | user who can access SNMP server |
| version | Set the SNMP server's version |
| view | MIB view configuration |
| <Community : word127> | |
| local | Set SNMP local engine ID |
| <ConfName : word32> Name of the host configuration | |
| model | security model |
| v1 | v1 security model |
| v2c | v2c security model |
| v3 | v3 security model |
| name | security user |
| <SecurityName : word32> security user name | |
| <Username : word32> name of user | |
| engine-id | engine ID |
| <Engineid : word10-32> engine ID octet string | |
| <Viewname : word32> MIB view name | |
| <Oidsubtree : word255> MIB view OID | |

EXAMPLE

```
SC60010(config)# no snmp-server access 333 model any level auth
SC60010(config)# no snmp-server community v2c
SC60010(config)# no snmp-server engined-id local
SC60010(config)# no snmp-server host 333
SC60010(config)# no snmp-server location
SC60010(config)# no snmp-server security-to-group model v2c name
132
SC60010(config)# no snmp-server trap
SC60010(config)# no snmp-server version
SC60010(config)#
```

spanning-tree

STP Bridge.

SYNTAX

no spanning-tree edge bpdu-filter

no spanning-tree edge bpdu-guard

no spanning-tree mode

no spanning-tree mst <instance> priority

no spanning-tree mst <instance> vlan

no spanning-tree mst forward-time

no spanning-tree mst max-age

no spanning-tree mst max-hops

no spanning-tree mst name

no spanning-tree recovery interval

no spanning-tree transmit hold-count

Parameter

edge Edge ports

| | |
|---------------------------------|--------------------------------------|
| mode | STP protocol mode |
| mst | STP bridge instance |
| recovery | The error recovery timeout |
| transmit | BPDUs to transmit |
| bpdu-filter | Enable BPDU filter (stop BPDU tx/rx) |
| bpdu-guard | Enable BPDU guard |
| <Instance : 0-7> | instance 0-7 (CIST=0, MST2=1...) |
| priority | Priority of the instance |
| forward-time | Delay between port states |
| max-age | Max bridge age before timeout |
| max-hops | MSTP bridge max hop count |
| name | Name keyword |
| vlan | VLAN keyword |
| interval | The interval |
| hold-count | Max number of transmit BPDUs per sec |
| <Holdcount : 1-10> | 1-10 per sec, 6 is default |

EXAMPLE

```

SC60010(config)# no spanning-tree edge bpdu-filter
SC60010(config)# no spanning-tree mode
SC60010(config)# no spanning-tree mst max-age
SC60010(config)# no spanning-tree recovery interval
SC60010(config)# no spanning-tree transmit hold-count
SC60010(config)#

```

switch2go-management

SwitchAlert Management configuration

SYNTAX

```
no switch2go-management port-name interface [ * | GigabitEthernet ] <port_type_list>
```

Parameter

| | |
|-------------------------------|----------------------------------|
| port-name | Interface specific description |
| interface | Select an interface to configure |
| * | All switches or All ports |
| GigabitEthernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list for all port types |
| <port_type_list> | Port list in 1/1-26 |

EXAMPLE

```
SC60010(config)# no switch2go-management port-name interface *
SC60010(config)#
```

system

Set the system description

SYNTAX

```
no system [ contact | description | location | name | reboot ]
```

Parameter

| | |
|--------------------|--|
| contact | Clear the SNMP server's contact string |
| description | Clear the system description string |
| location | Clear the SNMP server's location string |
| name | Clear the SNMP server's system model name string |
| reboot | erase all Switch Reboot scheduling |

EXAMPLE

```
SC60010(config)# no switchport vlan mapping 1 12
SC60010(config)#
```

tacacs-server

Configure TACACS+.

SYNTAX

no tacacs-server deadtime

no tacacs-server host <host_name> [port <port>]

no tacacs-server key

no tacacs-server timeout

Parameter

| | |
|-------------------------------------|---|
| deadtime | Time to stop using a TACACS+ server that doesn't respond |
| host | Specify a TACACS+ server |
| <Hostname : word1-255> | Host name or IP address |
| key | Set TACACS+ encryption key |
| timeout | Time to wait for a TACACS+ server to reply |
| key | Server specific key (overrides default) |
| port | TCP port for TACACS+ server |
| timeout | Time to wait for this TACACS+ server to reply (overrides default) |
| <Port : 0-65535> | TCP port number |

EXAMPLE

```
SC60010(config)# no tacacs-server deadtime
SC60010(config)# no tacacs-server host 192.168.1.1 port 10000
SC60010(config)# no tacacs-server key
SC60010(config)# no tacacs-server timeout
SC60010(config)#
```

upnp

Set UPnP's configurations.

SYNTAX

no upnp

no upnp advertising-duration

no upnp ttl

Parameter

advertising-duration Set advertising duration

ttl Set TTL value

EXAMPLE

```
SC60010(config)# no upnp advertising-duration
SC60010(config)# no upnp ttl
SC60010(config)#
```

username

Establish User Name Authentication.

SYNTAX

no username <Username : word31>

Parameter

<Username : word31> User name allows letters, numbers and underscores

EXAMPLE

```
SC60010(config)# no username admin
SC60010(config)#
```

vlan

Vlan commands.

SYNTAX

```
no vlan protocol { { eth2 { <0x600-0xffff> | arp | ip | ipx | at } } | { snap { <0x0-0xfffff> | rfc_1042 | snap_8021h } } } <0x0-0xffff> } | { llc <0x0-0xff> <0x0-0xff> } } group <word16>
```

```
no vlan { [ ethertype s-custom-port ] | <vlan_list> }
```

Parameter

| | |
|-----------------------------|--------------------------------------|
| protocol | Protocol-based VLAN commands |
| eth2 | Ethernet-based VLAN commands |
| <0x600-0xffff> | Ether Type(Range: 0x600 - 0xFFFF) |
| arp | Ether Type is ARP |
| ip | Ether Type is IP |
| ipx | Ether Type is IPX |
| at | Ether Type is AppleTalk |
| snap | SNAP-based VLAN group |
| <0x0-0xfffff> | SNAP OUI (Range 0x000000 - 0FFFFFFF) |
| rfc_1042 | SNAP OUI is rfc_1042 |
| snap_8021h | SNAP OUI is 8021h |
| <0x0-0xffff> | PID (Range: 0x0 - 0xFFFF) |
| llc | LLC-based VLAN group |
| <0x0-0xff> | DSAP (Range: 0x00 - 0xFF) |
| <0x0-0xff> | SSAP (Range: 0x00 - 0xFF) |

| | |
|--------------------------|---------------------------------------|
| group | Protocol-based VLAN group commands |
| <word16> | Group Name (Range: 1 - 16 characters) |
| <vlan_list> | Vlan list |
| ethertype | |
| s-custom-port | |

EXAMPLE

```
SC60010(config)# no vlan 3
SC60010(config)# no vlan ethertype s-custom-port
SC60010(config)#
```

voice

Voice appliance attributes.

SYNTAX

no voice vlan

no voice vlan aging-time

no voice vlan class

no voice vlan oui <oui>

no voice vlan vid

Parameter

| | |
|--------------------|--------------------------------|
| vlan | Vlan for voice traffic |
| aging-time | Set secure learning aging time |
| class | Set traffic class |
| oui | OUI configuration |
| <oui> | Traffic class value |
| vid | Set VLAN ID |

EXAMPLE

```
SC60010(config)# no voice vlan vid
SC60010(config)# no voice vlan class
SC60010(config)# no voice vlan aging-time
SC60010(config)#
```

web

Web.

SYNTAX

no web privilege group [<group_name>] level

Parameter

| | |
|----------------------|--|
| privilege | Web privilege |
| group | Web privilege group |
| <CWORD> | Valid words are 'Aggregation' 'Debug' 'Dhcp_Client' 'Diagnostics' 'EEE' 'GARP' 'GVRP' 'Green_Ethernet' 'IP2' 'IPMC_Snooping' 'LACP' 'LLDP' 'Loop_Protect' 'MAC_Table' 'MEP' 'MVR' 'Maintenance' 'Mirroring' 'NTP' 'POE' 'Ports' 'Private_VLANS' 'QoS' 'RPC' 'Security' 'Spanning_Tree' 'System' 'Timer' 'UPnP' 'VCL' 'VLANS' 'Voice_VLAN' 'XXRP' 'sFlow' |
| level | Web privilege group level |

EXAMPLE

```
SC60010(config)# no web privilege group LACP level
SC60010(config)#
```

ntp

Configure NTP.

SYNTAX

non-stop-poe

non-stop-poe | { begin | exclude | include } LINE

Parameter

| | |
|----------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| LINE | String to match output lines |

EXAMPLE

```
SC60010(config)# non-stop-poe
Non-Stop-PoE Status : Enable
SC60010(config)#
```

ntp

Configure NTP.

SYNTAX

ntp

ntp server <1-5> ip-address <hostname>

ntp server <1-5> ip-address <ipv4_ucast>

ntp server <1-5> ip-address <ipv6_ucast>

Parameter

| | |
|--------------------|----------------------|
| server | Configure NTP server |
| <1-5> | index number |

| | |
|---------------------------|--------------|
| ip-address | ip address |
| <ipv4_ucast> | ipv4 address |
| <ipv6_ucast> | ipv6 address |
| <hostname> | domain name |

EXAMPLE

```
SC60010(config)# ntp server 3 ip-address 192.168.1.1
SC60010(config)#
```

poe

Configure poe.

SYNTAX

poe management mode { class-consumption | class-reserved-power | allocation-consumption | allocation-reserved-power | lldp-consumption | lldp-reserved-power }

poe ping-check { enable | disable }

poe select-all <port_list>

Parameter

| | |
|----------------------------------|---|
| management | Use management mode to configure PoE power management method. |
| select-all | Configure PoE Schedule mode. |
| Ping-check | Enable/Disable POE Ping Check. |
| Mode | PoE Power Management Mode |
| allocation-consumption | Max. port power determined by allocated, and power is managed according to power consumption. |
| allocation-reserved-power | Max. port power determined by allocated, and power is managed according to reserved power. |
| class-consumption | Max. port power determined by class, and power is managed according to power consumption. |
| class-reserved-power | Max. port power determined by class, and power is managed according to reserved power. |
| lldp-consumption | Max. port power determined by LLDP Media protocol, and power is managed according to power consumption. |
| lldp-reserved-power | Max. port power determined by LLDP Media protocol, and power is managed according to reserved power. |

EXAMPLE

```

SC60010(config)# poe management mode allocation-consumption
SC60010(config)# poe management mode allocation-reserved-power
SC60010(config)# poe management mode class-consumption
SC60010(config)# poe management mode class-reserved-power
SC60010(config)# poe management mode lldp-consumption
SC60010(config)# poe management mode lldp-reserved-power
SC60010(config)# Poe ping-check enable
SC60010(config)# Poe select-all 3
SC60010(config)#

```

port-security

Enable/disable port security globally.

SYNTAX

port-security

port-security aging

port-security aging time <v_10_to_10000000>

Parameter

aging Time in seconds between check for activity on learned MAC addresses.

time Time in seconds between check for activity on learned MAC addresses.

<10-10000000> seconds

EXAMPLE

```

SC60010(config)# port-security agin time 1000
SC60010(config)#

```

privilege

Command privilege parameters.

SYNTAX

privilege { exec | configure | config-vlan | line | interface | if-vlan | ipmc-profile | snmps-host | stp-aggr | dhcp-

pool | rfc2544-profile } level <privilege> <cmd>

Parameter

| | |
|------------------------|--|
| config-vlan | VLAN Configuration Mode |
| configure | Global configuration mode |
| dhcp-pool | DHCP Pool Configuration Mode |
| exec | Exec mode |
| if-vlan | VLAN Interface Mode |
| interface | Port List Interface Mode |
| ipmc-profile | IPMC Profile Mode |
| line | Line configuration mode |
| rfc2544-profile | RFC2544 Profile Mode |
| snmps-host | SNMP Server Host Mode |
| stp-aggr | STP Aggregation Mode |
| level | Set privilege level of command |
| <LINE> | Initial valid words and literals of the command to modify, in 128 char's |

EXAMPLE

```
SC60010(config)# privilege config-vlan level 10 LINE
SC60010(config)# privilege configure level 10 LINE
SC60010(config)# privilege dhcp-pool level 10 LINE
SC60010(config)#
```

qos

Table : configure – qos Commands

| Command | Function |
|---------|----------------------|
| map | Global QoS Map/Table |
| qce | QoS Control Entry |
| storm | Storm policer |

map

Global QoS Map/Table.

SYNTAX

```
qos map cos-dscp <0~7> dpl <dpl : 0~1> dscp { <DscpNum : 0-63> | { be | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } }
```

```
qos map dscp-classify { <dscpNum : 0~63> | { be | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } }
```

```
qos map dscp-cos { <dscpNum : 0~63> | { be | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } } cos <Cos : 0-7> dpl <dpl>
```

```
qos map dscp-egress-translation { < DscpNum : 0~63> | { be | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } } <Dpl : 0~1> to { <Dscpnum : 0-63> | { be | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } }
```

```
qos map dscp-ingress-translation { < DscpNum : 0~63> | { be | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } } to { < DscpNum : 0-63> | { be | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } }
```

Parameter

| | |
|---------------------------------|---|
| cos-dscp | Map for cos to dscp |
| dscp-classify | Map for dscp classify enable |
| dscp-cos | Map for dscp to cos |
| dscp-egress-translation | Map for dscp egress translation |
| dscp-ingress-translation | Map for dscp ingress translation |
| dpl | Specify drop precedence level |
| <Dpl : 0~1> | Specific drop precedence level or range |
| dscp | Specify DSCP |
| <DscpNum : 0-63> | Specific DSCP |
| cos | Specify class of QoS |

| | |
|--------------------------|--|
| <Cos : 0-7> | Specific class of QoS |
| af11 | Assured Forwarding PHB AF11(DSCP 10) |
| af12 | Assured Forwarding PHB AF12(DSCP 12) |
| af13 | Assured Forwarding PHB AF13(DSCP 14) |
| af21 | Assured Forwarding PHB AF21(DSCP 18) |
| af22 | Assured Forwarding PHB AF22(DSCP 20) |
| af23 | Assured Forwarding PHB AF23(DSCP 22) |
| af31 | Assured Forwarding PHB AF31(DSCP 26) |
| af32 | Assured Forwarding PHB AF32(DSCP 28) |
| af33 | Assured Forwarding PHB AF33(DSCP 30) |
| af41 | Assured Forwarding PHB AF41(DSCP 34) |
| af42 | Assured Forwarding PHB AF42(DSCP 36) |
| af43 | Assured Forwarding PHB AF43(DSCP 38) |
| be | Default PHB(DSCP 0) for best effort traffic |
| cs1 | Class Selector PHB CS1 precedence 1(DSCP 8) |
| cs2 | Class Selector PHB CS2 precedence 2(DSCP 16) |
| cs3 | Class Selector PHB CS3 precedence 3(DSCP 24) |
| cs4 | Class Selector PHB CS4 precedence 4(DSCP 32) |
| cs5 | Class Selector PHB CS5 precedence 5(DSCP 40) |
| cs6 | Class Selector PHB CS6 precedence 6(DSCP 48) |
| cs7 | Class Selector PHB CS7 precedence 7(DSCP 56) |
| ef | Expedited Forwarding PHB(DSCP 46) |
| va | Voice Admit PHB(DSCP 44) |

EXAMPLE

```
SC60010(config)# qos map cos-dscp 5 dpl 1 dscp 20
SC60010(config)#
```

qce

QoS Control Entry.

SYNTAX

qos qce refresh

```
qos qce { [ update ] } <ld : 1-256> [ { next <ld : 1-256> } | last ] [ ingress interface *|GigabitEthernet
<PORT_LIST> ] [ tag { tagged | untagged | any } ] [ vid { <vlan_list> | any } ] [ pcp { <pcp> | any } ] [ dei { <Dpl :
0-1> | any } ] [ smac { <mac_addr> | <oui> | any } ] [ dmac-type { unicast | multicast | broadcast | any } ]
[ frametype { any | { etype [ { <0x600-0x7ff,0x801-0x86dc,0x86de-0xffff> | any } ] } | llc [ dsap { <0-0xff> | any } ]
[ ssap { <0-0xff> | any } ] [ control { <0-0xff> | any } ] } | { snap [ { <0-0xffff> | any } ] } | { ipv4 [ proto { <0-255> |
tcp | udp | any } ] [ sip { <ipv4_subnet> | any } ] [ dscp { <0~63> | { be | af11 | af12 | af13 | af21 | af22 | af23 |
af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } | any } ] [ frag { yes | no |
any } ] [ sport { <0~65535> | any } ] [ dport { <0~65535> | any } ] } | { ipv6 [ proto { <0-255> | tcp | udp | any } ]
[ sip { <ipv4_subnet> | any } ] [ dscp { <0~63> | { be | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 |
af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef | va } | any } ] [ sport { <0~65535> | any } ] [ dport
{ <0~65535> | any } ] } } ] [ action [ { cos { <0-7> | default } ] [ dpl { <0-1> | default } ] [ dscp { <0-63> | { be | af11 |
af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | ef |
va } | default } ] } ]
```

Parameter

| | |
|---------------------------|---------------------------------------|
| <ld : 1-256> | QCE ID |
| refresh | Refresh QCE tables in hardware |
| update | Update an existing QCE |
| action | Specify action |
| dei | Specify DEI (Drop Eligible Indicator) |
| dmac-type | Specify DMAC type |
| frametype | Specify frame type |
| ingress | Ingress interfaces |

| | |
|----------------------------|---|
| last | Place QCE at the end |
| next | Place QCE before the next QCE ID |
| pcp | Specify PCP (Priority Code Point) |
| smac | Specify SMAC. If 'qos qce dmac-dip' is set, this parameter specifies the DMAC |
| tag | Specify tag options |
| vid | Specify VLAN ID |
| cos | Specify class of service |
| dpl | Specify drop precedence level |
| dscp | Specify DSCP |
| cos | Specify class of service |
| <Cos : 0-7> | Specific class of service |
| default | Keep default class of service |
| <Dpl : 0-1> | Specific drop precedence level |
| default | Keep default drop precedence level |
| <Dscp : 0-63> | Specific DSCP |
| af11 | Assured Forwarding PHB AF11(DSCP 10) |
| af12 | Assured Forwarding PHB AF12(DSCP 12) |
| af13 | Assured Forwarding PHB AF13(DSCP 14) |
| af21 | Assured Forwarding PHB AF21(DSCP 18) |
| af22 | Assured Forwarding PHB AF22(DSCP 20) |
| af23 | Assured Forwarding PHB AF23(DSCP 22) |
| af31 | Assured Forwarding PHB AF31(DSCP 26) |
| af32 | Assured Forwarding PHB AF32(DSCP 28) |
| af33 | Assured Forwarding PHB AF33(DSCP 30) |
| af41 | Assured Forwarding PHB AF41(DSCP 34) |
| af42 | Assured Forwarding PHB AF42(DSCP 36) |

| | |
|---|--|
| af43 | Assured Forwarding PHB AF43(DSCP 38) |
| be | Default PHB(DSCP 0) for best effort traffic |
| cs1 | Class Selector PHB CS1 precedence 1(DSCP 8) |
| cs2 | Class Selector PHB CS2 precedence 2(DSCP 16) |
| cs3 | Class Selector PHB CS3 precedence 3(DSCP 24) |
| cs4 | Class Selector PHB CS4 precedence 4(DSCP 32) |
| cs5 | Class Selector PHB CS5 precedence 5(DSCP 40) |
| cs6 | Class Selector PHB CS6 precedence 6(DSCP 48) |
| cs7 | Class Selector PHB CS7 precedence 7(DSCP 56) |
| default | Keep default DSCP |
| ef | Expedited Forwarding PHB(DSCP 46) |
| va | Voice Admit PHB(DSCP 44) |
| any | Any |
| broadcast | Broadcast |
| multicast | Multicast |
| unicast | Unicast |
| etype | Ethernet frames |
| ipv4 | IPv4 frames |
| ipv6 | IPv6 frames |
| llc | LLC frames |
| snap | SNAP frames |
| <Etype : 0x600-0x7ff,0x801-0x86dc,0x86de-0xffff> | Specific EtherType |
| interface | Interfaces |
| <Next : 1-256> | The next QCE ID |
| <Pcp : pcp> | Specific PCP (0-7) or range (0-1, 2-3, 4-5, 6-7, 0-3 or 4-7) |
| <Smac : mac_addr> | Specific SMAC (XX-XX-XX-XX-XX-XX) |

| | |
|--------------------------------|---|
| tagged | Tagged frames only |
| untagged | Untagges frames only |
| <Vid : vlan_list> | Specific VLAN ID or range |
| interface | Interfaces |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <PORT_LIST> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010(config)# qos qce 100 vid any
SC60010(config)#
```

storm

Storm policer.

SYNTAX

```
qos storm { unicast | multicast | broadcast } <Rate : 1,2,4,8,16,32,64,128,256,512,1024> [ kfps ]
```

Parameter

| | |
|---|----------------------------|
| broadcast | Police broadcast frames |
| multicast | Police multicast frames |
| unicast | Police unicast frames |
| <Rate : 1,2,4,8,16,32,64,128,256,512,1024> | Policer rate (default fps) |
| kfps | Rate is kfps |

EXAMPLE

```
SC60010(config)# qos storm broadcast 256 kfps
SC60010(config)#
```

radius-server

Configure RADIUS.

SYNTAX

radius-server attribute 32 <line1-255>

radius-server attribute 4 <ipv4_ucast>

radius-server attribute 95 <ipv6_ucast>

radius-server deadtime <1-1440>

radius-server host { <word1-255> | <ipv4_ucast> | <ipv6_ucast> } [auth-port <0-65535>] [acct-port <0-65535>] [timeout <1-1000>] [retransmit <1-1000>] [key <line1-63>]

radius-server key <line1-63>

radius-server retransmit <1-1000>

radius-server timeout <1-1000>

Parameter

Attribute

deadtime Time to stop using a RADIUS server that doesn't respond

host Specify a RADIUS server

key Set RADIUS encryption key

retransmit Specify the number of retries to active server

timeout Time to wait for a RADIUS server to reply

<Minutes : 1-1440> Time in minutes

<Host4 : ipv4_ucast> IPv4 address

<Host6 : ipv6_ucast> IPv6 address

<HostName : word1-255> Hostname

acct-port UDP port for RADIUS accounting server

auth-port UDP port for RADIUS authentication server

| | |
|-----------------------------------|--|
| key | Server specific key (overrides default) |
| retransmit | Specify the number of retries to active server (overrides default) |
| timeout | Time to wait for this RADIUS server to reply (overrides default) |
| <AuthPort : 0-65535> | UDP port number |
| <Seconds : 1-1000> | Wait time in seconds |
| <Key : line1-63> | The shared key |
| <1-1000> | Number of retries for a transaction |

EXAMPLE

```
SC60010(config)# radius-server host device key 12
SC60010(config)#
```

rmon

Remote Monitoring.

SYNTAX

```
rmon alarm <1-65535> <WORD> <1-2147483647> { absolute | delta } rising-threshold <-2147483648-2147483647> [ <0-65535> ] falling-threshold <-2147483648-2147483647> [ <0-65535> ] { [ rising | falling | both ] }
```

```
rmon alarm <1-65535> { ifInOctets | ifInUcastPkts | ifInNUcastPkts | ifInDiscards | ifInErrors | ifInUnknownProtos | ifOutOctets | ifOutUcastPkts | ifOutNUcastPkts | ifOutDiscards | ifOutErrors } <uint> <1-2147483647> { absolute | delta } rising-threshold <-2147483648-2147483647> [ <0-65535> ] falling-threshold <-2147483648-2147483647> [ <0-65535> ] { [ rising | falling | both ] }
```

```
rmon event <1-65535> [ log ] [ trap <word127> ] { [ description <line127> ] }
```

Parameter

| | |
|------------------------|-------------------------|
| alarm | Configure an RMON alarm |
| event | Configure an RMON event |
| <1-65535> | Alarm entry ID |

| | |
|---------------------------------------|---|
| <WORD> | MIB object to monitor |
| <1-2147483647> | Sample interval |
| absolute | Test each sample directly |
| delta | Test delta between samples |
| rising-threshold | Configure the rising threshold |
| <-2147483648-2147483647> | rising threshold value |
| <0-65535> | Event to fire on rising threshold crossing |
| falling-threshold | Configure the falling threshold |
| <-2147483648-2147483647> | falling threshold value |
| rising | Trigger alarm when the first value is larger than the rising threshold |
| falling | Trigger alarm when the first value is less than the falling threshold |
| both | Trigger alarm when the first value is larger than the rising threshold or less than the falling threshold (default) |
| ifInOctets | The total number of octets received on the interface, including framing characters |
| ifInUcastPkts | The number of uni-cast packets delivered to a higher-layer protocol |
| ifInNUcastPkts | The number of broad-cast and multi-cast packets delivered to a higher-layer protocol |
| ifInDiscards | The number of inbound packets that are discarded even the packets are normal |
| ifInErrors | The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol |
| ifInUnknownProtos | The number of the inbound packets that were discarded because of the unknown or un-support protocol |
| ifOutOctets | The number of octets transmitted out of the interface , including framing characters |
| ifOutUcastPkts | The number of uni-cast packets that request to transmit |
| ifOutNUcastPkts | The number of broad-cast and multi-cast packets that request to transmit |
| ifOutDiscards | The number of outbound packets that are discarded event the packets is normal |
| ifOutErrors | The The number of outbound packets that could not be transmitted because of errors |

| | |
|-----------------------------|--------------------------------|
| <uint> | ifIndex |
| <1-2147483647> | Sample interval |
| absolute | Test each sample directly |
| delta | Test delta between samples |
| rising-threshold | Configure the rising threshold |

EXAMPLE

```
SC60010(config)# rmon alarm 10000 ifInErrors 10 9999 absolute rising-
threshold 0 falling-threshold 0 both
SC60010(config)#
```

sflow

Statistics flow

SYNTAX

sflow agent-ip { ipv4 <ipv4_addr> | ipv6 <ipv6_addr> }

sflow collector-address{ <ipv4_addr> | <ipv6_addr> }

sflow collector-port <1-65535>

sflow max-datagram-size [receiver <range_list>] <200-1468>

sflow timeout [receiver <range_list>] <0-2147483647>

Parameter

| | |
|--------------------------|---|
| agent-ip | The agent IP address used as agent-address in UDP datagrams. Defaults to IPv4 loopback address. |
| ipv4 | ipv4 address |
| ipv6 | ipv6 address |
| <ipv4_addr> | ipv6 address |
| <ipv6_addr> | ipv4 address |
| collector-address | Collector address |
| collector-port | Collector UDP port |

| | |
|-----------------------------|---|
| <1-65535> | Port Number |
| max-datagram-size | Maximum datagram size. |
| <200-1468> | Bytes |
| timeout | Receiver timeout measured in seconds. The switch decrements the timeout once per second, and as long as it is non-zero, the receiver receives samples. Once the timeout reaches 0, the receiver and all its configuration is reset to defaults. |
| <0-2147483647> | Number in seconds |

EXAMPLE

```
SC60010(config)# sflow agent-ip ipv4 192.168.1.2
SC60010(config)# sflow collector-port 3
SC60010(config)# sflow max-datagram-size 333
SC60010(config)# sflow timeout 3333
SC60010(config)#
```

smtp

Set email information

SYNTAX

smtp delete mailaddress <1-6>

smtp delete [returnpath | sender | server | username]

smtp mailaddress <1-6> <word47>

smtp (returnpath | sender | server) <word47>

smtp username <word31> <word31>

Parameter

| | |
|--------------------|----------------------------|
| delete | Delete command |
| mailaddress | Configure email address |
| returnpath | Configure email returnpath |
| sender | Configure email sender |
| server | Configure email server |

| | |
|-----------------------|---|
| username | Configure email user name |
| mailaddress | Delete email address |
| returnpath | Delete returnpath |
| sender | Delete sender |
| server | Delete email server |
| username | Delete username and password |
| <1-6> | Email address index |
| <word47> | Up to 47 characters describing mail address |
| <word47> | Up to 47 characters describing returnpath |
| <word47> | Up to 47 characters describing sender |
| <word47> | Up to 47 characters describing email server |
| <word31> | Up to 47 characters describing user name |
| <word31> | Configure email password |

EXAMPLE

```
SC60010(config)# smtp delete mailaddress 1
SC60010(config)# smtp delete returnpath
SC60010(config)#
```

snmp-server

Set SNMP server's configurations

SYNTAX

snmp-server

Table : configure –snmp-server Commands

| Command | Function |
|---------------------------|--------------------------------------|
| access | access configuration |
| community | Set the SNMP community |
| contact | Set the SNMP server's contact string |
| engine-id | Set SNMP engine ID |

| | |
|-----------------------------------|---------------------------------------|
| host | Set SNMP host's configurations |
| location | Set the SNMP server's location string |
| security-to-group | security-to-group configuration |
| trap | Set trap's configurations |
| user | Set the SNMPv3 user's configurations |
| version | Set the SNMP server's version |
| view | MIB view configuration |

access

access configuration.

SYNTAX

```
snmp-server access <GroupName : word32> model { v1 | v2c | v3 | any } level { auth | noauth | priv } [ read
<ViewName : word255> ] [ write <WriteName : word255> ]
```

Parameter

| | |
|------------------------------------|------------------------------------|
| <GroupName : word32> | group name |
| model | security model |
| any | any security model |
| v1 | v1 security model |
| v2c | v2c security model |
| v3 | v3 security model |
| level | security level |
| auth | authNoPriv Security Level |
| noauth | noAuthNoPriv Security Level |
| priv | authPriv Security Level |
| read | specify a read view for the group |
| write | specify a write view for the group |
| <ViewName : word255> | read view name |
| <WriteName : word255> | write view name |

EXAMPLE

```
SC60010(config)# snmp-server access text model v2c level noauth  
write text  
SC60010(config)#
```

community

Set the SNMP community.

SYNTAX

```
snmp-server community v2c <Community : word127> [ ro | rw ]
```

```
snmp-server community v3 <word127> [ <ipv4_addr> <ipv4_netmask> ]
```

Parameter

| | |
|------------------------------------|----------------|
| v2c | SNMPv2c |
| <Community : word127> | Community word |
| ro | Read only |
| rw | Read write |
| v3 | SNMPv3 |
| <Community : word127> | Community word |
| <ipv4_addr> | IPv4 address |
| <ipv4_netmask> | IPv4 netmask |

EXAMPLE

```
SC60010(config)# snmp-server community v2c text  
SC60010(config)#
```

contact

Set the SNMP server's contact string.

SYNTAX

```
snmp-server contact <line255>
```

Parameter

contact Set the SNMP server's contact string

<line255> contact string

EXAMPLE

```
SC60010(config)# snmp-server contact text
SC60010(config)#
```

engine-id

Set SNMP engine ID.

SYNTAX

```
snmp-server engine-id local <Engineid : word10-32>
```

Parameter

local Set SNMP local engine ID

<Engineid : word10-32> local engine ID

EXAMPLE

```
SC60010(config)# snmp-server engine-id local 1234567891
SC60010(config)#
```

host

Set SNMP host's configurations.

SYNTAX

snmp-server host <word32>

Parameter

<word32> Name of the host configuration

EXAMPLE

```
SC60010(config)# snmp-server host text
SC60010(config-snmps-host)#
```

location

Set the SNMP server's location string.

SYNTAX

snmp-server location <line255>

Parameter

<line255> location string

EXAMPLE

```
SC60010(config)# snmp-server location text
SC60010(config)#
```

security-to-group

security-to-group configuration.

SYNTAX

snmp-server security-to-group model { v1 | v2c | v3 } name <SecurityName : word32> group <GroupName : word32>

Parameter

model security model

v1 v1 security model

| | |
|--------------------------------------|---------------------|
| v2c | v2c security model |
| v3 | v3 security model |
| name | security user |
| <SecurityName : word32> | security user name |
| group | security group |
| <GroupName : word32> | security group name |

EXAMPLE

```
SC60010(config)# snmp-server security-to-group model v2c name text
group text
SC60010(config)#
```

trap

Set trap's configurations.

SYNTAX

snmp-server trap

EXAMPLE

```
SC60010(config)# snmp-server trap
SC60010(config)#
```

user

Set the SNMPv3 user's configurations.

SYNTAX

snmp-server user <Username : word32> engine-id <Engineid : word10-32> [{ md5 <Md5Passwd : word8-32> | sha <ShaPasswd : word8-40> } [priv { des | aes } <word8-32>]]

Parameter

<Username : word32> Username

| | |
|-------------------------------------|------------------------|
| engine-id | engine ID |
| <Engineid : word10-32> | Engine ID octet string |
| md5 | Set MD5 protocol |
| <Md5Passwd : word8-32> | MD5 password |
| sha | Set SHA protocol |
| <ShaPasswd word8-40> | SHA password |
| priv | Set Privacy |
| des | Set DES protocol |
| aes | Set AES protocol |
| <word8-32> | Set privacy password |

EXAMPLE

```
SC60010(config)# snmp-server user text engine-id 1234567891 md5
12345678 priv aes 12345678
SC60010(config)#
```

version

Set the SNMP server's version.

SYNTAX

```
snmp-server version { v1 | v2c | v3 }
```

Parameter

| | |
|------------|---------|
| v1 | SNMPv1 |
| v2c | SNMPv2c |
| v3 | SNMPv3 |

EXAMPLE

```
SC60010(config)# snmp-server version v2c
SC60010(config)#
```

view

MIB view configuration.

SYNTAX

```
snmp-server view <ViewName : word32> <OidSubtree : word255> { include | exclude }
```

Parameter

| | |
|-------------------------------------|-----------------------------|
| <ViewName : word32> | MIB view name |
| <OidSubtree : word255> | MIB view OID |
| include | Included type from the view |
| exclude | Excluded type from the view |

EXAMPLE

```
SC60010(config)# snmp-server view text .1 include
SC60010(config)#
```

spanning-tree

Spanning Tree protocol

Table : configure –spanning-tree Commands

| Command | Function |
|-------------|----------------------------|
| aggregation | Aggregation mode |
| edge | Edge ports |
| mode | STP protocol mode |
| mst | STP bridge instance |
| recovery | The error recovery timeout |
| transmit | BPDUs to transmit |

aggregation

Aggregation mode.

SYNTAX

spanning-tree aggregation

EXAMPLE

```
SC60010(config)# spanning-tree aggregation
SC60010(config-stp-aggr)#
```

edge

Edge ports.

SYNTAX

spanning-tree edge bpdu-filter

spanning-tree edge bpdu-guard

Parameter

bpdu-filter Enable BPDU filter (stop BPDU tx/rx)

bpdu-guard Enable BPDU guard

EXAMPLE

```
SC60010(config)# spanning-tree edge bpdu-filter
SC60010(config)#
```

mode

STP protocol mode.

SYNTAX

spanning-tree mode { stp | rstp | mstp }

Parameter

| | |
|-------------|---------------------------------|
| mstp | Multiple Spanning Tree (802.1s) |
| rstp | Rapid Spanning Tree (802.1w) |
| stp | 802.1D Spanning Tree |

EXAMPLE

```
SC60010(config)# spanning-tree mode stp
SC60010(config)#
```

mst

STP bridge instance.

SYNTAX

spanning-tree mst <Instance : 0-7> priority <Prio : 0-61440>

spanning-tree mst < Instance : 0-7> vlan <vlan_list>

spanning-tree mst forward-time <Fwdtime : 4-30>

spanning-tree mst max-age <Maxage : 6-40> [forward-time <Fwdtime : 4-30>]

spanning-tree mst max-hops <Maxhops : 6-40>

spanning-tree mst name <Name : word32> revision <0-65535>

Parameter

| | |
|-------------------------------|----------------------------------|
| <Instance : 0-7> | instance 0-7 (CIST=0, MST2=1...) |
| forward-time | Delay between port states |
| max-age | Max bridge age before timeout |
| max-hops | MSTP bridge max hop count |
| name | Name keyword |
| priority | Priority of the instance |
| vlan | VLAN keyword |
| <Prio : 0-61440> | Range in seconds |
| <vlan_list> | Range of VLANs |

| | |
|-------------------------------|--------------------|
| <Fwdtime : 4-30> | Range in seconds |
| <Maxage : 6-40> | Range in seconds |
| <Maxhops : 6-40> | Hop count range |
| <Name : word32> | Name of the bridge |
| revision | Revision keyword |
| <0-65535> | Revision number |

EXAMPLE

```
SC60010(config)# spanning-tree mst 7 vlan 10
SC60010(config)#
```

recovery

The error recovery timeouts.

SYNTAX

spanning-tree recovery interval <Interval : 30-86400>

Parameter

| | |
|------------------------------------|------------------|
| interval | The interval |
| <Interval : 30-86400> | Range in seconds |

EXAMPLE

```
SC60010(config)# spanning-tree recovery interval 50
SC60010(config)#
```

transmit

BPDUs to transmit.

SYNTAX

spanning-tree transmit hold-count <Holdcount : 1-10>

Parameter

hold-count Max number of transmit BPDUs per sec

<Holdcount : 1-10> 1-10 per sec, 6 is default

EXAMPLE

```
SC60010(config)# spanning-tree transmit hold-count 5
SC60010(config)#
```

switch2go-management

Switch2go Management configuration

SYNTAX

switch2go-management delete <1-6>

switch2go-management get activity-code

switch2go-management (port-name | port-role) interface [GigabitEthernet <port_type_list> (<line47> | * | GigabitEthernet)] [* (<line47> | <port_type_list>)]

switch2go-management server <word47>

switch2go-management switch2go-mode [disable | enable]

Parameter

| | |
|-----------------------|---|
| delete | Delete Mobile in List |
| get | Get Activity Code Action from SwitchAlert Management Server |
| port-name | Interface specific description |
| port-role | Configure Port Role |
| server | Configure SwitchAlert Management server IP address |
| switch2go-mode | Configure Switch2go Management mode |
| <1-6> | Mobile ID, available value is from 1 to 6 |
| activity-code | Get Activity Code Action from SwitchAlert Management Server |
| automatic | Enable NAT Option as Automatic |

| | |
|-------------------------------|--|
| manual | Enable NAT Option as Manual |
| <1-65535> | Port number |
| interface | Select an interface to configure |
| * | All switches or All ports |
| GigabitEthernet | 1 Gigabit Ethernet Port |
| <line47> | Up to 47 characters describing this interface |
| <port_type_list> | Port list for all port types |
| <word47> | SwitchAlert Management IP address or host name |
| disable | Disable SwitchAlert Management mode |
| enable | Enable SwitchAlert Management mode |

EXAMPLE

```
SC60010(config)# switch2go-management delete 1
SC60010(config)# switch2go-management get activity-code
SC60010(config)#
```

system

Set the SNMP server's configurations

SYNTAX

system contact <v_line255>

system location <v_line255>

system name <v_line255>

Parameter

contact Set the SNMP server's contact string

location Set the SNMP server's location string

name Set the SNMP server's system model name string

<line255> Maximum number of 255 character strings

EXAMPLE

```
SC60010(config)# system contact 222
SC60010(config)# system location 333
SC60010(config)# system name GE
SC60010(config)#
```

tacacs-server

Configure TACACS+.

SYNTAX

tacacs-server deadtime <minutes>

tacacs-server host <host_name> [port <port>] [timeout <seconds>] [key <key>]

tacacs-server key <key>

tacacs-server timeout <seconds>

Parameter

| | |
|---------------------------------|--|
| deadtime | Time to stop using a TACACS+ server that doesn't respond |
| host | Specify a TACACS+ server |
| key | Set TACACS+ encryption key |
| timeout | Time to wait for a TACACS+ server to reply |
| <Minutes : 1-1440> | Time in minutes |
| <Key : line1-63> | The shared key |
| <Seconds : 1-1000> | Wait time in seconds |
| <word1-255> | Hostname |
| <ipv4_ucast> | IPv4 address |
| <ipv6_ucast> | IPv6 address |
| port | TCP port for TACACS+ server |

<0-65535> TCP port number

EXAMPLE

```
SC60010(config)# tacacs-server deadtime 300
SC60010(config)# tacacs-server host 192.168.1.2
SC60010(config)# tacacs-server key 33
SC60010(config)# tacacs-server timeout 300
SC60010(config)#
```

upnp

Set UPnP's configurations.

SYNTAX

upnp

upnp advertising-duration <100-86400>

upnp ttl <1-255>

Parameter

advertising-duration Set advertising duration

ttl Set TTL value

<100-86400> advertising duration

<1-255> TTL value

EXAMPLE

```
SC60010(config)# upnp advertising-duration 8
SC60010(config)# upnp ttl 25
SC60010(config)#
```

username

Establish User Name Authentication.

SYNTAX

username <username> privilege <priv> password encrypted <encry_password>

username <username> privilege <priv> password none

username <username> privilege <priv> password unencrypted <password>

Parameter

| | |
|--------------------------------------|---|
| <Username : word31> | User name allows letters, numbers and underscores |
| privilege | Set user privilege level |
| <privilegeLevel : 0-15> | User privilege level |
| password | Specify the password for the user |
| encrypted | Specifies an ENCRYPTED password will follow |
| none | NULL password |
| unencrypted | Specifies an UNENCRYPTED password will follow |
| <Password : line31> | The UNENCRYPTED (Plain Text) user password. Any printable characters including space is accepted. Notice that you have no change to get the Plain Text password after this command. The system will always display the ENCRYPTED password. |
| <Password : word4-44> | The ENCRYPTED (hidden) user password. Notice the ENCRYPTED password will be decoded by system internally. You cannot directly use it as same as the Plain Text and it is not human-readable text normally. |

EXAMPLE

```
SC60010(config)# username jefferson privilege 15
password none
```

vlan

VLAN commands.

SYNTAX

vlan <vlan_list>

vlan ether-type s-custom-port <0x0600-0xffff>

vlan protocol { { eth2 { <0x600-0xffff> | arp | ip | ipx | at } } | { snap { <0x0-0xfffff> | rfc_1042 | snap_8021h } <0x0-0xffff> } | { llc <0x0-0xff> <0x0-0xff> } } group <word16>

Parameter

| | |
|------------------------------|--------------------------------------|
| <vlan_list> | ISL VLAN IDs 1-4095 |
| ether-type | Ether type for Custom S-ports |
| protocol | Protocol-based VLAN commands |
| s-custom-port | Custom S-ports configuration |
| <0x0600-0xffff> | Ether type (Range: 0x0600-0xffff) |
| eth2 | Ethernet-based VLAN commands |
| <0x600-0xffff> | Ether Type(Range: 0x600 - 0xFFFF) |
| arp | Ether Type is ARP |
| ip | Ether Type is IP |
| ipx | Ether Type is IPX |
| at | Ether Type is AppleTalk |
| snap | SNAP-based VLAN group |
| <0x0-0xfffff> | SNAP OUI (Range 0x000000 - 0FFFFFFF) |
| rfc_1042 | SNAP OUI is rfc_1042 |
| snap_8021h | SNAP OUI is 8021h |

| | |
|---------------------------|---------------------------------------|
| <0x0-0xffff> | PID (Range: 0x0 - 0xFFFF) |
| llc | LLC-based VLAN group |
| <0x0-0xff> | DSAP (Range: 0x00 - 0xFF) |
| <0x0-0xff> | SSAP (Range: 0x00 - 0xFF) |
| group | Protocol-based VLAN group commands |
| <word16> | Group Name (Range: 1 - 16 characters) |

EXAMPLE

```

SC60010(config)# vlan ethertype s-custom-port 0x1111
SC60010(config)# vlan protocol eth2 arp group 123
SC60010(config)#

```

voice

Voice appliance attributes.

SYNTAX

voice vlan

voice vlan aging-time <aging_time>

voice vlan class { <traffic_class> | low | normal | medium | high }

voice vlan oui <oui> [description <description>]

voice vlan vid <vid>

Parameter

| | |
|-----------------------------|---------------------------------|
| advertising-duration | Set advertising duration |
| vlan | Vlan for voice traffic |
| aging-time | Set secure learning aging time |
| <10-10000000> | Aging time, 10-10000000 seconds |
| class | Set traffic class |

| | |
|------------------------|-----------------------------|
| <0-7> | Traffic class value |
| oui | OUI configuration |
| <oui> | OUI value |
| description | Set description for the OUI |
| <line32> | Description line |
| vid | Set VLAN ID |
| <vlan_id> | VLAN ID, 1-4095 |

EXAMPLE

```
SC60010(config)# voice vlan aging-time 3333
SC60010(config)# voice vlan class 7
SC60010(config)# voice vlan vid 3333
SC60010(config)#
```

web

Web.

SYNTAX

web privilege group <CWORD> level { [crw <0-15>] [sro <0-15>] [srw <0-15>] }

Parameter

| | |
|------------------|---|
| privilege | Web privilege |
| group | Web privilege group |
| CWORD | Valid words are 'Aggregation' 'Debug' 'Dhcp_Client' 'Green_Ethernet' 'IP2' 'IPMC_Snooping' 'LACP' 'LLDP' 'Loop_Protect' 'MAC_Table' 'MEP' 'MVR' 'Maintenance' 'Mirroring' 'NTP' 'POE' 'Ports' 'Private_VLANS' 'QoS' 'RPC' 'Security' 'Spanning_Tree' 'System' 'Timer' 'UPnP' 'VCL' 'VLAN_Translation' 'VLANS' 'Voice_VLAN' |

| | |
|--------------|------------------------------------|
| | 'sFlow' |
| level | Web privilege group level |
| cro | Configuration Read-only level |
| crw | Configuration Read-write level |
| sro | Status/Statistics Read-only level |
| srw | Status/Statistics Read-write level |

EXAMPLE

```
SC60010(config)# web privilege group ptp level sro  
10
```

Copy from source to destination

SYNTAX

```
copy { startup-config | running-config | < flash:filename | tftp://server/path-and-filename > } { startup-config |
running-config | < flash:filename | tftp://server/path-and-filename > } [ syntax-check ][ | { begin | exclude |
include } { <LINE > }]
```

Parameter

| | |
|---|--|
| flash:filename tftp://server/path-and-filename | File in FLASH or on TFTP server |
| running-config | Currently running configuration |
| startup-config | Startup configuration |
| | Output modifiers |
| syntax-check | Perform syntax check on source configuration |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# copy startup-config running-config syntax-check | include
#
```


Debugging functions

SYNTAX

debug prompt text

Parameter

prompt Set prompt for testing

WORD Word for prompt in 32 char's

EXAMPLE

```
SC60010# debug prompt test
test#
```

Delete one file in flash: file system

SYNTAX

Delete <Path : word>

Parameter

<Path : word> Name of file to delete

EXAMPLE

```
SC60010# delete text
SC60010#
```

Directory of all files in flash: file system

SYNTAX

Dir [| begin | exclude | include <LINE>]

Parameter

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# dir
Directory of flash:
  r- 2011-01-01 00:00:00      720 default-config
  rw 2011-01-01 00:00:11    1777 startup-config
2 files, 2497 bytes total.
```

Turn off privileged commands

SYNTAX

disable <0-15>

Parameter

<0-15> Privilege level

EXAMPLE

```
SC60010# disable 10
SC60010#
```

To run exec commands in config mode

SYNTAX

Do <LINE>{[LINE]}

Parameter

LINE Exec Command

EXAMPLE

```
SC60010# do show clock
System Time      : 2011-01-01T00:03:44+00:00
```

IEEE Standard for port-based Network Access Control

SYNTAX

```
dot1x initialize [ interface ( <port_type> [ <plist> ] ) ]
```

Parameter

| | |
|-------------------------------|---|
| initialize | Force re-authentication immediately |
| interface | Interface |
| * | All switches or All ports |
| Gigabitethernet | 1 GigabitEthernet port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010# dot1x initialize interface GigabitEthernet 1/1-26
SC60010#
```

Turn on privileged commands

Syntax

Enable <1-15>

Parameter

<0-15> Choose privileged level

EXAMPLE

```
SC60010# enable 10
SC60010#
```

Firmware upgrade/swap

Syntax

firmware swap

firmware upgrade < TFTPServer_path_file : word>

Parameter

swap Swap between Active and Alternate firmware image.

upgrade Firmware upgrade

<TFTPServer_path_file : word> TFTP Server IP address, path and file name
for the server containing the new image.

EXAMPLE

```
SC60010# firmware upgrade tftp://192.168.1.1/path/GEL2706
Programming image...
SC60010#
```


IPv4 commands

Syntax

```
ip dhcp retry interface vlan <vlan_id>
```

Parameter

| | |
|------------------------|--------------------------------|
| dhcp | Dhcp commands |
| retry | Restart the DHCP query process |
| interface | Interface |
| vlan | Vlan interface |
| <vlan_id> | Vlan ID |

EXAMPLE

```
SC60010# ip dhcp retry interface vlan 1
```

Negate a command or set its defaults

Syntax

no debug prompt

no port-security shutdown

no terminal { editing | exec-timeout | (history size) | length | width }

Parameter

| | |
|----------------------|---|
| debug | Debugging functions |
| port-security | Port security (psec limit) |
| terminal | Set terminal line parameters |
| prompt | Clear prompt for testing |
| shutdown | Reopen one or more ports whose limit is exceeded and shut down. |
| editing | Enable command line editing |
| exec-timeout | Set the EXEC timeout |
| history | Control the command history function |
| length | Set number of lines on a screen |
| width | Set width of the display terminal |
| size | Set history buffer size |

EXAMPLE

```
SC60010# no debug prompt
SC60010#
```

Send ICMP echo messages

Syntax

```
ping ip <word1-255> [ repeat <Count : 1-60> ] [ size <Size : 2-1452> ] [ interval <Seconds : 0-30> ]
```

```
ping ipv6 <ipv6_addr> [ repeat <Count : 1-60> ] [ size <Size : 2-1452> ] [ interval <Seconds : 0-30> ] [ interface
vlan <vlan_id> ]
```

Parameter

| | |
|-------------------------------|--|
| ip | IP (ICMP) echo |
| <word1-255> | ICMP destination address |
| repeat | Specify repeat count |
| <Count : 1-60> | 1-60; Default is 5 |
| size | Specify datagram size |
| <Size : 2-1452> | 2-1452; Default is 56 (excluding MAC, IP and ICMP headers) |
| interval | Specify repeat interval |
| <Seconds : 0-30> | 0-30; Default is 0 |
| ipv6 | IPv6 (ICMPv6) echo |
| <ipv6_addr> | ICMPv6 destination address |
| repeat | Specify repeat count |
| <1-60> | 1-60; Default is 5 |
| size | Specify datagram size |
| <2-1452> | 2-1452; Default is 56 (excluding MAC, IP and ICMP headers) |
| interval | Specify repeat interval |
| <0-30> | 0-30; Default is 0 |
| interface | Select an interface to configure |
| vlan | VLAN Interface |

<vlan_id>

VLAN identifier(s): VID

EXAMPLE

```
SC60010# ping ip 33 interval 22 repeat 33 size 444  
PING server 0.0.0.33, 444 bytes of dataitalize interfac
```

Reload system.

Syntax

```
reload { { cold | warm } [ sid <usid> ] } | { defaults [ keep-ip ] }
```

Parameter

| | |
|-----------------|------------------------------------|
| cold | Reload cold, i.e. reboot. |
| defaults | Reload defaults without rebooting. |
| keep-ip | Attempt to keep VLAN1 IP setup. |

EXAMPLE

```
SC60010# reload defaults
% Reloading defaults. Please stand by.
SC60010# reload cold
% Cold reload in progress, please stand by.
SC60010# +M25PXX : Init device with JEDEC ID 0x20BA19.
Luton26 board detected (VSC7427 Rev. D).

RedBoot(tm) bootstrap and debug environment [ROMRAM]
Non-certified release, version 1_15a-Vitesse - built 18:36:46, Sep 30
2016

Copyright (C) 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009
Free Software Foundation, Inc.

RedBoot is free software, covered by the eCos license, derived from the
GNU General Public License. You are welcome to change it and/or
distribute
copies of it under certain conditions. Under the license terms, RedBoot's
source code and full license terms must have been made available to you.
Redboot comes with ABSOLUTELY NO WARRANTY.
```

Send a message to other tty lines

Syntax

```
send { * | <session_list> | console 0 | vty <vty_list> } <message>
```

Parameter

| | |
|---------------------|--|
| * | All tty lines |
| <0~16> | Send a message to multiple lines |
| console | Primary terminal line |
| 0 | Send a message to a specific line |
| vty | Virtual terminal |
| <0~15> | Send a message to multiple lines |
| <LINE> | Message to be sent to lines, in 128 char's |

EXAMPLE

```
SC60010# send * yes,i do
Enter TEXT message. End with the character 'y'.

y

-----

*** Message from line 0:
yes,i do

-----

SC60010#
```

Show running system information

Table : SHOW Commands

| Command | Function |
|----------------------------|---|
| aaa | Login methods |
| access | Access management |
| access-list | Access list |
| aggregation | Aggregation port configuration |
| broadcast-storm-protection | Broadcast Storm Protection |
| clock | Configure time-of-day clock |
| dhcp | Dynamic Host Configuration Protocol |
| dot1x | IEEE Standard for port-based Network Access Control |
| event | Show trap event configuration |
| green-ethernet | Green ethernet (Power reduction) |
| history | Display the session command history |
| interface | Interface status and configuration |
| ip | Internet Protocol |
| ipmc | IPv4/IPv6 multicast configuration |
| ipv6 | IPv6 configuration commands |
| lACP | LACP configuration/status |
| line | TTY line information |
| lldp | Display LLDP neighbors information. |
| logging | Syslog |
| loop-protect | Loop protection configuration |
| mac | Mac Address Table information |
| mvr | Multicast VLAN Registration configuration |
| non-stop-poe | Show Non-Stop PoE Status |
| ntp | Configure NTP |
| platform | platform specific information |
| poE | Power over ethernet |
| port-security | |
| privilege | Display command privilege |
| pVLAN | PVLAN status |
| qos | Quality of Service |
| radius-server | RADIUS configuration |
| rmon | RMON statistics |

| | |
|--------------------------------------|---|
| running-config | Show running system information |
| sflow | Statistics flow. |
| smtp | Show email information |
| snmp | Display SNMP configurations |
| spanning-tree | STP Bridge |
| switch2go-management | Show Switch2go Management information |
| switchport | Display switching mode characteristics |
| System | show system information |
| tacacs-server | TACACS+ configuration |
| terminal | Display terminal configuration parameters |
| upnp | Display UPnP configurations |
| user-privilege | Users privilege configuration |
| users | Display information about terminal lines |
| version | System hardware and software status |
| vlan | VLAN status |
| voice | Voice appliance attributes |
| web | Web |

aaa

Login methods.

SYNTAX

```
show aaa [ | {begin | exclude | include } <LINE>]
```

Parameter

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE


```
SC60010# show aaa
console : local
telnet  : local
ssh     : local
http    : local
SC60010#
```

access

Access management.

SYNTAX

```
show access management [ statistics | <access_id_list> ]
```

Parameter

management Access management configuration

statistics Statistics data

<AccessidList : 1~16> ID of access management entry

| Output modifiers

begin Begin with the line that matches

exclude Exclude lines that match

include Include lines that match

<LINE> String to match output lines

EXAMPLE

```
SC60010# show access management
Switch access management mode is disabled

W: WEB/HTTPS
S: SNMP
T: TELNET/SSH

Idx VID Start IP Address          End IP Address          W S
T
-----
- - - -
SC60010# show access management statistics

Access Management Statistics:
-----
HTTP   Receive:      0   Allow:      0   Discard:    0
HTTPS  Receive:      0   Allow:      0   Discard:    0
SNMP   Receive:      0   Allow:      0   Discard:    0
TELNET Receive:      0   Allow:      0   Discard:    0
SSH    Receive:      0   Allow:      0   Discard:    0
```

access-list

Access list

SYNTAX

```
show access-list [ interface [ * | Gigabitethern <PORT_LIST> ] ] [ rate-limiter [ <RateLimiterList : 1~16> ] ]
[ ace statistics [ <Aceld : 1~256> ] ]
```

```
show access-list ace-status [ static ] [ loop-protect ] [ dhcp ] [ upnp ] [ arp-inspection ] [ mep ] [ ipmc ] [ ip-
source-guard ] [ ip-mgmt ] [ conflicts ]
```

Parameter

interface Select an interface to configure

***** All Switches or All Ports

| | |
|--|--|
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 |
| rate-limiter | Rate limiter |
| < RateLimiterList : 1~16> | Rate limiter ID |
| ace | Access list entry |
| statistics | Traffic statistics |
| <Acelid : 1~256> | ACE ID |
| ace-status | The local ACEs status |
| static | The ACEs that are configured by users manually |
| loop-protect | The ACEs that are configured by Loop Protect module |
| dhcp | The ACEs that are configured by DHCP module |
| upnp | The ACEs that are configured by UPnP module |
| arp-inspection | The ACEs that are configured by ARP Inspection module |
| mep | The ACEs that are configured by MEP module |
| ipmc | The ACEs that are configured by IPMC module |
| ip-source-guard | The ACEs that are configured by IP Source Guard module |
| ip-mgmt | The ACEs that are configured by IP Management module |
| conflicts | The conflicts ACEs that does not applied to the hardware due to hardware limitations |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show access-list ace statistics rate-limiter

Switch access-list ace number: 0

Switch access-list rate limiter ID 1 is 1 pps
Switch access-list rate limiter ID 2 is 1 pps
Switch access-list rate limiter ID 3 is 1 pps
Switch access-list rate limiter ID 4 is 1 pps
Switch access-list rate limiter ID 5 is 1 pps
Switch access-list rate limiter ID 6 is 1 pps
Switch access-list rate limiter ID 7 is 1 pps
Switch access-list rate limiter ID 8 is 1 pps
Switch access-list rate limiter ID 9 is 1 pps
Switch access-list rate limiter ID 10 is 1 pps
Switch access-list rate limiter ID 11 is 1 pps
Switch access-list rate limiter ID 12 is 1 pps
Switch access-list rate limiter ID 13 is 1 pps
Switch access-list rate limiter ID 14 is 1 pps
Switch access-list rate limiter ID 15 is 1 pps
Switch access-list rate limiter ID 16 is 1 pps
SC60010#
```

aggregation

Aggregation port configuration.

SYNTAX

```
show aggregation [ mode ] [ [ {begin | exclude | include } <LINE>]
```

Parameter

| | |
|--------------|----------------------------------|
| mode | Traffic distribution mode |
| | Output modifiers |
| begin | Begin with the line that matches |

| | |
|---------------------|------------------------------|
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```

SC60010# show aggregation Mode
Aggregation Mode:

SMAC : Enabled
DMAC : Disabled
IP   : Enabled
Port : Enabled
SC60010#

```

broadcast-storm-protection

Broadcast Storm Protection

SYNTAX

show broadcast-storm-protection

show broadcast-storm-protection | { begin | exclude | include } LINE

show broadcast-storm-protection interface [*] { | | PORT_LIST }

show broadcast-storm-protection interface { * | GigabitEthernet }

Parameter

| | |
|------------------|----------------------------------|
| | Output modifiers |
| interface | Select an interface to configure |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| LINE | String to match output lines |

- * All switches or All ports
- GigabitEthernet** 1 Gigabit Ethernet Port
- PORT_LIST** Port list for all port types

EXAMPLE

```

SC60010# show broadcast-storm-protection interface *
Port  Mode      Action          PPS      Timer(seconds)  Status
-----
1     Enable    Shutdown       74400    300
2     Enable    Shutdown       74400    300
'
'
'
'

N-2   Enable    Shutdown       74400    300
N-1   Enable    Shutdown       74400    300
N     Enable    Shutdown       74400    300
SC60010#

```

clock

Configure time-of-day clock.

SYNTAX

show clock [detail]

Parameter

detail Display detailed information

EXAMPLE

```
SC60010# show clock detail
System Time      : 2011-01-01T00:53:57+00:00

Timezone : Timezone Offset : 0 ( 0 minutes)
Timezone Acronym :

Daylight Saving Time Mode : Disabled.
Daylight Saving Time Start Time Settings :
    Week: 0
    Day: 0
    Month: 0
    Date: 0
    Year: 0
    Hour: 0
    Minute: 0
Daylight Saving Time End Time Settings :
    Week: 0
    Day: 0
    Month: 0
    Date: 0
    Year: 0
    Hour: 0
    Minute: 0
Daylight Saving Time Offset : 1 (minutes)
```

dhcp

Dynamic Host Configuration Protocol

SYNTAX

show dhcp helper debug

Parameter

helper DHCP helper

debug

EXAMPLE

```
SC60010# show dhcp helper debug
DHCP helper
frame_info_cnt : 0
debug : disable
SC60010#
```

dot1x

IEEE Standard for port-based Network Access Control.

SYNTAX

```
show dot1x statistics { eapol | radius | all } [ interface <port_type> <port_type_list> ] [ {begin | exclude | include } <LINE>]
```

```
show dot1x status [ interface ( <port_type> [ <port_type_list> ] ) ] [ brief ] [ {begin | exclude | include } <LINE>]
```

Parameter

| | |
|-------------------------------|--|
| statistics | Shows statistics for either eapol or radius. |
| all | Show all dot1x statistics |
| eapol | Show EAPOL statistics |
| radius | Show Backend Server statistics |
| <port_type > | GigabitEthernet |
| <port_type_list> | Port list in 1/1-26 for Gigabotethernet |
| Status | Shows dot1x status, such as admin state, port state and last source. |
| brief | Show status in a brief format |
| interface | Interface |
| * | All Switches or All Ports |

Gigabitethernet 1 Gigabit Ethernet Port

<port_type_list> Port list in 1/1-26 for Gigabitethernet

EXAMPLE

```
SC60010# show dot1x statistics radius
```

| Interface | Rx Access Challenges | Rx Other Requests | Rx Auth. Successes | Rx Auth. Failures | Tx Responses | MAC Address |
|---------------------|----------------------|-------------------|--------------------|-------------------|--------------|-------------|
| GigabitEthernet 1/1 | 0 | 0 | 0 | 0 | 0 | - |
| GigabitEthernet 1/2 | 0 | 0 | 0 | 0 | 0 | - |
| GigabitEthernet 1/3 | 0 | 0 | 0 | 0 | 0 | - |
| GigabitEthernet 1/4 | 0 | 0 | 0 | 0 | 0 | - |
| GigabitEthernet 1/5 | 0 | 0 | 0 | 0 | 0 | - |

```
SC60010#
```

event

Show trap event configuration

SYNTAX

show event

EXAMPLE

```
SC60010# show event
```

```
Group Name          Severity Level   Syslog Mode   Trap Mode     SMTP Mode     iPush
Mode
```

```
-----
-----
ACL                  Info             enable        disable       disable       disable
ACL-Log              Info             enable        disable       disable       disable
Access-Mgmt          Info             enable        disable       disable       disable
Auth-Failed          Warning          enable        disable       disable       disable
Cold-Start          Warning          enable        disable       disable       disable
Config-Info          Info             enable        disable       disable       disable
DMS                  Info             enable        disable       disable       disable
Firmware-Upgrade     Info             enable        disable       disable       disable
Import-Export        Info             enable        disable       disable       disable
LACP                 Info             enable        disable       disable       disable
Link-Status          Warning          enable        disable       disable       disable
Login                Info             enable        disable       disable       disable
Logout               Info             enable        disable       disable       disable
Loop-Protect         Info             enable        disable       disable       disable
Mgmt-IP-Change       Info             enable        disable       disable       disable
Module-Change        Warning          enable        disable       disable       disable
NAS                  Info             enable        disable       disable       disable
Password-Change      Info             enable        disable       disable       disable
PoE-Auto-Check       Warning          enable        disable       disable       disable
Port-Security        Info             enable        disable       disable       disable
Reset-Security       Warning          disable        enable        disable       disable
Spanning-Tree        Info             enable        disable       disable       disable
Warm-Start           Warning          enable        disable       disable       disable
```

green-ethernet

Green ethernet (Power reduction).

SYNTAX

show green-ethernet [interface <port_type> <port_type_list>]

show green-ethernet eee [interface <port_type> <port_type_list>]

show green-ethernet energy-detect [interface <port_type> <port_type_list>]

show green-ethernet short-reach [interface <port_type> <port_type_list>]

Parameter

| | |
|-------------------------------|---|
| eee | Shows green ethernet EEE status for a specific port or ports. |
| energy-detect | Shows green ethernet energy-detect status for a specific port or ports. |
| interface | Shows green ethernet status for a specific port or ports. |
| short-reach | Shows green ethernet short-reach status for a specific |
| interface | |
| * | All Switches or All ports |
| <port_type > | GigabitEthernet or |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010# show green-ethernet eee
Interface          Lnk  EEE Capable  EEE Enabled  LP EEE Capable  In
Power Save
-----
-----
GigabitEthernet 1/1    No   Yes         No           No           No
GigabitEthernet 1/2    No   Yes         No           No           No
GigabitEthernet 1/3    No   Yes         No           No           No
GigabitEthernet 1/4    No   Yes         No           No           No
GigabitEthernet 1/5    No   Yes         No           No           No
GigabitEthernet 1/6    No   Yes         No           No           No
GigabitEthernet 1/7    No   Yes         No           No           No
GigabitEthernet 1/8    No   Yes         No           No           No
GigabitEthernet 1/9    No   Yes         No           No           No
```

history

Display the session command history.

SYNTAX

```
show history [ | {begin | exclude | include } <LINE>]
```

Parameter

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show history
  show evc statistics
  show green-ethernet EEE
  show green-ethernet EEE interface GigabitEthernet
  show history
SC60010#
```

interface

Interface status and configuration.

SYNTAX

```
show interface <port_type> <port_type_list> [ switchport [ access | trunk | hybrid ]]
```

```
show interface <port_type> <port_type_list> capabilities
```

```
show interface <port_type> <port_type_list> statistics [ { packets | bytes | errors | discards | filtered | { priority
[ <0~7> ] } } ] [ { up | down } ]
```

```
show interface <port_type> <port_type_list> status
```

show interface <port_type> <port_type_list> verify

show interface vlan [<vlan_list>]

Parameter

| | |
|-------------------------------|---|
| <port_type> | Gigabitethernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabitethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| capabilities | Display capabilities. |
| statistics | Display statistics counters. |
| status | Display status. |
| switchport | Show interface switchport information |
| verify | Run cable diagnostics and show result. |
| bytes | Show byte statistics. |
| discards | Show discard statistics. |
| down | Show ports which are down |
| errors | Show error statistics. |
| filtered | Show filtered statistics. |
| packets | Show packet statistics. |
| priority | Queue number |
| up | Show ports which are up |
| vlan | VLAN status |
| <vlan_list> | VLAN list |

EXAMPLE

```
SC60010# show interface GigabitEthernet 1/1-3 capabilities

GigabitEthernet 1/1 Capabilities:
SFP Type: None
SFP Vendor name:
SFP Vendor PN:
SFP Vendor revision:

GigabitEthernet 1/2 Capabilities:
SFP Type: None
SFP Vendor name:
SFP Vendor PN:
SFP Vendor revision:

GigabitEthernet 1/3 Capabilities:
SFP Type: None
SFP Vendor name:
SFP Vendor PN:
SFP Vendor revision:
SC60010#
```

ip

Internet Protocol.

SYNTAX

show ip arp

show ip arp inspection [interface {<port_type> <port_type_list>} | vlan <vlan_list>]

show ip arp inspection entry [dhcp-snooping | static] [interface <port_type> <port_type_list>]

show ip dhcp relay [statistics]

show ip dhcp snooping [statistics] [interface <port_type> <port_type_list>]

show ip http server secure status

show ip igmp snooping [vlan <vlan_list>] [group-database [interface <port_type> <port_type_list>] [sfm-information]] [detail]

show ip igmp snooping mrouter [detail]

show ip interface brief

show ip name-server

show ip route

show ip source binding [dhcp-snooping | static] [interface <port_type> <port_type_list>]

show ip ssh

show ip statistics [system] [interface vlan <vlan_list>] [icmp] [icmp-msg <0~255>]

show ip verify source [interface <port_type> <port_type_list>]

Parameter

| | |
|-------------------------------|---|
| arp | Address Resolution Protocol |
| inspection | ARP inspection |
| interface | arp inspection entry interface config |
| <port_type> | Gigabitethernet |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| vlan | VLAN configuration |
| <vlan_list> | Select a VLAN id to configure |
| entry | arp inspection entries |
| dhcp-snooping | learn from dhcp snooping |
| static | setting from static entries |
| dhcp | Dynamic Host Configuration Protocol |
| relay | DHCP relay agent configuration |
| statistics | Traffic statistics |
| snooping | DHCP snooping |
| http | Hypertext Transfer Protocol |
| server | HTTP web server |

| | |
|--------------------------|---|
| secure | Secure |
| status | Status |
| igmp | Internet Group Management Protocol |
| snooping | Snooping IGMP |
| vlan | Search by VLAN |
| <vlan_list> | VLAN identifier(s): VID |
| group-database | Multicast group database from IGMP |
| sfm-information | Including source filter multicast information from IGMP |
| detail | Detail running information/statistics of IGMP snooping |
| mrouter | Multicast router port status in IGMP |
| detail | Detail running information/statistics of IGMP snooping |
| interface | IP interface status and configuration |
| brief | Brief IP interface status |
| name-server | Domain Name System |
| route | Display the current ip routing table |
| binding | ip source binding |
| dhcp-snooping | learn from dhcp snooping |
| ssh | Secure Shell |
| system | IPv4 system traffic |
| icmp | IPv4 ICMP traffic |
| icmp-msg | IPv4 ICMP traffic for designated message type |
| <0~255> | ICMP message type ranges from 0 to 255 |
| verify | verify command |
| source | verify source |

EXAMPLE

```
SC60010# show ip statistics system

IPv4 statistics:

  Rcvd: 411 total in 36226 bytes
        273 local destination, 0 forwarding
        0 header error, 0 address error, 0 unknown protocol
        0 no route, 0 truncated, 138 discarded

  Sent: 0 total in 0 byte
        0 generated, 0 forwarded
        0 no route, 0 discarded

  Frags: 0 reassemble (0 reassembled, 0 couldn't reassemble)
        0 fragment (0 fragmented, 0 couldn't fragment)
        0 fragment created

  Mcast: 411 received in 36226 bytes
        0 sent in 0 byte

  Bcast: 273 received, 0 sent

SC60010#
```

ipmc

IPv4/IPv6 multicast configuration.

SYNTAX

```
show ipmc profile [ <ProfileName : word16> ] [ detail ] [ | {begin | exclude | include } <LINE> ]
```

```
show ipmc range [ <EntryName : word16> ] [ | {begin | exclude | include } <LINE> ]
```

Parameter

| | |
|-------------------------------------|--|
| profile | IPMC profile configuration |
| range | A range of IPv4/IPv6 multicast addresses for the profile |
| <ProfileName : word16> | Profile name in 16 char's |
| detail | Detail information of a profile |
| <EntryName : word16> | Range entry name in 16 char's |

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show ipmc range
SC60010#
```

ipv6

IPv6 configuration commands.

SYNTAX

show ipv6 interface [vlan <vlan_list> { brief | statistics }] [{begin | exclude | include } <LINE>]

show ipv6 mld snooping [vlan <vlan_list>] [group-database [interface <port_type> <port_type_list>] [sfm-information]] [detail]

show ipv6 mld snooping mrouter [detail]

show ipv6 neighbor [interface vlan <vlan_list>]

show ipv6 route [interface vlan <vlan_list>]

show ipv6 statistics [system] [interface vlan <vlan_list>] [icmp] [icmp-msg <Type : 0~255>]

Parameter

| | |
|--------------------------|--|
| interface | Select an interface to configure |
| vlan | VLAN of IPv6 interface |
| <vlan_list> | IPv6 interface VLAN list |
| brief | Brief summary of IPv6 status and configuration |
| statistics | Traffic statistics |
| mld | Multicast Listener Discovery |
| snooping | Snooping MLD |

| | |
|-------------------------------|--|
| vlan | Search by VLAN |
| <vlan_list> | VLAN identifier(s): VID |
| group-database | Multicast group database from MLD |
| interface | Search by port |
| <port_type> | Gigabitethernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| sfm-information | Including source filter multicast information from MLD |
| detail | Detail running information/statistics of MLD snooping |
| mrouter | Multicast router port status in MLD |
| neighbor | IPv6 neighbors |
| route | IPv6 routes |
| statistics | Traffic statistics |
| system | IPv6 system traffic |
| icmp | IPv6 ICMP traffic |
| icmp-msg | IPv6 ICMP traffic for designated message type |
| <Type : 0~255> | ICMP message type ranges from 0 to 255 |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show ipv6 statistics system

IPv6 statistics:

Rcvd: 2 total in 112 bytes
      0 local destination, 0 forwarding
      0 header error, 0 address error, 0 unknown protocol
      0 no route, 0 truncated, 2 discarded

Sent: 8 total in 512 bytes
      14 generated, 0 forwarded
      3 no route, 0 discarded

Frag: 0 reassemble (0 reassembled, 0 couldn't reassemble)
      0 fragment (0 fragmented, 0 couldn't fragment)
      0 fragment created

Mcast: 2 received in 112 bytes
        8 sent in 512 bytes

Bcast: 0 received, 0 sent

SC60010#
```

lACP

LACP configuration/status.

SYNTAX

```
show lACP { internal | statistics | system-id | neighbour } [ | {begin | exclude | include } <LINE>]
```

Parameter

| | |
|-------------------|----------------------------------|
| internal | Internal LACP configuration |
| neighbour | Neighbour LACP status |
| statistics | Internal LACP statistics |
| system-id | LACP system id |
| | Output modifiers |
| begin | Begin with the line that matches |

| | |
|---------------------|------------------------------|
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```

SC60010# show lacp internal
Port  Mode      Key  Role  Timeout  Priority
-----
1     Disabled  Auto  Active  Fast     32768
2     Disabled  Auto  Active  Fast     32768
3     Disabled  Auto  Active  Fast     32768
4     Disabled  Auto  Active  Fast     32768
5     Disabled  Auto  Active  Fast     32768
6     Disabled  Auto  Active  Fast     32768
7     Disabled  Auto  Active  Fast     32768
SC60010#

```

line

TTY line information.

SYNTAX

```
show line [ alive ] [ | {begin | exclude | include } <LINE>]
```

Parameter

| | |
|---------------------|---------------------------------------|
| alive | Display information about alive lines |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show line alive
Line is con 0.
    * You are at this line now.
    Alive from Console.
    Default privileged level is 2.
    Command line editing is enabled
    Display EXEC banner is enabled.
    Display Day banner is enabled.
    Terminal width is 80.
        length is 24.
            history size is 32.
                exec-timeout is 10 min 0 second.

Current session privilege is 15.
Elapsed time is 0 day 0 hour 26 min 52 sec.
Idle time is 0 day 0 hour 0 min 0 sec.

SC60010#
```

lldp

Display LLDP neighbors information..

SYNTAX

```
show lldp med media-vlan-policy [ <0~31> ] [ | {begin | exclude | include } <LINE>]
```

```
show lldp med remote-device [ interface <port_type> <port_type_list> ] [ | {begin | exclude | include } <LINE>]
```

```
show lldp neighbors [ interface <port_type> <port_type_list> ] [ | {begin | exclude | include } <LINE>]
```

```
show lldp statistics [ interface <port_type> <port_type_list> ] [ | {begin | exclude | include } <LINE>]
```

Parameter

med Display LLDP-MED neighbors information.

neighbors Display LLDP neighbors information.

| | |
|-------------------------------|---|
| statistics | Display LLDP statistics information. |
| media-vlan-policy | Display media vlan policies. |
| remote-device | Display remote device LLDP-MED neighbors information. |
| <0~31> | List of policies. |
| Interface | |
| <port_type > | GigabitEthernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show lldp med media-vlan-policy
No policies defined
SC60010#
```

logging

Syslog.

SYNTAX

```
show logging <loggin_id : 1-4294967295> { [ exclude | include ] <LINE> } | { switch <switch_list> }
```

```
show logging [ alert ] [ crit ] [ debug ] [ emerg ] [ error ] [ info ] [ notice ] [ warning ] { | ( begin | exclude | include ) <LINE> }
```

Parameter

```
<logging_id: 1-4294967295> Logging ID
```

| | |
|----------------------------|----------------------------------|
| | Output modifiers |
| alert | Alert |
| crit | Critical |
| debug | Debug |
| emerg | Emergency |
| error | Error |
| info | Information |
| notice | Notice |
| warning | Warning |
| exclude | Exclude lines that match |
| include | Include lines that match |
| switch | Switch |
| LINE | String to match output lines |
| <switch_list> | Switch ID list in 1 |
| begin | Begin with the line that matches |

EXAMPLE

```
SC60010# show logging info
Switch logging host mode is disabled
Switch logging host address is null
Swi
Number of logging level is information
Number of entries:
Info      : 3
Warning: 158SC60010# show logging 1 exclude line
Switch    : 1
ID        : 1
Level     : Info
Time      : 2011-01-01T02:03:56+00:00
Message:
User 'admin' logout
through TELNET from 192.168.1.3
SC60010#
```

loop-protect

Loop protection configuration.

SYNTAX

```
show loop-protect [ interface <port_type> <port_type_list> ]
```

Parameter

| | |
|-------------------------------|---|
| interface | Interface status and configuration |
| <port_type > | GigabitEthernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```
SC60010# show loop-protect

Loop Protection Configuration
=====
Loop Protection      : Enable
Transmission Time   : 1 sec
Shutdown Time       : 180 sec

GigabitEthernet 1/1
-----
    Loop protect mode is enabled.
    Actions are both of shutdown and log.

    Transmit mode is enabled.
    No loop.
    The number of loops is 0.
    Status is down.

GigabitEthernet 1/2
-----
    Loop protect mode is enabled.
-- more --, next page: Space, continue: g, quit: ^C    No loop.
```

mac

Mac Address Table information.

SYNTAX

```
show mac address-table [ conf | static | aging-time | { { learning | count } [ interface <port_type>
<port_type_list> ] } | { address <mac_addr> [ vlan <vlan_id> ] } | vlan <vlan_id> | interface <port_type>
<port_type_list> ] [ | {begin | exclude | include } <LINE>]
```

Parameter

| | |
|----------------------|---------------------------------|
| address-table | Mac Address Table |
| conf | User added static mac addresses |
| static | All static mac addresses |

| | |
|-------------------------------|---|
| aging-time | Aging time |
| learning | Learn/disable/secure state |
| count | Total number of mac addresses |
| interface | Select an interface to configure |
| <port_type> | Gigabitethernet |
| * | All switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 |
| address | MAC address lookup |
| <mac_addr> | 48 bit MAC address: xx:xx:xx:xx:xx:xx |
| vlan | VLAN lookup |
| <vlan_id> | VLAN IDs 1-4095 |
| vlan | Addresses in this VLAN |
| <vlan_id> | VLAN IDs 1-4095 |
| interface | Select an interface to configure |
| <port_type> | igabitethernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show mac address-table static
SC60010#
```

mvr

Multicast VLAN Registration configuration.

SYNTAX

```
show mvr [ vlan <vlan_list> | name <word16> ] [ group-database [ interface <port_type> <port_type_list> ]  
[ sfm-information ] ] [ detail ] [ | {begin | exclude | include } <LINE>]
```

Parameter

| | |
|-------------------------------|--|
| vlan | Search by VLAN |
| <vlan_list> | MVR multicast VLAN list |
| name | Search by MVR name |
| <word16> | MVR multicast VLAN name |
| group-database | Multicast group database from MVR |
| interface | Search by port |
| <port_type> | * or Gigabitethernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| sfm-information | Including source filter multicast information from MVR |
| detail | Detail information/statistics of MVR group database |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show mvr vlan 10 detail

MVR is currently disabled, please enable MVR to start group
registration.

% Invalid MVR IGMP VLAN 10.

% Invalid MVR MLD VLAN 10.
```

platform

Platform specific information

SYNTAX

```
show platform phy [ interface ( <port_type> [ <v_port_type_list> ] ) ] [ | {begin | exclude | include } <LINE>]
```

```
show platform phy id [ interface ( <port_type> [ <v_port_type_list> ] ) ] [ | {begin | exclude | include } <LINE>]
```

```
show platform phy instance [ | {begin | exclude | include } <LINE>]
```

```
show platform phy status [ interface ( <port_type> [ <v_port_type_list> ] ) ] [ | {begin | exclude | include } <LINE>]
```

Parameter

| | |
|---------------------|----------------------------------|
| phy | PHYs' information |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show platform phy
Port   API Inst  WAN/LAN/1G Mode   Duplex  Speed  Link
-----
1      Default  1G         PD      -        -      ,No
2      Default  1G         PD      -        -      ,No
3      Default  1G         PD      -        -      ,No
4      Default  1G         PD      -        -      ,Yes
5      Default  1G         PD      -        -      ,No
6      Default  1G         PD      -        -      ,No
7      Default  1G         PD      -        -      ,No
8      Default  1G         PD      -        -      ,No
9      Default  1G         PD      -        -      ,No
10     Default  1G         PD      -        -      ,No
11     Default  1G         PD      -        -      ,No
12     Default  1G         PD      -        -      ,No
```

poe

show poe.

SYNTAX

```
show poe auto-check [ interface ( <port_type> [ <v_port_type_list> ] ) ]
```

```
show poe config [ interface ( <port_type> [ <v_port_type_list> ] ) ]
```

```
show poe power-delay [ interface ( <port_type> [ <v_port_type_list> ] ) ]
```

```
show poe schedule [ interface ( <port_type> [ <v_port_type_list> ] ) ]
```

```
show poe status [ interface ( <port_type> [ <v_port_type_list> ] ) ]
```

Parameter

interface

| Output modifiers

begin Begin with the line that matches

exclude Exclude lines that match

- include** Include lines that match
- <LINE>** String to match output lines

EXAMPLE

```

SC60010# show poe status interface GigabitEthernet 1/1-2
Interface          PD Class  Port Status          Pwr
Req Pwr Alloc Power  Current  Priority
Used
[W] Used[W]  Used[W] Used[mA]
-----
----
-----

GigabitEthernet 1/1  -      PoE turned OFF - PoE disabled      30
0          0.0  0      Low
GigabitEthernet 1/2  -      PoE turned OFF - PoE disabled      30
0          0.0  0      Low

Total Power Request :  60.0 [W]
Total Power Allocated : 0.0 [W]
Total Power Used :    0.0 [W]
Total Current Used :   0 [mA]
SC60010#

```

non-stop-poe

Show Non-Stop PoE Status

SYNTAX

- show non-stop-poe**
- show non-stop-poe** { begin | exclude | include } LINE

Parameter

- |** Output modifiers
- begin** Begin with the line that matches
- exclude** Exclude lines that match

include Include lines that match

LINE String to match output lines

EXAMPLE

```
SC60010# show non-stop-poe
Non-Stop-PoE Status : Enable
SC60010#
```

ntp

show NTP.

SYNTAX

show ntp status

Parameter

status status

EXAMPLE

```
SC60010# show ntp status
NTP Mode : disabled
Idx  Server IP host address (a.b.c.d) or a host name string
---  -----
1
2
3
4
5
SC60010#
```

port-security

SYNTAX

show port-security port [interface <port_type> <port_type_list>] [{begin | exclude | include } <LINE>

show port-security switch [interface <port_type> <port_type_list>] [| {begin | exclude | include } <LINE>

Parameter

port Show MAC Addresses learned by Port Security

switch Show Port Security status.

Interface

<port_type > GigabitEthernet

* All Switches or All ports

Gigabitethernet 1 Gigabit Ethernet Port

<port_type_list> Port list in 1/1-26 for Gigabitethernet

| Output modifiers

begin Begin with the line that matches

exclude Exclude lines that match

include Include lines that match

<LINE> String to match output lines

EXAMPLE

```
SC60010# show port-security port interface GigabitEthernet 1/2
GigabitEthernet 1/2
-----
MAC Address          VID   State      Added          Age/Hold Time
-----
<none>

SC60010#
```

privilege

SYNTAX

show privilege [| {begin | exclude | include } <LINE>

Parameter

| | |
|----------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |

EXAMPLE

```
SC60010# show privilege

-----
| The order is as the input sequence and |
| the last one has the highest priority. |
-----

privilege line level 5 LINE
```

pvlan

PVLAN status.

SYNTAX

```
show pvlan<range_list>
```

```
show pvlan isolation interface <port_type> <port_type_list>
```

Parameter

| | |
|-------------------------------|---|
| <range_list> | PVLAN id to show configuration for |
| isolation | show isolation configuration |
| <port_type > | GigabitEthernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```

SC60010# show pvlan isolation interface GigabitEthernet 1/1-2
Port                               Isolation
-----
GigabitEthernet 1/1                Disabled
GigabitEthernet 1/2                Disabled
SC60010#

```

qos

Quality of Service.

SYNTAX

```

show qos [ { interface [ <port_type> <port_type_list> ] } | wred | { maps [ dscp-cos ] [ dscp-ingress-translation ]
[ dscp-classify ] [ cos-dscp ] [ dscp-egress-translation ] } | storm | { qce [ <Qce : 1-256> ] } ] [ { begin | exclude |
include } <LINE>

```

Parameter

| | |
|-------------------------------|---|
| interface | Interface |
| <port_type > | GigabitEthernet |
| * | All switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| maps | Global QoS Maps/Tables |
| qce | QoS Control Entry |
| storm | Storm policer |

| | |
|---------------------------------|----------------------------------|
| wred | Weighted Random Early Discard |
| cos-dscp | Map for cos to dscp |
| dscp-classify | Map for dscp classify enable |
| dscp-cos | Map for dscp to cos |
| dscp-egress-translation | Map for dscp egress translation |
| dscp-ingress-translation | Map for dscp ingress translation |
| <Qce : 1-256> | QCE ID |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```

SC60010# show qos storm
qos storm:
=====
Unicast : disabled          1
Multicast: disabled        1
Broadcast: disabled        1
SC60010#

```

radius-server

RADIUS configuration.

SYNTAX

```
show radius-server [statistics] [ | {begin | exclude | include } <LINE>
```

Parameter

| | |
|-------------------|-------------------|
| statistics | RADIUS statistics |
| | Output modifiers |

| | |
|---------------------|----------------------------------|
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```

SC60010# show radius-server
Global RADIUS Server Timeout      : 5 seconds
Global RADIUS Server Retransmit   : 3 times
Global RADIUS Server Deadttime    : 0 minutes
Global RADIUS Server Key          :
Global RADIUS Server Attribute 4  :
Global RADIUS Server Attribute 95 :
Global RADIUS Server Attribute 32 :
No hosts configured!
SC60010#

```

rmon

RMON statistics.

SYNTAX

show rmon alarm [<1~65535>] [| {begin | exclude | include } <LINE>

show rmon event [<1~65535>] [| {begin | exclude | include } <LINE>

show rmon history [<1~65535>] [| {begin | exclude | include } <LINE>

show rmon statistics [<1~65535>] [| {begin | exclude | include } <LINE>

Parameter

| | |
|------------------------|---|
| alarm | Display the RMON alarm table |
| event | Display the RMON event table |
| history | Display the RMON history table |
| statistics | Display the RMON statistics table |
| <1~65535> | Alarm/Event/History/Statistics entry list |

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show rmon alarm
SC60010#
```

running-config

Show running system information.

SYNTAX

show running-config [all-defaults] [| {begin | exclude | include } <LINE>

show running-config feature <CWORD> [all-defaults] [| {begin | exclude | include } <LINE>

show running-config interface <port_type> <port_type_list> [all-defaults] [| {begin | exclude | include } <LINE>

show running-config interface vlan <vlan_list> [all-defaults] [| {begin | exclude | include } <LINE>

show running-config line { console | vty } <range_list> [all-defaults] [| {begin | exclude | include } <LINE>

show running-config vlan <vlan_list> [all-defaults] [| {begin | exclude | include } <LINE>

Parameter

all-defaults Include most/all default values

feature Show configuration for specific feature

interface Show specific interface(s)

line Show line settings

vlan VLAN

CWORD Valid words are 'GVRP' 'access' 'access-list'

'aggregation' 'arp-inspection' 'auth' 'clock'

'dhcp' 'dhcp-snooping' 'dns' 'dot1x' 'green-ethernet' 'http' 'icli'

'ip-igmp-snooping' 'ip-igmp-snooping-port'
 'ip-igmp-snooping-vlan' 'ipmc-profile'
 'ipmc-profile-range' 'ipv4' 'ipv6'
 'ipv6-mld-snooping' 'ipv6-mld-snooping-port' 'ipv6-mld-snooping-vlan'
 'lacp' 'lldp' 'logging' 'loop-protect' 'mac' 'mep'
 'monitor' 'mstp' 'mvr' 'mvr-port' 'ntp' 'phy' 'poe' 'port'
 'port-security' 'pvlan' 'qos' 'rmon' 'sflow'
 'snmp' 'source-guard' 'ssh' 'system' 'upnp' 'user'
 'vlan' 'voice-vlan'
 'web-privilege-group-level'

| | |
|-------------------------------|---|
| <port_type > | GigabitEthernet |
| * | All switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| <vlan_list> | List of VLAN numbers |
| console | Console |
| vty | VTY |
| <range_list> | List of console/VTYs |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show running-config interface vlan 3
Building configuration...
end
SC60010#
```

sflow

Statistics flow..

SYNTAX

```
show sflow [ statistics { receiver | samplers [ [ <range_list> ] <port_type> <port_type_list> ] } ] [ | {begin | exclude
| include } <LINE>
```

Parameter

| | |
|-------------------------------|---|
| statistics | sFlow statistics. |
| receiver | Show statistics for receiver. |
| samplers | Show statistics for samplers. |
| <range_list> | runtime, see sflow_icli_functions.c |
| <port_type > | GigabitEthernet |
| * | All switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show sflow

Agent Configuration:
=====

Agent Address: 127.0.0.1

Receiver Configuration:
=====

Owner      : <none>
Receiver   : 0.0.0.0
UDP Port   : 6343
Max. Datagram: 1400 bytes
Time left  : 0 seconds

No enabled collectors (receivers). Skipping displaying per-port info.
SC60010#
```

smtp

Show email information

SYNTAX

show smtp

EXAMPLE

```
SC60010# show smtp
Mail Server      :
User Name       :
Password        :
Sender          :
Return Path     :
Email Address 1 :
Email Address 2 :
Email Address 3 :
Email Address 4 :
Email Address 5 :
Email Address 6 :
SC60010#
```

snmp

Display SNMP configurations.

SYNTAX

show snmp

show snmp access [<GroupName : word32> { v1 | v2c | v3 | any } { auth | noauth | priv }] [{begin | exclude | include } <LINE>

show snmp community v3 [<Community : word127>] [{begin | exclude | include } <LINE>

show snmp host [<ConfName : word32>] [system] [switch] [interface] [aaa] [{begin | exclude | include } <LINE>

show snmp security-to-group [{ v1 | v2c | v3 } <SecurityName : word32>] [{begin | exclude | include } <LINE>

show snmp user [<UserName : word32> <EngineId : word10-32>] [{begin | exclude | include } <LINE>

show snmp view [<ViewName : word32> <OidSubtree : word255>] [{begin | exclude | include } <LINE>

Parameter

access access configuration

<GroupName : word32> Group name

| | |
|--------------------------------------|----------------------------------|
| v1 | v1 security model |
| v2c | v2c security model |
| v3 | v3 security model |
| any | any security model |
| auth | authNoPriv Security Level |
| noauth | noAuthNoPriv Security Level |
| priv | authPriv Security Level |
| community | Community |
| v3 | SNMPv3 |
| <Community : word127> | Specify community name |
| host | Set SNMP host's configurations |
| <ConfName : word32> | Name of the host configuration |
| system | System event group |
| switch | Switch event group |
| interface | Interface event group |
| aaa | AAA event group |
| security-to-group | security-to-group configuration |
| <SecurityName : word32> | security group name |
| user | User |
| <UserName : word32> | Security user name |
| <EngineId : word10-32> | Security Engine ID |
| view | MIB view configuration |
| <ViewName : word32> | MIB view name |
| <OidSubtree : word255> | MIB view OID |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |

include Include lines that match
<LINE> String to match output lines

EXAMPLE

```
SC60010# show snmp
SNMP Configuration
SNMP Mode                                 : enabled
SNMP Version                              : 2c
Read Community                            : public
Write Community                           : private
Trap Mode                                 : disabled
Trap Version                              : 1

SNMPv3 Communities Table:
Community    : public
Source IP    : 0.0.0.0
Source Mask  : 0.0.0.0

Community    : private
Source IP    : 0.0.0.0
Source Mask  : 0.0.0.0

SNMPv3 Users Table:
User Name                                 : default_user
Engine ID                                 : 800007e5017f000001
-- more --, next page: Space, continue: g, quit: ^C
```

spanning-tree

STP Bridge.

SYNTAX

```
show spanning-tree [ summary | active | { interface <port_type> <port_type_list> } | { detailed [ interface  
<port_type> <port_type_list> ] } | { mst [ configuration | { <0-7> [ interface <port_type> <port_type_list> ] } ] } ] ]
```

{begin | exclude | include } <LINE>

Parameter

| | |
|-------------------------------|---|
| summary | STP summary |
| active | STP active interfaces |
| interface | Choose port |
| <port_type> | Gigabitethernet |
| * | All switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| detailed | STP statistics |
| interface | List of port type and port ID, ex, 1/1-26 |
| mst | Configuration |
| configuration | STP bridge instance no (0-7, CIST=0, MST2=1...) |
| <0-7> | Choose port |
| <port_type > | GigabitEthernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show snmp

SNMP Configuration
SNMP Mode           : enabled
SNMP Version        : 2c
Read Community      : public
Write Community     : private
Trap Mode           : disabled
Trap Version        : 1

SNMPv3 Communities Table:
Community   : public
Source IP   : 0.0.0.0
Source Mask : 0.0.0.0

Community   : private
Source IP   : 0.0.0.0
Source Mask : 0.0.0.0

SNMPv3 Users Table:
User Name       : default_user
Engine ID       : 800007e5017f000001
SC60010# show spanning-tree ?
|           Output modifiers
active      STP active interfaces
detailed    STP statistics
interface   Choose port
mst         Configuration
summary     STP summary
<cr>
SC60010# show spanning-tree
CIST Bridge STP Status
Bridge ID    : 32768.00-40-C7-01-02-03
Root ID     : 32768.00-40-C7-01-02-03
Root Port   : -
```

Switch2go-management

Show Switch2go Management information

SYNTAX

```
show switch2go-management> [ mobile-link | options | setting ]
```

Parameter

| | |
|--------------------|---|
| mobile-link | Show Registered Mobile Device List |
| options | Show Port Name Service configuration |
| setting | Show Switch2go Management configuration |

EXAMPLE

```
SC60010# show switch2go-management setting
Switch2go Mode      : Disabled
Server Address      : ipush.cloudapp.net
Server State        :
SC60010#
```

switchport

Display switching mode characteristics.

SYNTAX

```
show switchport forbidden [ { vlan <vlan_id> } | { name <word> } ] [ | {begin | exclude | include } <LINE>
```

Parameter

| | |
|------------------------|--|
| forbidden | Lookup VLAN Forbidden port entry. |
| name | name - Show forbidden access for specific VLAN name. |
| vlan | vid - Show forbidden access for specific VLAN id. |
| <vlan_id> | VLAN id |
| <word> | VLAN name |

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show switchport forbidden
Forbidden VLAN table is empty
SC60010#
```

tacacs-server

TACACS+ configuration.

SYNTAX

show tacacs-server [| {begin | exclude | include } <LINE>

Parameter

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show tacacs-server
Global TACACS+ Server Timeout      : 5 seconds
Global TACACS+ Server Deadtime     : 0 minutes
Global TACACS+ Server Key          :
No hosts configured!
SC60010#
```


system

show system information.

SYNTAX

show system

Parameter

None

EXAMPLE

```
SC60010# show system
Model Name           :
System Description   :
Location            :
Contact             :
System Name         :
System Date         : 2011-01-01T07:54:13+00:00
System Uptime       : 07:54:14
Bootloader Version  : v1.15f
Firmware Version    : v7.10.1049 2017-04-11
Hardware Version    : v1.01
Mechanical Version  :
Serial Number       :
MAC Address         : 00-00-8c-78-91-23
Memory              : Total=52065 KBytes, Free=32998 KBytes,
Max=31857 KBytes
FLASH               : 0x40000000-0x41ffffff, 512 x 0x10000 blocks
Powers status      : Normal
Powers              : PWR_1.0V:0.98V; PWR_3.3V:3.29V;
PWR_2.5V:2.57V; PWR_1.8V:1.87V
Temperature status  : Normal
Temperature 1      : 46(C) ; 114(F)
Temperature 2      : 46(C) ; 114(F)
SC60010#
```

terminal

Display terminal configuration parameters.

SYNTAX

```
show terminal [ | {begin | exclude | include } <LINE>
```

Parameter

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show terminal
Line is con 0.
  * You are at this line now.
  Alive from Console.
  Default privileged level is 2.
  Command line editing is enabled
  Display EXEC banner is enabled.
  Display Day banner is enabled.
  Terminal width is 80.
    length is 24.
    history size is 32.
    exec-timeout is 10 min 0 second.

  Current session privilege is 15.
  Elapsed time is 0 day 0 hour 29 min 24 sec.
  Idle time is 0 day 0 hour 0 min 0 sec.

SC60010#
```

upnp

Display UPnP configurations.

SYNTAX

```
show upnp [ | {begin | exclude | include } <LINE>
```

Parameter

| | |
|---------------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show upnp
UPnP Mode           : Disabled
UPnP TTL            : 4
UPnP Advertising Duration : 100
SC60010#
```

user-privilege

Users privilege configuration

SYNTAX

```
show user-privilege
```

EXAMPLE

```
SC60010# show user-privilege
username admin privilege 15 password none
SC60010#
```

users

Display information about terminal lines.

SYNTAX

```
show users myself [ | {begin | exclude | include } <LINE>
```

Parameter

| | |
|---------------------|----------------------------------|
| myself | Display information about mine |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show user myself
Line is vty 0.
  * You are at this line now.
  Connection is from 192.168.10.119:4123 by Telnet.
  User name is admin.
  Privilege is 15.
  Elapsed time is 0 day 1 hour 33 min 27 sec.
  Idle time is 0 day 0 hour 0 min 0 sec.
```

version

System hardware and software status.

SYNTAX

```
show version [ | {begin | exclude | include } <LINE>
```

Parameter

| | |
|--------------|----------------------------------|
| | Output modifiers |
| begin | Begin with the line that matches |

- exclude** Exclude lines that match
- include** Include lines that match
- <LINE>** String to match output lines

EXAMPLE

```
SC60010# show version

MEMORY          : Total=76031 KBytes, Free=57621 KBytes, Max=56469 KBytes
FLASH           : 0x40000000-0x41ffffff, 512 x 0x10000 blocks
MAC Address     : 80-34-57-13-03-bd
Previous Restart : Cold

System Contact  :
System Name     :
System Location :
System Time     : 2016-09-30T14:52:34+00:00
System Uptime   : 01:43:12

Active Image
-----
Image          : managed
Version       : SC60010 (standalone) v7.04.724
Date          : 2016-08-18T10:11:49+08:00

Alternate Image
-----
Image          : managed.bk
Version       :
Date          :

-----
SID : 1
-----

Chipset ID     : VSC0
Board Type     : SC60010
Port Count     : 26
Product        : Vitesse SC60010 Switch
Software Version : SC60010 (standalone) v6.02
```

vlan

VLAN status.

SYNTAX

```
show vlan [ id <vlan_list> | name <vword32> | brief ]
```

```
show vlan protocol [ eth2 { <0x600-0xffff> | arp | ip | ipx | at } ] [ snap { <0x0-0xfffff> | rfc_1042 | snap_8021h } <0x0-0xffff> ] [ llc <0x0-0xff> <0x0-0xff> ]
```

```
show vlan status [admin [interface] | all | combined | conflicts | gvrp | interface | mstp | mvr | nas | vcl | voice-vlan ] [<port_type ><port_type_list>]
```

Parameter

| | |
|-----------------------------|--------------------------------------|
| id | VLAN status by VLAN id |
| <vlan_list> | VLAN IDs 1-4095 |
| name | VLAN status by VLAN name |
| <vword32> | A VLAN name |
| brief | VLAN summary information |
| protocol | Protocol-based VLAN status |
| eth2 | Ethernet protocol based VLAN status |
| <0x600-0xffff> | Ether Type(Range: 0x600 - 0xFFFF) |
| arp | Ether Type is ARP |
| ip | Ether Type is IP |
| ipx | Ether Type is IPX |
| at | Ether Type is AppleTalk |
| snap | SNAP-based VLAN status |
| <0x0-0xfffff> | SNAP OUI (Range 0x000000 - 0FFFFFFF) |
| rfc_1042 | SNAP OUI is rfc_1042 |
| snap_8021h | SNAP OUI is 8021h |
| <0x0-0xffff> | PID (Range: 0x0 - 0xFFFF) |
| llc | LLC-based VLAN status |

| | |
|-------------------------------|--|
| <0x0-0xff> | DSAP (Range: 0x00 - 0xFF) |
| <0x0-0xff> | SSAP (Range: 0x00 - 0xFF) |
| admin | Show the VLANs configured by administrator. |
| all | Show all VLANs configured. |
| combined | Show the VLANs configured by a combination. |
| conflicts | Show VLANs configurations that has conflicts. |
| gvrp | Show the VLANs configured by GVRP. |
| interface | Show the VLANs configured for a specific interface(s). |
| mstp | Show the VLANs configured by MSTP. |
| mvr | Show the VLANs configured by MVR. |
| nas | Show the VLANs configured by NAS. |
| vcl | Show the VLANs configured by VCL. |
| voice-vlan | Show the VLANs configured by Voice VLAN. |
| interface | Show the VLANs configured for a specific interface(s). |
| <port_type > | GigabitEthernet |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |

EXAMPLE

```

SC60010# show vlan
VLAN  Name                               Interfaces
-----
1     default                               Gi 1/1-26

SC60010#

```

voice

Voice appliance attributes.

SYNTAX

show voice vlan [oui <oui> | interface <port_type> <port_type_list>] [| {begin | exclude | include } <LINE>

Parameter

| | |
|-------------------------------|---|
| vlan | Vlan for voice traffic |
| oui | OUI configuration |
| <oui> | OUI value |
| interface | Select an interface to configure |
| <port_type> | * or Gigabitethernet |
| * | All Switches or All ports |
| Gigabitethernet | 1 Gigabit Ethernet Port |
| <port_type_list> | Port list in 1/1-26 for Gigabitethernet |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show voice vlan
Switch voice vlan is disabled
Switch voice vlan ID is 1000
Switch voice vlan aging-time is 86400 seconds
Switch voice vlan traffic class is 7

Telephony OUI Description
-----
00-01-E3      Siemens AG phones
00-03-6B      Cisco phones
00-0F-E2      H3C phones
00-60-B9      Philips and NEC AG phones
00-D0-1E      Pingtel phones
00-E0-75      Polycom phones
00-E0-BB      3Com phones

Voice VLAN switchport is configured on following:
```

```
GigabitEthernet 1/1 :
-----
GigabitEthernet 1/1 switchport voice vlan mode is disabled
GigabitEthernet 1/1 switchport voice security is disabled
GigabitEthernet 1/1 switchport voice discovery protocol is oui
-- more --, next page: Space, continue: g, quit: ^C
```

web

web.

SYNTAX

```
show web privilege group [ <keyword> ] level [ | {begin | exclude | include } <LINE>
```

Parameter

| | |
|------------------|--|
| privilege | Web privilege |
| group | Web privilege group |
| CWORD | Valid words are 'Aggregation' 'DHCP' 'Debug' 'Dhcp_Client' 'Diagnostics' |

'EEE' 'GARP' 'GVRP' 'Green_Ethernet' 'IP2' 'IPMC_Snooping' 'LACP' 'LLDP'
'Loop_Protect' 'MAC_Table' 'MVR' 'Maintenance'
'Mirroring' 'NTP' 'POE' 'Ports' 'Private_VLANs' 'QoS'
'RPC' 'Security' 'Spanning_Tree' 'System' 'Timer'
'UPnP' 'VCL' 'VLANs' 'Voice_VLAN' 'XXRP' 'sFlow'
'sFlow'

| | |
|---------------------|----------------------------------|
| level | Web privilege group level |
| | Output modifiers |
| begin | Begin with the line that matches |
| exclude | Exclude lines that match |
| include | Include lines that match |
| <LINE> | String to match output lines |

EXAMPLE

```
SC60010# show web privilege group level
Group Name                Privilege Level
                          CRO CRW SRO SRW
-----
ACTIVATE                   5  10  5  10
Aggregation                5  10  5  10
cloud_management           5  10  5  10
Debug                     15  15  15  15
DHCP                       5  10  5  10
Dhcp_Client                5  10  5  10
Diagnostics                5  10  5  10
EEE                        5  10  5  10
GARP                       5  10  5  10
Green_Ethernet             5  10  5  10
GVRP                       5  10  5  10
IP2                        5  10  5  10
IPMC_Snooping              5  10  5  10
LACP                       5  10  5  10
LLDP                       5  10  5  10
Loop_Protect               5  10  5  10
MAC_Table                  5  10  5  10
Maintenance                15  15  15  15
Mirroring                  5  10  5  10
MVR                        5  10  5  10
NTP                        5  10  5  10
POE                        5  10  5  10
Ports                      5  10  1  10
Private_VLANs              5  10  5  10
QoS                        5  10  5  10
RPC                        5  10  5  10
Security                   5  10  5  10
sFlow                      5  10  5  10
Spanning_Tree              5  10  5  10
System                     5  10  1  10
Timer                      5  10  5  10
Trap_Event                 5  10  5  10
```

Set terminal line parameters

Syntax

terminal editing

terminal exec-timeout <0-1440> [<0-3600>]

terminal help

terminal history size <0-32>

terminal length <0 or 3-512>

terminal width <0 or 40-512>

Parameter

| | |
|----------------------------|---|
| editing | Enable command line editing |
| exec-timeout | Set the EXEC timeout |
| help | Description of the interactive help system |
| history | Control the command history function |
| length | Set number of lines on a screen |
| width | Set width of the display terminal |
| <0-1440> | Timeout in minutes |
| <0-3600> | Timeout in seconds |
| size | Set history buffer size |
| <0-32> | Number of history commands, 0 means disable |
| <0 or 3-512> | Number of lines on screen (0 for no pausing) |
| <0 or 40-512> | Number of characters on a screen line (0 for unlimited width) |

EXAMPLE

```
SC60010# terminal help
```

```
Help may be requested at any point in a command by entering a question mark '?'. If nothing matches, the help list will be empty and you must backup until entering a '?' shows the available options.
```

```
Two styles of help are provided:
```

1. Full help is available when you are ready to enter a command argument (e.g. 'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you want to know what arguments match the input (e.g. 'show pr?'.)

```
SC60010#
```

Copy from source to destination

SYNTAX

```
traceroute ip <v_ip_addr> [ protocol { icmp | udp | tcp } ] [ wait <v_wait_time> ] [ ttl <v_max_ttl> ] [ nqueries <v_nqueries> ]
```

Parameter

| | |
|--------------------------|--|
| ip | IP |
| <word1-255> | destination address |
| nqueries | Specify number of probe packets |
| protocol | Specify protocol including icmp, udp and tcp |
| ttl | Specify max TTL |
| wait | Specify wait time |

EXAMPLE

```
SC60010# traceroute ip 22 nqueries 3 protocol icmp ttl 3 wait 3
traceroute to 22 (0.0.0.22), 3 hops max, 140 byte packets
 1 * * *
 2 * * *
 3 * * *
SC60010#
```

This chapter introduces the CLI privilege level and command modes.

- The privilege level determines whether or not the user could run the particular commands
- If the user could run the particular command, then the user has to run the command in the correct mode.

29-1 Privilege level

Every command has a privilege level (0-15). Users can run a command if the session's privilege level is greater than or equal to the command's privilege level. The session's privilege level initially comes from the login account's privilege level, though it is possible to change the session's privilege level after logging in.

| PRIVILEGE LEVEL | TYPES OF COMMANDS AT THIS PRIVILEGE LEVEL |
|-----------------|--|
| 0 | Display basic system information |
| 13 | Configure features except for login accounts, the authentication method sequence, multiple logins, and administrator and enable passwords. |
| 15 | Configure login accounts, the authentication method sequence, multiple logins, and administrator and enable passwords. |

29-2 Command modes

The CLI is divided into several modes. If a user has enough privilege to run a particular command, the user has to run the command in the correct mode. The modes that are available depend on the session's privilege level.

Command Summary

| COMMAND | DESCRIPTION | P | M |
|--|---|----|---------------------|
| show access management | Use the show access management user EXEC command without keywords to display the access management configuration, or use the statistics keyword to display statistics, or use the <AccessId> keyword to display the specific access management entry. | 15 | EXEC |
| clear access management statistics | Use the clear access management statistics privileged EXEC command to clear the statistics maintained by access management. | 15 | EXEC |
| access management | Use the access management global configuration command to enable the access management. Use the no form of this command to disable the access management. | 15 | GLOBAL_CONFIG |
| access management <1-16> <1-4094> <ipv4_addr> [to <ipv4_addr>] { [web] [snmp] [telnet] all } | Use the access management <AccessId> global configuration command to set the access management entry for IPv4 address. | 15 | GLOBAL_CONFIG |
| access management <1-16> <1-4094> <ipv6_addr> [to <ipv6_addr>] { [web] [snmp] [telnet] all } | Use the access management <AccessId> global configuration command to set the access management entry for IPv6 address. | 15 | GLOBAL_CONFIG |
| no access management <1~16> | Use the no access management <AccessIdList> global configuration command to delete the specific access management entry. | 15 | GLOBAL_CONFIG |
| access-list action { permit deny } | Use the access-list action interface configuration command to configure access-list action. The access-list interface configuration will affect the | 15 | INTERFACE_PORT_LIST |

| | | | |
|--|---|----|---------------------|
| | received frames if it doesn't match any ACE. | | |
| access-list rate-limiter <1-16> | Use the access-list rate-limiter interface configuration command to configure the access-list rate-limiter ID . The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| no access-list rate-limiter | Use the no access-list rate-limiter interface configuration command to disable the access-list rate-limiter. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| access-list { redirect port-copy } interface { <port_type_id> <port_type_list> } | Use the no access-list redirect interface configuration command to configure the access-list redirect interface. | 15 | INTERFACE_PORT_LIST |
| no access-list { redirect port-copy } | Use the no access-list redirect interface configuration command to disable the access-list redirect. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| access-list mirror | Use the access-list mirror interface configuration command to enable access-list mirror. Use the no form of this command to disable access-list mirror. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| access-list logging | Use the access-list logging interface configuration command to enable access-list logging. Use the no form of this command to disable access-list logging. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| access-list shutdown | Use the access-list shutdown interface configuration command to enable | 15 | INTERFACE_PORT_LIST |

| | | | |
|--|--|----|---------------------|
| | access-list shutdown. Use the no form of this command to disable access-list shutdown. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | | |
| access-list evc-policer <1-256> | Use the access-list evc-policer interface configuration command to configure the access-list evc-policer ID. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| no access-list evc-policer | Use the no access-list evc-policer interface configuration command to configure the access-list evc-policer ID. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| access-list policy <0-255> | Use the access-list policy interface configuration command to configure the access-list policy value. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| no access-list policy | Use the no access-list policy interface configuration command to restore the default access-list policy ID. The access-list interface configuration will affect the received frames if it doesn't match any ACE. | 15 | INTERFACE_PORT_LIST |
| access-list port-state | Use the access-list port-state interface configuration command to enable access-list port state. Use the no form of this command to disable access-list port state. | 15 | INTERFACE_PORT_LIST |
| access-list rate-limiter [<1~16>] { pps <1,2,4,8,16,32,64,128,256,512> 100pps <1-32767> kpps <1,2,4,8,16,32,64,128,256,512,1024> 100kbps <0-10000> } | Use the access-list rate-limiter global configuration command to configure the access-list rate-limiter. | 15 | INTERFACE_PORT_LIST |

| | | | |
|--|--|-----------|----------------------|
| <p>default access-list rate-limiter [<1~16>]</p> | <p>Use the default access-list rate-limiter global configuration command to restore the default setting of access-list rate-limiter.</p> | <p>15</p> | <p>GLOBAL_CONFIG</p> |
| <p>access-list ace [update] <1-256> [next {<1-256> last}] [ingress {switch <switch_id> switchport {<1-53> <1~53>}} interface {<port_type_id> <port_type_list>}} any]] [policy <0-255> [policy-bitmask <0x0-0xFF>]] [tag {tagged untagged any}}] [vid {<1-4095> any}}] [tag-priority {<0-7> 0-1 2-3 4-5 6-7 0-3 4-7 any}}] [dmac-type {unicast multicast broadcast any}}] [frametype { any etype [etype-value {<0x600-0x7ff,0x801-0x805,0x807-0x86dc,0x86de-0xffff> any}}] [smac {<mac_addr> any}}] [dmac {<mac_addr> any}}] arp [sip {<ipv4_subnet> any}}] [dip {<ipv4_subnet> any}}] [smac {<mac_addr> any}}] [arp-opcode {arp rarp other any}}] [arp-flag [arp-request {<0-1> any}}] [arp-smac {<0-1> any}}] [arp-tmac {<0-1> any}}] [arp-len {<0-1> any}}] [arp-ip {<0-1> any}}] [arp-ether {<0-1> any}}]] ipv4 [sip {<ipv4_subnet> any}}] [dip {<ipv4_subnet> any}}] [ip-protocol {<0,2-5,7-16,18-255> any}}] [ip-flag [ip-ttl {<0-1> any}}] [ip-options {<0-1> any}}] [ip-fragment {<0-1> any}}]] ipv4-icmp [sip {<ipv4_subnet> any}}] [dip {<ipv4_subnet> any}}] [icmp-type {<0-255> any}}] [icmp-code {<0-255> any}}] [ip-flag [ip-ttl {<0-1> any}}] [ip-options {<0-1> any}}] [ip-fragment {<0-1> any}}]] ipv4-udp [sip {<ipv4_subnet> any}}] [dip {<ipv4_subnet> any}}] [sport {<0-65535> [to <0-65535>] any}}] [dport {<0-65535> [to <0-65535>] any}}] [ip-flag [ip-ttl {<0-1> any}}] [ip-options {<0-1> any}}] [ip-fragment {<0-1> any}}]] ipv4-tcp [sip {<ipv4_subnet> any}}] [dip {<ipv4_subnet> any}}] [sport {<0-65535> [to <0-65535>] any}}] [dport {<0-65535> [to <0-65535>] any}}] [ip-flag [ip-ttl {<0-1> any}}] [ip-options {<0-1> any}}] [ip-fragment {<0-1> any}}]]</p> | <p>Use the access-list ace global configuration command to set the access-list ace. The command without the update keyword will creates or overwrites an existing ACE, any unspecified parameter will be set to its default value. Use the update keyword to update an existing ACE and only specified parameter are modified. The ACE must ordered by an appropriate sequence, the received frame will only be hit on the first matched ACE. Use the next or last keyword to adjust the ACE's sequence order.</p> | <p>15</p> | <p>GLOBAL_CONFIG</p> |

| | | | |
|--|---|----|---------------|
| <pre>[tcp-flag [tcp-fin {<0-1> any}] [tcp-syn {<0-1> any}] [tcp-rst {<0-1> any}] [tcp-psh {<0-1> any}] [tcp-ack {<0-1> any}] [tcp-urg {<0-1> any}]] ipv6 [next- header {<0-5,7-16,18-57,59-255> any}] [sip {<ipv6_addr> [sip-bitmask <uint>] any}] [hop-limit {<0-1> any}] ipv6-icmp [sip {<ipv6_addr> [sip- bitmask <uint>] any}] [icmp-type {<0-255> any}] [icmp-code {<0-255> any}] [hop-limit {<0-1> any}] ipv6-udp [sip {<ipv6_addr> [sip-bitmask <uint>] any}] [sport {<0-65535> [to <0- 65535>] any}] [dport {<0-65535> [to <0- 65535>] any}] [hop-limit {<0-1> any}] ipv6-tcp [sip {<ipv6_addr> [sip-bitmask <uint>] any}] [sport {<0- 65535> [to <0-65535>] any}] [dport {<0-65535> [to <0-65535>] any}] [hop-limit {<0-1> any}] [tcp-flag [tcp-fin {<0-1> any}] [tcp-syn {<0-1> any}] [tcp-rst {<0-1> any}] [tcp-psh {<0-1> any}] [tcp-ack {<0- 1> any}] [tcp-urg {<0-1> any}]]] [action {permit deny filter {switchport <1~53> interface <port_type_list>}}] [rate-limiter {<1-16> disable}] [evc-policer {<1-256> disable}] [{redirect port- copy} {switchport {<1-53> <1~53>} interface {<port_type_id> <port_type_list>} disable}] [mirror [disable]] [logging [disable]] [shutdown [disable]] [lookup [disable]]</pre> | | | |
| <pre>no access-list ace <1~256></pre> | <p>Use the no access-list ace global configuration command to delete the access-list ace.</p> | 15 | GLOBAL_CONFIG |
| <pre>show access-list [interface [<port_type_list>]] [rate-limiter [<1~16>]] [ace statistics [<1~256>]]</pre> | <p>Use the show access-list privilege EXEC command without keywords to display the access-list configuration, or particularly the show access-list interface for the access-list interface configuration, or use the rate-limiter keyword to display access-list rate-limiter configuration, or use the ace keyword to display access-list ace configuration.</p> | 15 | EXEC |
| <pre>clear access-list ace statistics</pre> | <p>Use the clear access-list ace statistics</p> | 15 | EXEC |

| | | | |
|---|--|----|---------------------|
| | privileged EXEC command to clear the statistics maintained by access-list, including access-list interface statistics and ACE's statistics. | | |
| show access-list ace-status [static] [link-oam] [loop-protect] [dhcp] [ptp] [upnp] [arp-inspection] [mep] [ipmc] [ip-source-guard] [ip-mgmt] [conflicts] [switch <switch_list>] | Use the show access-list ace-status privilege EXEC command without keywords to display the access-list ace status for all access-list users, or particularly the access-list user for the access-list ace status. Use conflicts keyword to display the access-list ace that doesn't apply on on the hardware. In other word, it means the specific ACE is not applied to the hardware due to hardware limitations. | 15 | EXEC |
| show aggregation [mode] | | 15 | EXEC |
| aggregation mode { [smac] [dmac] [ip] [port] } | | 15 | GLOBAL_CONFIG |
| no aggregation mode | | 15 | GLOBAL_CONFIG |
| aggregation group <uint> | | 15 | INTERFACE_PORT_LIST |
| no aggregation group | | 15 | INTERFACE_PORT_LIST |
| ip arp inspection | Use the ip arp inspection global configuration command to globally enable ARP inspection. Use the no form of this command to globally disable ARP inspection. | 13 | GLOBAL_CONFIG |
| ip arp inspection vlan <vlan_list> | Use the ip arp inspection global configuration command to globally enable ARP inspection. Use the no form of this command to globally disable ARP inspection. | 13 | GLOBAL_CONFIG |
| ip arp inspection vlan <vlan_list> logging { deny permit all } | | 13 | GLOBAL_CONFIG |
| no ip arp inspection vlan <vlan_list> logging | | 13 | GLOBAL_CONFIG |
| ip arp inspection entry interface <port_type_id> <vlan_id> <mac_ucast> <ipv4_ucast> | | 13 | GLOBAL_CONFIG |
| arp_inspection_translate | | 13 | GLOBAL_CONFIG |
| arp_inspection_port_mode | Use the ip arp inspection trust interface configuration command to configure a port as trusted for ARP inspection | 13 | INTERFACE_PORT_LIST |

| | | | |
|--|--|----|---------------------|
| | purposes. Use the no form of this command to configure a port as untrusted. | | |
| arp_inspection_port_check_vlan | Use the ip arp inspection check-vlan interface configuration command to configure a port as VLAN mode for ARP inspection purposes. Use the no form of this command to configure a port as default. | 13 | INTERFACE_PORT_LIST |
| ip arp inspection logging { deny permit all } | Use the ip arp inspection logging interface configuration command to configure a port as some logging mode for ARP inspection purposes. Use the no form of this command to configure a port as logging none. | 13 | INTERFACE_PORT_LIST |
| no ip arp inspection logging | Use the no ip arp inspection logging interface configuration command to configure a port as default logging mode for ARP inspection purposes. | 13 | INTERFACE_PORT_LIST |
| show ip arp inspection [interface <port_type_list> vlan <vlan_list>] | | 0 | EXEC |
| show ip arp inspection entry [dhcp-snooping static] [interface <port_type_list>] | | 13 | EXEC |
| aaa authentication login { console telnet ssh http } { [local radius tacacs] ... } | Use the aaa authentication login command to configure the authentication methods. | 15 | GLOBAL_CONFIG |
| no aaa authentication login { console telnet ssh http } | | 15 | GLOBAL_CONFIG |
| radius-server timeout <1-1000> | Use the radius-server timeout command to configure the global RADIUS timeout value. | 15 | GLOBAL_CONFIG |
| no radius-server timeout | Use the no radius-server timeout command to reset the global RADIUS timeout value to default. | 15 | GLOBAL_CONFIG |
| radius-server retransmit <1-1000> | Use the radius-server retransmit command to configure the global RADIUS retransmit value. | 15 | GLOBAL_CONFIG |
| no radius-server retransmit | Use the no radius-server retransmit command to reset the global RADIUS | 15 | GLOBAL_CONFIG |

| | | | |
|--|--|----|---------------|
| | retransmit value to default. | | |
| radius-server deadtime <1-1440> | Use the radius-server deadtime command to configure the global RADIUS deadtime value. | 15 | GLOBAL_CONFIG |
| no radius-server deadtime | Use the no radius-server deadtime command to reset the global RADIUS deadtime value to default. | 15 | GLOBAL_CONFIG |
| radius-server key <line1-63> | Use the radius-server key command to configure the global RADIUS key. | 15 | GLOBAL_CONFIG |
| no radius-server key | Use the no radius-server key command to remove the global RADIUS key. | 15 | GLOBAL_CONFIG |
| radius-server attribute 4 <ipv4_ucast> | | 15 | GLOBAL_CONFIG |
| no radius-server attribute 4 | | 15 | GLOBAL_CONFIG |
| radius-server attribute 95 <ipv6_ucast> | | 15 | GLOBAL_CONFIG |
| no radius-server attribute 95 | | 15 | GLOBAL_CONFIG |
| radius-server attribute 32 <line1-253> | | 15 | GLOBAL_CONFIG |
| no radius-server attribute 32 | | 15 | GLOBAL_CONFIG |
| radius-server host <word1-255> [auth-port <0-65535>] [acct-port <0-65535>] [timeout <1-1000>] [retransmit <1-1000>] [key <line1-63>] | Use the radius-server host command to add a new RADIUS host. | 15 | GLOBAL_CONFIG |
| no radius-server host <word1-255> [auth-port <0-65535>] [acct-port <0-65535>] | Use the no radius-server host command to delete an existing RADIUS host. | 15 | GLOBAL_CONFIG |
| tacacs-server timeout <1-1000> | Use the tacacs-server timeout command to configure the global TACACS+ timeout value. | 15 | GLOBAL_CONFIG |
| no tacacs-server timeout | Use the no tacacs-server timeout command to reset the global TACACS+ timeout value to default. | 15 | GLOBAL_CONFIG |
| tacacs-server deadtime <1-1440> | Use the tacacs-server deadtime command to configure the global TACACS+ deadtime value. | 15 | GLOBAL_CONFIG |
| no tacacs-server deadtime | Use the no tacacs-server deadtime command to reset the global TACACS+ deadtime value to default. | 15 | GLOBAL_CONFIG |
| tacacs-server key <line1-63> | Use the tacacs-server key command to configure the global TACACS+ key. | 15 | GLOBAL_CONFIG |
| no tacacs-server key | Use the no tacacs-server key command to remove the global TACACS+ key. | 15 | GLOBAL_CONFIG |
| tacacs-server host <word1-255> [port <0- | Use the tacacs-server host command to | 15 | GLOBAL_CONFIG |

| | | | |
|--|--|-------|---------------|
| 65535>] [timeout <1-1000>] [key <line1-63>] | add a new TACACS+ host. | | |
| no tacacs-server host <word1-255> [port <0-65535>] | Use the no tacacs-server host command to delete an existing TACACS+ host. | 15 | GLOBAL_CONFIG |
| show aaa | Use the show aaa command to view the currently active authentication login methods. | 15 | GLOBAL_CONFIG |
| show radius-server [statistics] | Use the show radius-server command to view the current RADIUS configuration and statistics. | 15 | EXEC |
| show tacacs-server | Use the show tacacs-server command to view the current TACACS+ configuration. | 15 | EXEC |
| debug auth { console telnet ssh http } <word31> [<word31>] | | debug | EXEC |
| clock summer-time <word16> recurring [<1-5> <1-7> <1-12> <hhmm> <1-5> <1-7> <1-12> <hhmm> [<1-1440>]] | | 13 | GLOBAL_CONFIG |
| clock summer-time <word16> date [<1-12> <1-31> <2000-2097> <hhmm> <1-12> <1-31> <2000-2097> <hhmm> [<1-1440>]] | | 13 | GLOBAL_CONFIG |
| no clock summer-time | | 13 | GLOBAL_CONFIG |
| clock timezone <word16> <-23-23> [<0-59>] | | 13 | GLOBAL_CONFIG |
| no clock timezone | | 13 | GLOBAL_CONFIG |
| show clock detail | | 0 | EXEC |
| clock summer-time <word16> recurring [<1-5> <1-7> <1-12> <hhmm> <1-5> <1-7> <1-12> <hhmm> [<1-1440>]] | | 13 | GLOBAL_CONFIG |
| clock summer-time <word16> date [<1-12> <1-31> <2000-2097> <hhmm> <1-12> <1-31> <2000-2097> <hhmm> [<1-1440>]] | | 13 | GLOBAL_CONFIG |
| no clock summer-time | | 13 | GLOBAL_CONFIG |
| clock timezone <word16> <-23-23> [<0-59>] | | 13 | GLOBAL_CONFIG |
| no clock timezone | | 13 | GLOBAL_CONFIG |
| show clock detail | | 0 | EXEC |
| show ip dhcp detailed statistics { server client snooping relay normal-forward combined } [interface <port_type_list>] | Use the show ip dhcp detailed statistics user EXEC command to display statistics. Notice that the normal forward per-port TX statistics isn't increased if | 0 | EXEC |

| | | | |
|--|---|----|---------------|
| | the incoming DHCP packet is done by L3 forwarding mechanism. Notice that the normal forward per-port TX statistics isn't increased if the incoming DHCP packet is done by L3 forwarding mechanism. | | |
| clear ip dhcp detailed statistics { server client snooping relay helper all } [interface <port_type_list>] | Use the clear ip dhcp detailed statistics privileged EXEC command to clear the statistics, or particularly the IP DHCP statistics for the interface. Notice that except for clear statistics on all interfaces, clear the statistics on specific port may not take effect on global statistics since it gathers the different layer overview. | 15 | EXEC |
| clear ip dhcp relay statistics | Use the clear ip dhcp relay statistics privileged EXEC command to clear the statistics maintained by IP DHCP relay. | 15 | EXEC |
| show ip dhcp relay [statistics] | Use the show ip dhcp relay user EXEC command without keywords to display the DHCP relay configuration, or use the statistics keyword to display statistics. | 0 | EXEC |
| ip dhcp relay | Use the ip dhcp relay global configuration command to enable the DHCP relay server. Use the no form of this command to disable the DHCP relay server. | 15 | GLOBAL_CONFIG |
| ip helper-address <ipv4_ucast> | Use the ip helper-address global configuration command to configure the host address of DHCP relay server. | 15 | GLOBAL_CONFIG |
| no ip helper-address | Use the no ip helper-address global configuration command to clear the host address of DHCP relay server. | 15 | GLOBAL_CONFIG |
| ip dhcp relay information option | Use the ip dhcp relay information option global configuration command to enable the DHCP relay information option. Use the no form of this command to disable the DHCP relay information option. The | 15 | GLOBAL_CONFIG |

| | | | |
|---|---|-------|---------------|
| | option 82 circuit ID format as "[vlan_id][module_id][port_no]". The first four characters represent the VLAN ID, the fifth and sixth characters are the module ID(in standalone device it always equal 0), and the last two characters are the port number. For example, "00030108" means the DHCP message receive form VLAN ID 3, switch ID 1, port No 8. And the option 82 remote ID value is equal the switch MAC address. | | |
| ip dhcp relay information policy { drop keep replace } | Use the ip dhcp relay information policy global configuration command to configure the DHCP relay information policy. When DHCP relay information mode operation is enabled, if the agent receives a DHCP message that already contains relay agent information it will enforce the policy. The 'Replace' policy is invalid when relay information mode is disabled. | 15 | GLOBAL_CONFIG |
| no ip dhcp relay information policy | Use the ip dhcp relay information policy global configuration command to restore the default DHCP relay information policy. | 15 | GLOBAL_CONFIG |
| show ip dhcp pool [<word32>] | | 0 | EXEC |
| show ip dhcp pool counter [<word32>] | | debug | EXEC |
| show ip dhcp excluded-address | | 0 | EXEC |
| show ip dhcp server binding [state {allocated committed expired}] [type {automatic manual expired}] | | 0 | EXEC |
| show ip dhcp server binding <ipv4_ucast> | | 0 | EXEC |
| show ip dhcp server | | 0 | EXEC |
| show ip dhcp server statistics | | 0 | EXEC |
| show ip dhcp server declined-ip | | 0 | EXEC |
| show ip dhcp server declined-ip <ipv4_addr> | | 0 | EXEC |
| clear ip dhcp server binding <ipv4_ucast> | | 13 | EXEC |
| clear ip dhcp server binding { automatic manual | | 13 | EXEC |

| | | | |
|--|--|----|----------------|
| expired } | | | |
| clear ip dhcp server statistics | | 13 | EXEC |
| ip dhcp server | | 13 | GLOBAL_CONFIG |
| ip dhcp excluded-address <ipv4_addr> [<ipv4_addr>] | | 13 | GLOBAL_CONFIG |
| no ip dhcp pool <word32> | | 13 | GLOBAL_CONFIG |
| ip dhcp server | | 13 | INTERFACE_VLAN |
| network <ipv4_addr> <ipv4_netmask> | | 13 | DHCP_POOL |
| no network | | 13 | DHCP_POOL |
| broadcast <ipv4_addr> | | 13 | DHCP_POOL |
| no broadcast | | 13 | DHCP_POOL |
| default-router <ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast>]]] | | 13 | DHCP_POOL |
| no default-router | | 13 | DHCP_POOL |
| lease { <0-365> [<0-23> [<uint>]] infinite } | | 13 | DHCP_POOL |
| no lease | | 13 | DHCP_POOL |
| domain-name <word128> | | 13 | DHCP_POOL |
| no domain-name | | 13 | DHCP_POOL |
| dns-server <ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast>]]] | | 13 | DHCP_POOL |
| no dns-server | | 13 | DHCP_POOL |
| ntp-server <ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast>]]] | | 13 | DHCP_POOL |
| no ntp-server | | 13 | DHCP_POOL |
| netbios-name-server <ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast>]]] | | 13 | DHCP_POOL |
| no netbios-name-server | | 13 | DHCP_POOL |
| netbios-node-type { b-node h-node m-node p- node } | | 13 | DHCP_POOL |
| no netbios-node-type | | 13 | DHCP_POOL |
| netbios-scope <line128> | | 13 | DHCP_POOL |
| no netbios-scope | | 13 | DHCP_POOL |
| nis-domain-name <word128> | | 13 | DHCP_POOL |
| no nis-domain-name | | 13 | DHCP_POOL |
| nis-server <ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast> [<ipv4_ucast>]]] | | 13 | DHCP_POOL |
| no nis-server | | 13 | DHCP_POOL |
| host <ipv4_ucast> <ipv4_netmask> | | 13 | DHCP_POOL |

| | | | |
|---|--|-------|---------------------|
| no host | | 13 | DHCP_POOL |
| client-identifier { fqdn <line128> mac-address <mac_addr> } | | 13 | DHCP_POOL |
| no client-identifier | | 13 | DHCP_POOL |
| hardware-address <mac_ucast> | | 13 | DHCP_POOL |
| no hardware-address | | 13 | DHCP_POOL |
| client-name <word32> | | 13 | DHCP_POOL |
| no client-name | | 13 | DHCP_POOL |
| vendor class-identifier <string64> specific-info <hexval32> | | 13 | DHCP_POOL |
| no vendor class-identifier <string64> | | 13 | DHCP_POOL |
| debug dhcp server memsize | | debug | EXEC |
| debug dhcp server declined add <ipv4_addr> | | debug | EXEC |
| debug dhcp server declined delete <ipv4_addr> | | debug | EXEC |
| show ip dhcp snooping [interface <port_type_list>] | Use the show ip dhcp snooping user EXEC command to display the DHCP snooping configuration. | 0 | EXEC |
| show ip dhcp snooping [statistics] [interface <port_type_list>] | Use the show ip dhcp snooping user EXEC command without keywords to display the DHCP snooping configuration, or particularly the ip dhcp snooping statistics for the interface, or use the statistics keyword to display statistics. | 0 | EXEC |
| clear ip dhcp snooping statistics [interface <port_type_list>] | Use the clear ip dhcp snooping statistics privileged EXEC command to clear the statistics maintained by IP DHCP snooping, or particularly the IP DHCP snooping statistics for the interface. | 15 | EXEC |
| ip dhcp snooping | Use the ip dhcp snooping global configuration command to globally enable DHCP snooping. Use the no form of this command to globally disable DHCP snooping. | 15 | GLOBAL_CONFIG |
| dhcp_snooping_port_mode | Use the ip dhcp snooping trust interface configuration command to configure a port as trusted for DHCP snooping purposes. Use the no form of this | 15 | INTERFACE_PORT_LIST |

| | | | |
|---|--|----|---------------|
| | command to configure a port as untrusted. | | |
| show ip dhcp snooping table | Use the show ip dhcp snooping table user EXEC command to display the IP assigned information that is obtained from DHCP server except for local VLAN interface IP addresses. | 15 | EXEC |
| ip name-server { <ipv4_ucast> dhcp [interface vlan <vlan_id>] } | Set the DNS server for resolving domain names | 15 | GLOBAL_CONFIG |
| no ip name-server | Stop resolving domain names by accessing DNS server | 15 | GLOBAL_CONFIG |
| show ip name-server | Display the active domain name server information | 0 | EXEC |
| ip dns proxy | Enable DNS proxy service | 15 | GLOBAL_CONFIG |
| show version | Use show version to display firmware information. | 0 | EXEC |
| firmware upgrade <word> | Use firmware upgrade to load new firmware image to the switch. | 15 | EXEC |
| firmware swap | Use firmware swap to swap the active and alternative firmware images. | 15 | EXEC |
| show green-ethernet fan | Shows Fan status (chip Temperature and fan speed). | 15 | GLOBAL_CONFIG |
| green-ethernet fan temp-on <-127-127> | Sets temperature at which to turn fan on to the lowest speed. | 15 | GLOBAL_CONFIG |
| no green-ethernet fan temp-on | Sets temperature at which to turn fan on to the lowest speed to default. | 15 | GLOBAL_CONFIG |
| green-ethernet fan temp-max <-127-127> | Sets temperature where the fan must be running at full speed. | 15 | GLOBAL_CONFIG |
| no green-ethernet fan temp-max | Sets temperature at which the fan shall be running at full speed to default. | 15 | GLOBAL_CONFIG |
| green-ethernet led interval <0~24> intensity <0-100> | Use green-ethernet led interval to configure the LED intensity at specific interval of the day. | 15 | GLOBAL_CONFIG |
| no green-ethernet led interval <0~24> | | 15 | GLOBAL_CONFIG |
| green-ethernet led on-event { [link-change <0-65535>] [error] }*1 | Use green-ethernet led on-event to configure when to turn LEDs intensity to 100%%. | 15 | GLOBAL_CONFIG |
| no green-ethernet led on-event [link-change] [error] | | 15 | GLOBAL_CONFIG |

| | | | |
|--|--|----|---------------------|
| show green-ethernet eee [interface <port_type_list>] | Shows Green Ethernet EEE status. | 15 | EXEC |
| show green-ethernet short-reach [interface <port_type_list>] | Shows Green Ethernet short-reach status. | 15 | EXEC |
| show green-ethernet energy-detect [interface <port_type_list>] | Shows Green Ethernet energy-detect status. | 15 | EXEC |
| show green-ethernet [interface <port_type_list>] | Shows Green Ethernet status. | 15 | EXEC |
| green-ethernet eee | Sets EEE mode. | 15 | INTERFACE_PORT_LIST |
| green-ethernet eee urgent-queues [<range_list>] | Sets EEE urgent queues. | 15 | INTERFACE_PORT_LIST |
| green-ethernet eee optimize-for-power | Sets if EEE should be optimized for least traffic latency or least power consumption | 15 | GLOBAL_CONFIG |
| green-ethernet energy-detect | Enables energy-detect power savings. | 15 | INTERFACE_PORT_LIST |
| green-ethernet short-reach | Enables short-reach power savings. | 15 | INTERFACE_PORT_LIST |
| show ip http server secure status | Use the show ip http server secure status privileged EXEC command to display the secure HTTP web server status. | 15 | EXEC |
| ip http secure-server | Use the ip http secure-server global configuration command to enable the secure HTTP web server. Use the no form of this command to disable the secure HTTP web server. | 15 | GLOBAL_CONFIG |
| ip http secure-redirect | Use the http secure-redirect global configuration command to enable the secure HTTP web redirection. When the secure HTTP web server is enabled, the feature automatic redirect the none secure HTTP web connection to the secure HTTP web connection. Use the no form of this command to disable the secure HTTP web redirection. | 15 | GLOBAL_CONFIG |
| reload { { { cold warm } [sid <1-16>] } { defaults [keep-ip] } } | Reload system, either cold (reboot) or restore defaults without reboot. | 15 | EXEC |
| show running-config [all-defaults] | | 15 | EXEC |
| show running-config feature <word> [all-defaults] | | 15 | EXEC |
| show running-config interface <port_type_list> [all-defaults] | | 15 | EXEC |

| | | | |
|---|-----------------------------------|-------|----------------|
| show running-config interface vlan <vlan_list> [all-defaults] | | 15 | EXEC |
| show running-config vlan <vlan_list> [all- defaults] | | 15 | EXEC |
| show running-config line { console vty } <range_list> [all-defaults] | | 15 | EXEC |
| copy { startup-config running-config <word> } { startup-config running-config <word> } [syntax-check] | | 15 | EXEC |
| dir | | 15 | EXEC |
| more <word> | | 15 | EXEC |
| delete <word> | | debug | EXEC |
| debug icfg wipe-flash-fs-conf-block | | debug | EXEC |
| debug icfg wipe-specific-block {local global} <uint> | | debug | EXEC |
| debug icfg silent-upgrade status | | debug | EXEC |
| debug icfg dir | | debug | EXEC |
| debug icfg error-trace <line> | | debug | EXEC |
| ip routing | Enable routing for IPv4 and IPv6 | 15 | GLOBAL_CONFIG |
| no ip routing | Disable routing for IPv4 and IPv6 | 15 | GLOBAL_CONFIG |
| ip address {{<ipv4_addr> <ipv4_netmask>} {dhcp [fallback <ipv4_addr> <ipv4_netmask> [timeout <uint>]]}} | IP address configuration | 15 | INTERFACE_VLAN |
| ip dhcp retry interface vlan <vlan_id> | Restart the dhcp client | 15 | EXEC |
| no ip address | IP address configuration | 15 | INTERFACE_VLAN |
| ip route <ipv4_addr> <ipv4_netmask> <ipv4_addr> | Add new IP route | 15 | GLOBAL_CONFIG |
| no ip route <ipv4_addr> <ipv4_netmask> <ipv4_addr> | Delete an existing IP route | 15 | GLOBAL_CONFIG |
| show interface vlan [<vlan_list>] | Vlan interface status | 15 | EXEC |
| show ip interface brief | Brief IP interface status | 0 | EXEC |
| show ip arp | Print ARP table | 0 | EXEC |
| clear ip arp | Clear ARP cache | 0 | EXEC |
| show ip route | Routing table status | 0 | EXEC |
| ping ip <word1-255> [repeat <1-60>] [size <2- 1452>] [interval <0-30>] | | 0 | EXEC |
| clear ip statistics [system] [interface vlan <vlan_list>] [icmp] [icmp-msg <0~255>] | | 0 | EXEC |
| show ip statistics [system] [interface vlan <vlan_list>] [icmp] [icmp-msg <0~255>] | | 0 | EXEC |

| | | | |
|--|--|-------|----------------|
| debug ipstack log [ERR NOERR] [WARNING NOWARNING] [NOTICE NONOTICE] [INFO NOINFO] [DEBUG NODEBUG] [MDEBUG NOMDEBUG] [IOCTL NOIOCTL] [INIT NOINIT] [ADDR NOADDR] [FAIL NOFAIL] [EMERG NOEMERG] [CRIT NOCRIT] | | debug | EXEC |
| debug ip kmem | | debug | EXEC |
| debug ip route | | debug | EXEC |
| debug ip sockets | | debug | EXEC |
| debug ip lpm stat ip <vlan_list> | | debug | EXEC |
| debug ip lpm stat ipv6 <vlan_list> | | debug | EXEC |
| debug ip lpm stat clear <vlan_list> | | debug | EXEC |
| debug ip lpm sticky clear | | debug | EXEC |
| debug ip lpm usage | | debug | EXEC |
| debug ip global interface table change | | debug | EXEC |
| debug ip vlan ipv4 created <vlan_list> | | debug | EXEC |
| debug ip vlan ipv4 changed <vlan_list> | | debug | EXEC |
| debug ip vlan ipv6 created <vlan_list> | | debug | EXEC |
| debug ip vlan ipv6 changed <vlan_list> | | debug | EXEC |
| show ip igmp snooping mrouter [detail] | | 0 | EXEC |
| clear ip igmp snooping [vlan <vlan_list>] statistics | | 15 | EXEC |
| show ip igmp snooping [vlan <vlan_list>] [group- database [interface <port_type_list>] [sfm- information]] [detail] | | 0 | EXEC |
| ip igmp snooping | | 15 | GLOBAL_CONFIG |
| ip igmp unknown-flooding | | 15 | GLOBAL_CONFIG |
| ip igmp host-proxy [leave-proxy] | | 15 | GLOBAL_CONFIG |
| ip igmp ssm-range <ipv4_mcast> <4-32> | | 15 | GLOBAL_CONFIG |
| no ip igmp ssm-range | | 15 | GLOBAL_CONFIG |
| ip igmp snooping vlan <vlan_list> | | 15 | GLOBAL_CONFIG |
| no ip igmp snooping vlan [<vlan_list>] | | 15 | GLOBAL_CONFIG |
| ip igmp snooping | | 15 | INTERFACE_VLAN |
| ip igmp snooping querier { election address <ipv4_ucast> } | | 15 | INTERFACE_VLAN |
| no ip igmp snooping querier { election address } | | 15 | INTERFACE_VLAN |
| ip igmp snooping compatibility { auto v1 v2 v3 } | | 15 | INTERFACE_VLAN |
| no ip igmp snooping compatibility | | 15 | INTERFACE_VLAN |

| | | | |
|--|--|----|---------------------|
| ip igmp snooping priority <0-7> | | 15 | INTERFACE_VLAN |
| no ip igmp snooping priority | | 15 | INTERFACE_VLAN |
| ip igmp snooping robustness-variable <1-255> | | 15 | INTERFACE_VLAN |
| no ip igmp snooping robustness-variable | | 15 | INTERFACE_VLAN |
| ip igmp snooping query-interval <1-31744> | | 15 | INTERFACE_VLAN |
| no ip igmp snooping query-interval | | 15 | INTERFACE_VLAN |
| ip igmp snooping query-max-response-time <0-31744> | | 15 | INTERFACE_VLAN |
| no ip igmp snooping query-max-response-time | | 15 | INTERFACE_VLAN |
| ip igmp snooping last-member-query-interval <0-31744> | | 15 | INTERFACE_VLAN |
| no ip igmp snooping last-member-query-interval | | 15 | INTERFACE_VLAN |
| ip igmp snooping unsolicited-report-interval <0-31744> | | 15 | INTERFACE_VLAN |
| no ip igmp snooping unsolicited-report-interval | | 15 | INTERFACE_VLAN |
| ip igmp snooping immediate-leave | | 15 | INTERFACE_VLAN |
| ip igmp snooping mrouter | | 15 | INTERFACE_PORT_LIST |
| ip igmp snooping max-groups <1-10> | | 15 | INTERFACE_PORT_LIST |
| no ip igmp snooping max-groups | | 15 | INTERFACE_PORT_LIST |
| ip igmp snooping filter <word16> | | 15 | INTERFACE_PORT_LIST |
| no ip igmp snooping filter | | 15 | INTERFACE_PORT_LIST |
| ipv6 mld snooping | | 15 | GLOBAL_CONFIG |
| ipv6 mld unknown-flooding | | 15 | GLOBAL_CONFIG |
| ipv6 mld host-proxy [leave-proxy] | | 15 | GLOBAL_CONFIG |
| ipv6 mld ssm-range <ipv6_mcast> <8-128> | | 15 | GLOBAL_CONFIG |
| no ipv6 mld ssm-range | | 15 | GLOBAL_CONFIG |
| ipv6 mld snooping vlan <vlan_list> | | 15 | GLOBAL_CONFIG |
| no ipv6 mld snooping vlan [<vlan_list>] | | 15 | GLOBAL_CONFIG |
| ipv6 mld snooping immediate-leave | | 15 | INTERFACE_PORT_LIST |
| ipv6 mld snooping mrouter | | 15 | INTERFACE_PORT_LIST |
| ipv6 mld snooping max-groups <1-10> | | 15 | INTERFACE_PORT_LIST |
| no ipv6 mld snooping max-groups | | 15 | INTERFACE_PORT_LIST |
| ipv6 mld snooping filter <word16> | | 15 | INTERFACE_PORT_LIST |
| no ipv6 mld snooping filter | | 15 | INTERFACE_PORT_LIST |
| show ipv6 mld snooping mrouter [detail] | | 0 | EXEC |
| clear ipv6 mld snooping [vlan <vlan_list>] statistics | | 15 | EXEC |
| show ipv6 mld snooping [vlan <vlan_list>] | | 0 | EXEC |

| | | | |
|---|------------------------------------|----|---------------------|
| [group-database [interface <port_type_list>] [sfm-information]] [detail] | | | |
| ipv6 mld snooping | | 15 | INTERFACE_VLAN |
| ipv6 mld snooping querier election | | 15 | INTERFACE_VLAN |
| ipv6 mld snooping compatibility { auto v1 v2 } | | 15 | INTERFACE_VLAN |
| no ipv6 mld snooping compatibility | | 15 | INTERFACE_VLAN |
| ipv6 mld snooping priority <0-7> | | 15 | INTERFACE_VLAN |
| no ipv6 mld snooping priority | | 15 | INTERFACE_VLAN |
| ipv6 mld snooping robustness-variable <1-255> | | 15 | INTERFACE_VLAN |
| no ipv6 mld snooping robustness-variable | | 15 | INTERFACE_VLAN |
| ipv6 mld snooping query-interval <1-31744> | | 15 | INTERFACE_VLAN |
| no ipv6 mld snooping query-interval | | 15 | INTERFACE_VLAN |
| ipv6 mld snooping query-max-response-time <0-31744> | | 15 | INTERFACE_VLAN |
| no ipv6 mld snooping query-max-response-time | | 15 | INTERFACE_VLAN |
| ipv6 mld snooping last-member-query-interval <0-31744> | | 15 | INTERFACE_VLAN |
| no ipv6 mld snooping last-member-query-interval | | 15 | INTERFACE_VLAN |
| ipv6 mld snooping unsolicited-report-interval <0-31744> | | 15 | INTERFACE_VLAN |
| no ipv6 mld snooping unsolicited-report-interval | | 15 | INTERFACE_VLAN |
| ip verify source | | 13 | GLOBAL_CONFIG |
| i ip verify source | | 13 | INTERFACE_PORT_LIST |
| ip verify source limit <0-2> | | 13 | INTERFACE_PORT_LIST |
| no ip verify source limit | | 13 | INTERFACE_PORT_LIST |
| ip verify source translate | | 13 | GLOBAL_CONFIG |
| show ip verify source [interface <port_type_list>] | | 0 | EXEC |
| show ip source binding [dhcp-snooping static] [interface <port_type_list>] | | 13 | EXEC |
| ip source binding interface <port_type_id> <vlan_id> <ipv4_ucast> <mac_ucast> | | 13 | GLOBAL_CONFIG |
| ip source binding interface <port_type_id> <vlan_id> <ipv4_ucast> <ipv4_netmask> | | 13 | GLOBAL_CONFIG |
| show lacp { internal statistics system-id neighbour } | Show LACP configuration and status | 15 | EXEC |
| clear lacp statistics | Clear all LACP statistics | 15 | EXEC |
| lacp system-priority <1-65535> | Set the LACP system priority | 15 | GLOBAL_CONFIG |
| lacp | Enable LACP on an interface | 15 | INTERFACE_PORT_LIST |

| | | | |
|--|--|----|---------------------|
| lACP key { <1-65535> auto } | Set the LACP key | 15 | INTERFACE_PORT_LIST |
| lACP role { active passive } | Set the LACP role, active or passive in transmitting BPDUs | 15 | INTERFACE_PORT_LIST |
| lACP timeout { fast slow } | Set the LACP timeout, i.e. how fast to transmit BPDUs, once a sec or once each 30 sec. | 15 | INTERFACE_PORT_LIST |
| lACP port-priority <1-65535> | Set the lACP port priority, | 15 | INTERFACE_PORT_LIST |
| lldp holdtime <2-10> | Sets LLDP hold time (The neighbor switch will discarded the LLDP information after \"hold time\" multiplied with \"timer\" seconds) | 15 | GLOBAL_CONFIG |
| no lldp holdtime | | 15 | GLOBAL_CONFIG |
| lldp timer <5-32768> | Sets LLDP TX interval (The time between each LLDP frame transmitted in seconds). | 15 | GLOBAL_CONFIG |
| no lldp timer | | 15 | GLOBAL_CONFIG |
| lldp reinit <1-10> | Sets LLDP reinitialization delay. | 15 | GLOBAL_CONFIG |
| no lldp reinit | Sets LLDP reinitialization delay. | 15 | GLOBAL_CONFIG |
| lldp tlv-select {management-address port-description system-capabilities system-description system-name} | Enables/disables LLDP optional TLVs. | 15 | INTERFACE_PORT_LIST |
| lldp transmit | Sets if switch shall transmit LLDP frames. | 15 | INTERFACE_PORT_LIST |
| lldp receive | Sets if switch shall update LLDP entry table with incoming LLDP information. | 15 | INTERFACE_PORT_LIST |
| show lldp neighbors [interface <port_type_list>] | Shows the LLDP neighbors information. | 0 | EXEC |
| show lldp statistics [interface <port_type_list>] | Shows the LLDP statistics information. | 0 | EXEC |
| clear lldp statistics | Clears the LLDP statistics. | 0 | EXEC |
| lldp transmission-delay <1-8192> | Sets LLDP transmission-delay. LLDP transmission delay (the amount of time that the transmission of LLDP frames will delayed after LLDP configuration has changed) in seconds.) | 15 | GLOBAL_CONFIG |
| no lldp transmission-delay | | 15 | GLOBAL_CONFIG |
| lldp cdp-aware | Configures if the interface shall be CDP aware (CDP discovery information is added to the LLDP neighbor table) | 15 | INTERFACE_PORT_LIST |
| show lldp med remote-device [interface <port_type_list>] | Show LLDP-MED neighbor device information. | 0 | EXEC |

| | | | |
|--|--|----|---------------------|
| show lldp med media-vlan-policy [<0~31>] | Show media vlan policy(ies) | 0 | EXEC |
| lldp med location-tlv latitude { north south } <word8> | Use the lldp med location-tlv latitude to configure the location latitude. | 15 | GLOBAL_CONFIG |
| no lldp med location-tlv latitude | Use no lldp med location-tlv latitude to configure the latitude location to north 0 degrees. | 15 | GLOBAL_CONFIG |
| lldp med location-tlv longitude { west east } <word9> | Use the lldp med location-tlv longitude to configure the location longitude. | 15 | GLOBAL_CONFIG |
| no lldp med location-tlv longitude | Use no lldp med location-tlv longitude to configure the longitude location to north 0 degrees. | 15 | GLOBAL_CONFIG |
| lldp med location-tlv altitude { meters floors } <word11> | Use the lldp med location-tlv altitude to configure the location altitude. | 15 | GLOBAL_CONFIG |
| no lldp med location-tlv altitude | Use the lldp med location-tlv altitude to configure the location altitude. | 15 | GLOBAL_CONFIG |
| lldp med location-tlv civic-addr { country state county city district block street leading-street-direction trailing-street-suffix street-suffix house-no house-no-suffix landmark additional-info name zip-code building apartment floor room-number place-type postal-community-name p-o-box additional-code } <string250> | Use lldp med location-tlv civic-addr to configure the civic address. | 15 | GLOBAL_CONFIG |
| no lldp med location-tlv civic-addr { country state county city district block street leading-street-direction trailing-street-suffix street-suffix house-no house-no-suffix landmark additional-info name zip-code building apartment floor room-number place-type postal-community-name p-o-box additional-code } | | 15 | GLOBAL_CONFIG |
| lldp med location-tlv elin-addr <dword25> | Use the lldp med location-tlv elin-addr to configure value for the Emergency Call Service | 15 | GLOBAL_CONFIG |
| no lldp med location-tlv elin-addr | Use the no lldp med location-tlv elin-addr to configure value for the Emergency Call Service to default value. | 15 | GLOBAL_CONFIG |
| lldp med transmit-tlv [capabilities] [location] | Use the lldp med transmit-tlv to | 15 | INTERFACE_PORT_LIST |

| | | | |
|--|---|----|---------------------|
| [network-policy] | configure which TLVs to transmit to link partner. | | |
| no lldp med transmit-tlv [capabilities] [location] [network-policy] | | 15 | INTERFACE_PORT_LIST |
| lldp med datum { wgs84 nad83-navd88 nad83-mlw } | Use the lldp med datum to configure the datum (geodetic system) to use. | 15 | GLOBAL_CONFIG |
| no lldp med datum | | 15 | GLOBAL_CONFIG |
| lldp med fast <1-10> | Use the lldp med fast to configure the number of times the fast start LLDPDU are being sent during the activation of the fast start mechanism defined by LLDP-MED (1-10). | 15 | GLOBAL_CONFIG |
| no lldp med fast | | 15 | GLOBAL_CONFIG |
| lldp med media-vlan-policy <0-31> { voice voice-signaling guest-voice-signaling guest-voice softphone-voice video-conferencing streaming-video video-signaling } { tagged <vlan_id> untagged } [l2-priority <0-7>] [dscp <0-63>] | Use the media-vlan-policy to create a policy, which can be assigned to an interface. | 15 | GLOBAL_CONFIG |
| no lldp med media-vlan-policy <0-31> | | 15 | GLOBAL_CONFIG |
| lldp med media-vlan policy-list <range_list> | Use the media-vlan policy-list to assign policy to the interface. | 15 | INTERFACE_PORT_LIST |
| loop-protect | Loop protection configuration | 15 | GLOBAL_CONFIG |
| loop-protect transmit-time <1-10> | Loop protection transmit time interval | 15 | GLOBAL_CONFIG |
| no loop-protect transmit-time | | 15 | GLOBAL_CONFIG |
| loop-protect shutdown-time <0-604800> | Loop protection shutdown time interval | 15 | GLOBAL_CONFIG |
| no loop-protect shutdown-time | | 15 | GLOBAL_CONFIG |
| loop-protect | Loop protection configuration | 15 | INTERFACE_PORT_LIST |
| loop-protect action { [shutdown] [log] }*1 | | 15 | INTERFACE_PORT_LIST |
| no loop-protect action | | 15 | INTERFACE_PORT_LIST |
| loop-protect tx-mode | | 15 | INTERFACE_PORT_LIST |
| show loop-protect [interface <port_type_list>] | | 13 | EXEC |
| mac address-table learning [secure] | Enable learning on port | 15 | INTERFACE_PORT_LIST |
| show mac address-table [conf static aging-time] { { learning count } [interface <port_type_list>] } { address <mac_addr> [vlan <vlan_id>] } vlan <vlan_id> interface <port_type_list>] | | 0 | EXEC |
| clear mac address-table | | 15 | EXEC |
| mac address-table static <mac_addr> vlan | Assign a static mac address to this port | 15 | GLOBAL_CONFIG |

| | | | |
|---|--------------------------------------|-------|---------------------|
| <vlan_id> interface <port_type_list> | | | |
| mac address-table aging-time <0,10-1000000> | Set switch aging time, 0 to disable. | 15 | GLOBAL_CONFIG |
| no mac address-table aging-time | Default aging time. | 15 | GLOBAL_CONFIG |
| monitor destination interface <port_type_id> | Sets monitor destination port. | 15 | GLOBAL_CONFIG |
| no monitor destination | Sets monitor destination port. | 15 | GLOBAL_CONFIG |
| monitor source { { interface <port_type_list> } { cpu [<range_list>] } { both rx tx } | Sets monitor source port(s). | 15 | GLOBAL_CONFIG |
| no monitor source { { interface <port_type_list> } { cpu [<range_list>] } } | Sets monitor source port(s). | 15 | GLOBAL_CONFIG |
| debug chip [{ 0 1 all }] | | debug | EXEC |
| debug api [interface <port_type_list>] [{ ail cil }] [{ init misc port counters phy vlan pvlan mac-table acl qos aggr stp mirror evc erps eps packet fdma ts pts wm ipmc cmef mplscore mplsoam vxlat oam sgpio l3 afi macsec }] [full] [clear] | | debug | EXEC |
| debug suspend | | debug | EXEC |
| debug resume | | debug | EXEC |
| debug kr-conf [cm1 <-32-31>] [c0 <-32-31>] [cp1 <-32-31>] [ampl <300-1275>] [{ ps25 ps35 ps55 ps70 ps120 }] [en-ob dis-ob] [ser-inv ser-no-inv] | | debug | INTERFACE_PORT_LIST |
| show spanning-tree [summary active { interface <port_type_list> } { detailed [interface <port_type_list>] } { mst [configuration { <0-7> [interface <port_type_list>] }] }] | | 15 | EXEC |
| clear spanning-tree { { statistics [interface <port_type_list>] } { detected-protocols [interface <port_type_list>] } } | | 15 | EXEC |
| spanning-tree mode { stp rstp mstp } | | 15 | GLOBAL_CONFIG |
| no spanning-tree mode | | 15 | GLOBAL_CONFIG |
| spanning-tree transmit hold-count <1-10> | | 15 | GLOBAL_CONFIG |
| no spanning-tree transmit hold-count | | 15 | GLOBAL_CONFIG |
| spanning-tree mst max-hops <6-40> | | 15 | GLOBAL_CONFIG |
| no spanning-tree mst max-hops | | 15 | GLOBAL_CONFIG |
| spanning-tree mst max-age <6-40> [forward-time <4-30>] | | 15 | GLOBAL_CONFIG |
| no spanning-tree mst max-age | | 15 | GLOBAL_CONFIG |
| spanning-tree mst forward-time <4-30> | | 15 | GLOBAL_CONFIG |

| | | | |
|--|--|----|---------------------|
| no spanning-tree mst forward-time | | 15 | GLOBAL_CONFIG |
| spanning-tree edge bpdu-filter | | 15 | GLOBAL_CONFIG |
| spanning-tree edge bpdu-guard | | 15 | GLOBAL_CONFIG |
| spanning-tree recovery interval <30-86400> | | 15 | GLOBAL_CONFIG |
| no spanning-tree recovery interval | | 15 | GLOBAL_CONFIG |
| spanning-tree mst <0-7> priority <0-61440> | | 15 | GLOBAL_CONFIG |
| no spanning-tree mst <0-7> priority | | 15 | GLOBAL_CONFIG |
| spanning-tree mst <0-7> vlan <vlan_list> | | 15 | GLOBAL_CONFIG |
| no spanning-tree mst <0-7> vlan | | 15 | GLOBAL_CONFIG |
| spanning-tree mst name <word32> revision <0-65535> | | 15 | GLOBAL_CONFIG |
| no spanning-tree mst name | | 15 | GLOBAL_CONFIG |
| spanning-tree | | 15 | INTERFACE_PORT_LIST |
| spanning-tree edge | | 15 | INTERFACE_PORT_LIST |
| spanning-tree auto-edge | | 15 | INTERFACE_PORT_LIST |
| spanning-tree link-type { point-to-point shared auto } | | 15 | INTERFACE_PORT_LIST |
| no spanning-tree link-type | | 15 | INTERFACE_PORT_LIST |
| spanning-tree restricted-role | | 15 | INTERFACE_PORT_LIST |
| spanning-tree restricted-tcn | | 15 | INTERFACE_PORT_LIST |
| spanning-tree bpdu-guard | | 15 | INTERFACE_PORT_LIST |
| spanning-tree mst <0-7> cost { <1-200000000> auto } | | 15 | INTERFACE_PORT_LIST |
| no spanning-tree mst <0-7> cost | | 15 | INTERFACE_PORT_LIST |
| spanning-tree mst <0-7> port-priority <0-240> | | 15 | INTERFACE_PORT_LIST |
| no spanning-tree mst <0-7> port-priority | | 15 | INTERFACE_PORT_LIST |
| spanning-tree | | 15 | STP_AGGR |
| spanning-tree edge | | 15 | STP_AGGR |
| spanning-tree auto-edge | | 15 | STP_AGGR |
| spanning-tree link-type { point-to-point shared auto } | | 15 | STP_AGGR |
| no spanning-tree link-type | | 15 | STP_AGGR |
| spanning-tree restricted-role | | 15 | STP_AGGR |
| spanning-tree restricted-tcn | | 15 | STP_AGGR |
| spanning-tree bpdu-guard | | 15 | STP_AGGR |
| spanning-tree mst <0-7> cost { <1-200000000> auto } | | 15 | STP_AGGR |
| no spanning-tree mst <0-7> cost | | 15 | STP_AGGR |

| | | | |
|--|--|----|---------------------|
| spanning-tree mst <0-7> port-priority <0-240> | | 15 | STP_AGGR |
| no spanning-tree mst <0-7> port-priority | | 15 | STP_AGGR |
| mvr vlan <vlan_list> type { source receiver } | | 15 | INTERFACE_PORT_LIST |
| mvr name <word16> type { source receiver } | | 15 | INTERFACE_PORT_LIST |
| no mvr vlan <vlan_list> type | | 15 | INTERFACE_PORT_LIST |
| no mvr name <word16> type | | 15 | INTERFACE_PORT_LIST |
| mvr immediate-leave | | 15 | INTERFACE_PORT_LIST |
| clear mvr [vlan <vlan_list> name <word16>] statistics | | 15 | EXEC |
| show mvr [vlan <vlan_list> name <word16>] [group-database [interface <port_type_list>] [sfm-information]] [detail] | | 0 | EXEC |
| mvr | | 15 | GLOBAL_CONFIG |
| mvr vlan <vlan_list> [name <word16>] | | 15 | GLOBAL_CONFIG |
| no mvr vlan <vlan_list> | | 15 | GLOBAL_CONFIG |
| mvr vlan <vlan_list> mode { dynamic compatible } | | 15 | GLOBAL_CONFIG |
| mvr name <word16> mode { dynamic compatible } | | 15 | GLOBAL_CONFIG |
| no mvr vlan <vlan_list> mode | | 15 | GLOBAL_CONFIG |
| no mvr name <word16> mode | | 15 | GLOBAL_CONFIG |
| mvr vlan <vlan_list> igmp-address <ipv4_ucast> | | 15 | GLOBAL_CONFIG |
| mvr name <word16> igmp-address <ipv4_ucast> | | 15 | GLOBAL_CONFIG |
| no mvr vlan <vlan_list> igmp-address | | 15 | GLOBAL_CONFIG |
| no mvr name <word16> igmp-address | | 15 | GLOBAL_CONFIG |
| mvr vlan <vlan_list> frame priority <0-7> | | 15 | GLOBAL_CONFIG |
| mvr vlan <vlan_list> frame tagged | | 15 | GLOBAL_CONFIG |
| mvr name <word16> frame priority <0-7> | | 15 | GLOBAL_CONFIG |
| mvr name <word16> frame tagged | | 15 | GLOBAL_CONFIG |
| no mvr vlan <vlan_list> frame priority | | 15 | GLOBAL_CONFIG |
| no mvr name <word16> frame priority | | 15 | GLOBAL_CONFIG |
| mvr vlan <vlan_list> last-member-query-interval <0-31744> | | 15 | GLOBAL_CONFIG |
| mvr name <word16> last-member-query-interval <0-31744> | | 15 | GLOBAL_CONFIG |
| no mvr vlan <vlan_list> last-member-query- interval | | 15 | GLOBAL_CONFIG |
| no mvr name <word16> last-member-query- | | 15 | GLOBAL_CONFIG |

| | | | |
|--|--|----|---------------------|
| interval | | | |
| mvr vlan <vlan_list> channel <word16> | | 15 | GLOBAL_CONFIG |
| no mvr vlan <vlan_list> channel | | 15 | GLOBAL_CONFIG |
| no mvr name <word16> channel | | 15 | GLOBAL_CONFIG |
| show dot1x statistics { eapol radius all} [interface <port_type_list>] | Shows statistics for either eapol or radius. | 0 | EXEC |
| show dot1x status [interface <port_type_list>] [brief] | Shows dot1x status, such as admin state, port state and last source. | 0 | EXEC |
| clear dot1x statistics [interface <port_type_list>] | Clears the statistics counters | 15 | EXEC |
| dot1x re-authentication | Set Re-authentication state | 15 | GLOBAL_CONFIG |
| dot1x authentication timer re-authenticate <1-3600> | The period between re-authentication attempts in seconds | 15 | GLOBAL_CONFIG |
| no dot1x authentication timer re-authenticate | | 15 | GLOBAL_CONFIG |
| dot1x timeout tx-period <1-65535> | the time between EAPOL retransmissions. | 15 | GLOBAL_CONFIG |
| no dot1x timeout tx-period | | 15 | GLOBAL_CONFIG |
| dot1x authentication timer inactivity <10-1000000> | Time in seconds between check for activity on successfully authenticated MAC addresses. | 15 | GLOBAL_CONFIG |
| no dot1x authentication timer inactivity | | 15 | GLOBAL_CONFIG |
| dot1x timeout quiet-period <10-1000000> | Time in seconds before a MAC-address that failed authentication gets a new authentication chance. | 15 | GLOBAL_CONFIG |
| no dot1x timeout quiet-period | | 15 | GLOBAL_CONFIG |
| dot1x re-authenticate | Refresh (restart) 802.1X authentication process. | 15 | INTERFACE_PORT_LIST |
| dot1x initialize [interface <port_type_list>] | Force re-authentication immediately | 15 | EXEC |
| dot1x system-auth-control | Set the global NAS state | 15 | GLOBAL_CONFIG |
| dot1x port-control { force-authorized force-unauthorized auto single multi mac-based } | Sets the port security state. | 15 | INTERFACE_PORT_LIST |
| no dot1x port-control | Sets the port security state. | 15 | INTERFACE_PORT_LIST |
| dot1x guest-vlan | Enables/disables guest VLAN | 15 | INTERFACE_PORT_LIST |
| dot1x max-reauth-req <1-255> | The number of times a Request Identity EAPOL frame is sent without response before considering entering the Guest VLAN | 15 | GLOBAL_CONFIG |
| no dot1x max-reauth-req | The number of times a Request Identity EAPOL frame is sent without response before considering entering the Guest | 15 | GLOBAL_CONFIG |

| | | | |
|---|---|----|---------------------|
| | VLAN | | |
| dot1x guest-vlan <1-4095> | Guest VLAN ID used when entering the Guest VLAN. | 15 | GLOBAL_CONFIG |
| no dot1x guest-vlan | Guest VLAN ID used when entering the Guest VLAN. | 15 | GLOBAL_CONFIG |
| dot1x guest-vlan supplicant | The switch remembers if an EAPOL frame has been received on the port for the life-time of the port. Once the switch considers whether to enter the Guest VLAN, it will first check if this option is enabled or disabled. If disabled (unchecked; default), the switch will only enter the Guest VLAN if an EAPOL frame has not been received on the port for the life-time of the port. If enabled (checked), the switch will consider entering the Guest VLAN even if an EAPOL frame has been received on the port for the life-time of the port. | 15 | GLOBAL_CONFIG |
| dot1x radius-qos | Enables/disables per-port state of RADIUS-assigned QoS. | 15 | INTERFACE_PORT_LIST |
| dot1x radius-vlan | Enables/disables per-port state of RADIUS-assigned VLAN. | 15 | INTERFACE_PORT_LIST |
| dot1x feature { [guest-vlan] [radius-qos] [radius-vlan] } *1 | Globally enables/disables a dot1x feature functionality | 15 | GLOBAL_CONFIG |
| show dot1x statistics { eapol radius all } [interface <port_type_list>] | Shows statistics for either eapol or radius. | 0 | EXEC |
| ntp | Enable NTP | 13 | GLOBAL_CONFIG |
| ntp server <1-5> ip-address {<ipv4_ucast> <ipv6_ucast> <hostname>} | | 13 | GLOBAL_CONFIG |
| ntp server <1-5> ip-address {<ipv4_ucast> <hostname>} | | 13 | GLOBAL_CONFIG |
| no_ntp_server_ip_address | | 13 | GLOBAL_CONFIG |
| show ntp status | | 13 | EXEC |
| show platform phy [interface <port_type_list>] | Show PHY module's information for all or a given interface | 15 | EXEC |
| show platform phy id [interface <port_type_list>] | Platform PHY's IDs | 15 | EXEC |
| show platform phy instance | | 15 | EXEC |
| show platform phy failover | | 15 | EXEC |

| | | | |
|---|--|-------|---------------------|
| platform phy instance restart { cool warm } | | 15 | EXEC |
| platform phy instance default-activate | | 15 | EXEC |
| show platform phy status [interface <port_type_list>] | | 15 | EXEC |
| no platform phy instance | | 15 | GLOBAL_CONFIG |
| platform phy failover | | 15 | INTERFACE_PORT_LIST |
| debug phy read [<0~31>] [<0-0xffff>] [addr- sort] | | debug | INTERFACE_PORT_LIST |
| debug phy write [<0~31>] <0-0xffff> [<0-0xffff>] | | debug | INTERFACE_PORT_LIST |
| debug phy do-page-chk [enable disable] | | debug | EXEC |
| debug phy force-pass-through-speed {1G 100M 10M} | | debug | INTERFACE_PORT_LIST |
| debug phy reset | | debug | INTERFACE_PORT_LIST |
| debug phy gpio <0-13> mode {output input alternative} | | debug | INTERFACE_PORT_LIST |
| debug phy gpio <0-13> get | | debug | INTERFACE_PORT_LIST |
| show poe [interface <port_type_list>] | Use the show poe to show PoE status. | 0 | EXEC |
| poe mode { standard plus } | Use poe mode to configure of PoE mode. | 15 | INTERFACE_PORT_LIST |
| no poe mode | Use poe mode to configure of PoE mode. | 15 | INTERFACE_PORT_LIST |
| poe priority { low high critical } | Use poe priority to configure PoE priority. | 15 | INTERFACE_PORT_LIST |
| no poe priority | Use poe priority to configure PoE priority. | 15 | INTERFACE_PORT_LIST |
| poe management mode { class-consumption class-reserved-power allocation-consumption allocation-reserved-power lldp-consumption lldp-reserved-power } | Use management mode to configure PoE power management method. | 15 | GLOBAL_CONFIG |
| no poe management mode | | 15 | GLOBAL_CONFIG |
| poe power limit { <fword2.1> } | Use poe power limit to configure the maximum allowed power for the interface when power management is in allocation mode. | 15 | INTERFACE_PORT_LIST |
| no poe power limit | Use poe power limit to configure the maximum allowed power for the interface when power management is in allocation mode. | 15 | INTERFACE_PORT_LIST |
| poe supply sid <1~16> <1-2000> | Use poe supply to specify the maximum | 15 | GLOBAL_CONFIG |

| | | | |
|-------------------------------------|--|----|---------------------|
| | power the power supply can deliver. | | |
| no poe supply [sid <1~16>] | | 15 | GLOBAL_CONFIG |
| poe schedule-mode | Configure PoE Schedule mode. | 15 | INTERFACE_PORT_LIST |
| no poe schedule-mode | disable PoE power management method. | 15 | INTERFACE_PORT_LIST |
| poe select-all <range_list> | Configure PoE Schedule mode. | 15 | GLOBAL_CONFIG |
| no poe schedule-all <range_list> | disable PoE power management method. | 15 | GLOBAL_CONFIG |
| poe delay-mode <range_list> | Configure PoE Power Delay mode. | 15 | GLOBAL_CONFIG |
| no poe delay-mode <range_list> | | 15 | GLOBAL_CONFIG |
| poe delay-time <range_list> <0-300> | Configure PoE Power Delay time. | 15 | GLOBAL_CONFIG |
| poe hour <0-23> | This command is used to set hour time per week to enable PoE. | 15 | INTERFACE_PORT_LIST |
| no poe hour <0-23> | This command is used to set hour time per week to disable PoE. | 15 | INTERFACE_PORT_LIST |
| poe Sun | This command is used to set hour time on Sunday to enable PoE. | 15 | INTERFACE_PORT_LIST |
| no poe Sun | This command is used to set hour time on Sunday to disable PoE. | 15 | INTERFACE_PORT_LIST |
| poe Mon | This command is used to set hour time on Monday to enable PoE. | 15 | INTERFACE_PORT_LIST |
| no poe Mon | This command is used to set hour time on Monday to disable PoE. | 15 | INTERFACE_PORT_LIST |
| poe Tue | This command is used to set hour time on Tuesday to enable PoE. | 15 | INTERFACE_PORT_LIST |
| no poe Tue | This command is used to set hour time on Tuesday to disable PoE. | 15 | INTERFACE_PORT_LIST |
| poe Wed | This command is used to set hour time on Wednesday to enable PoE. | 15 | INTERFACE_PORT_LIST |
| no poe Wed | This command is used to set hour time on Wednesday to disable PoE. | 15 | INTERFACE_PORT_LIST |
| poe Thr | This command is used to set hour time on Thursday to enable PoE. | 15 | INTERFACE_PORT_LIST |
| no poe Thr | This command is used to set hour time on Thursday to enable PoE. | 15 | INTERFACE_PORT_LIST |
| poe Fri | This command is used to set hour time on Friday to enable PoE. | 15 | INTERFACE_PORT_LIST |
| no poe Fri | This command is used to set hour time on Friday to disable PoE. | 15 | INTERFACE_PORT_LIST |

| | | | |
|---|---|----|---------------------|
| poE Sat | This command is used to set hour time on Saturday to enable PoE. | 15 | INTERFACE_PORT_LIST |
| no poE Sat | This command is used to set hour time on Saturday to disable PoE. | 15 | INTERFACE_PORT_LIST |
| show interface <port_type_list> statistics [{ packets bytes errors discards filtered { priority [<0~7> } }] [{ up down }] | Shows the statistics for the interface. | 0 | EXEC |
| show interface <port_type_list> veriphy | Run and display cable diagnostics. | 0 | EXEC |
| clear statistics [interface] <port_type_list> | Clears the statistics for the interface. | 0 | EXEC |
| show interface <port_type_list> capabilities | | 0 | EXEC |
| show interface <port_type_list> status | Display status for the interface. | 0 | EXEC |
| mtu <'VTSS_MAX_FRAME_LENGTH_STANDARD'- 'VTSS_MAX_FRAME_LENGTH_MAX'> | Use mtu to specify maximum frame size (1518-9600 bytes). | 15 | INTERFACE_PORT_LIST |
| no mtu | Use no mtu to set maximum frame size to default. | 15 | INTERFACE_PORT_LIST |
| shutdown | Use shutdown to shutdown the interface. | 15 | INTERFACE_PORT_LIST |
| speed {2500 1000 100 10 auto {[10] [100] [1000]} } | Configures interface speed. If you use 10, 100, or 1000 keywords with the auto keyword the port will only advertise the specified speeds. | 15 | INTERFACE_PORT_LIST |
| no speed | Use "no speed" to configure interface to default speed. | 15 | INTERFACE_PORT_LIST |
| duplex { half full auto [half full] } | Use duplex to configure interface duplex mode. | 15 | INTERFACE_PORT_LIST |
| no duplex | Use "no duplex" to set duplex to default. | 15 | INTERFACE_PORT_LIST |
| media-type { rj45 sfp dual } | Use media-type to configure the interface media type. | 15 | INTERFACE_PORT_LIST |
| no media-type | Use to configure the interface media-type type to default. | 15 | INTERFACE_PORT_LIST |
| flowcontrol { on off } | Use flowcontrol to configure flow control for the interface. | 15 | INTERFACE_PORT_LIST |
| no flowcontrol | Use no flowcontrol to set flow control to default. | 15 | INTERFACE_PORT_LIST |
| excessive-restart | Use excessive-restart to configure backoff algorithm in half duplex mode. | 15 | INTERFACE_PORT_LIST |
| show web privilege group [<word>] level | | 0 | EXEC |
| web privilege group <word> level [[cro <0-15>] | | 15 | GLOBAL_CONFIG |

| | | | |
|--|---|----|---------------------|
| [crw <0-15>] [sro <0-15>] [srw <0-15>] }*1 | | | |
| no web privilege group [<word>] level | | 15 | GLOBAL_CONFIG |
| show port-security port [interface <port_type_list>] | Show MAC Addresses learned by Port Security | 0 | EXEC |
| show port-security switch [interface <port_type_list>] | Show Port Security status. | 0 | EXEC |
| no port-security shutdown [interface <port_type_list>] | Reopen one or more ports whose limit is exceeded and shut down. | 15 | EXEC |
| port-security | Enable/disable port security globally. | 15 | GLOBAL_CONFIG |
| port-security aging | Enable/disable port security aging. | 15 | GLOBAL_CONFIG |
| port-security aging time <10-1000000> | Time in seconds between check for activity on learned MAC addresses. | 15 | GLOBAL_CONFIG |
| no port-security aging time | | 15 | GLOBAL_CONFIG |
| port-security | Enable/disable port security per interface. | 15 | INTERFACE_PORT_LIST |
| port-security maximum [<1-1024>] | Maximum number of MAC addresses that can be learned on this set of interfaces. | 15 | INTERFACE_PORT_LIST |
| no port-security maximum | | 15 | INTERFACE_PORT_LIST |
| port-security violation { protect trap trap-shutdown shutdown } | The action involved with exceeding the limit. | 15 | INTERFACE_PORT_LIST |
| no port-security violation | The action involved with exceeding the limit. | 15 | INTERFACE_PORT_LIST |
| pvlan <range_list> | Use the pvlan add or remove command to add or remove a port from a PVLAN. | 13 | INTERFACE_PORT_LIST |
| pvlan isolation | Use the pvlan isolation command to add the port into an isolation group. | 13 | INTERFACE_PORT_LIST |
| show pvlan [<range_list>] | Use the show pvlan command to view the PVLAN configuration. | 13 | EXEC |
| show pvlan isolation [interface <port_type_list>] | Use the show pvlan isolation command to view the PVLAN isolation configuration. | 13 | EXEC |
| show qos [{ interface [<port_type_list>] } wred { maps [dscp-cos] [dscp-ingress-translation] [dscp-classify] [cos-dscp] [dscp-egress-translation] } storm { qce [<1-256>] }] | | 15 | EXEC |
| qos map dscp-cos { <0-63> <dscp> } cos <0-7> dpl <dpl> | | 15 | GLOBAL_CONFIG |
| no qos map dscp-cos { <0-63> <dscp> } | | 15 | GLOBAL_CONFIG |

| | | | |
|---|--|----|---------------|
| qos map dscp-ingress-translation { <0~63> <dscp> } to { <0-63> <dscp> } | | 15 | GLOBAL_CONFIG |
| no qos map dscp-ingress-translation { <0~63> <dscp> } | | 15 | GLOBAL_CONFIG |
| qos map dscp-classify { <0~63> <dscp> } | | 15 | GLOBAL_CONFIG |
| qos map cos-dscp <0~7> dpl <0~1> dscp { <0-63> <dscp> } | | 15 | GLOBAL_CONFIG |
| no qos map cos-dscp <0~7> dpl <0~1> | | 15 | GLOBAL_CONFIG |
| qos map dscp-egress-translation { <0~63> <dscp> } <0~1> to { <0-63> <dscp> } | | 15 | GLOBAL_CONFIG |
| no qos map dscp-egress-translation { <0~63> <dscp> } <0~1> | | 15 | GLOBAL_CONFIG |
| qos wred queue <0~5> min-th <0-100> mdp-1 <0-100> mdp-2 <0-100> mdp-3 <0-100> | | 15 | GLOBAL_CONFIG |
| qos wred queue <0~5> min-fl <0-100> max <1-100> [fill-level] | | 15 | GLOBAL_CONFIG |
| no qos wred queue <0~5> | | 15 | GLOBAL_CONFIG |
| qos storm { unicast multicast broadcast } { { <1,2,4,8,16,32,64,128,256,512> [kfps] } { 1024 kfps } } | | 15 | GLOBAL_CONFIG |
| no qos storm { unicast multicast broadcast } | | 15 | GLOBAL_CONFIG |
| qos qce { [update] } <uint> [{ next <uint> } last] [interface <port_type_list>] [smac { <mac_addr> <oui> any }] [dmac { <mac_addr> unicast multicast broadcast any }] [tag { [type { untagged tagged c-tagged s-tagged any }] [vid { <vcap_vr> any }] [pcp { <pcp> any }] [dei { <0-1> any }] }*1] [inner-tag { [type { untagged tagged c-tagged s-tagged any }] [vid { <vcap_vr> any }] [pcp { <pcp> any }] [dei { <0-1> any }] }*1] [frame-type { any { etype [{ <0x600-0x7ff,0x801-0x86dc,0x86de-0xffff> any }] } llc [dsap { <0-0xff> any }] [ssap { <0-0xff> any }] [control { <0-0xff> any }] } { snap [{ <0-0xffff> any }] } ipv4 [proto { <0-255> tcp udp any }] [sip { <ipv4_subnet> any }] [dip { <ipv4_subnet> any }] [dscp { <vcap_vr> <dscp> any }] [fragment { yes no any }] [sport { <vcap_vr> | | 15 | GLOBAL_CONFIG |

| | | | |
|---|--|----|---------------------|
| any }][dport { <vcap_vr> any }]} { ipv6 [proto { <0-255> tcp udp any }][sip { <ipv4_subnet> any }][dip { <ipv4_subnet> any }][dscp { <vcap_vr> <dscp> any }][sport { <vcap_vr> any }][dport { <vcap_vr> any }]}]} action { [cos { <0-7> default }][dpl { <0-1> default }][pcp-dei { <0-7> <0-1> default }][dscp { <0-63> <dscp> default }][policy { <uint> default }]}*1] | | | |
| no qos qce <'QCE_ID_START'~'QCE_ID_END'> | | 15 | GLOBAL_CONFIG |
| qos qce refresh | | 15 | GLOBAL_CONFIG |
| qos cos <0-7> | | 15 | GLOBAL_CONFIG |
| no qos cos | | 15 | INTERFACE_PORT_LIST |
| qos dpl <dpl> | | 15 | INTERFACE_PORT_LIST |
| no qos dpl | | 15 | INTERFACE_PORT_LIST |
| qos pcp <0-7> | | 15 | INTERFACE_PORT_LIST |
| no qos pcp | | 15 | INTERFACE_PORT_LIST |
| qos dei <0-1> | | 15 | INTERFACE_PORT_LIST |
| no qos dei | | 15 | INTERFACE_PORT_LIST |
| qos trust tag | | 15 | INTERFACE_PORT_LIST |
| qos trust dscp | | 15 | INTERFACE_PORT_LIST |
| qos map tag-cos pcp <0~7> dei <0~1> cos <0-7> dpl <dpl> | | 15 | INTERFACE_PORT_LIST |
| no qos map tag-cos pcp <0~7> dei <0~1> | | 15 | INTERFACE_PORT_LIST |
| qos policer <uint> [fps] [flowcontrol] | | 15 | INTERFACE_PORT_LIST |
| no qos policer | | 15 | INTERFACE_PORT_LIST |
| qos queue-policer queue <0~7> <uint> | | 15 | INTERFACE_PORT_LIST |
| qos queue-policer queue <0~7> <uint> | | 15 | INTERFACE_PORT_LIST |
| no qos queue-policer queue <0~7> | | 15 | INTERFACE_PORT_LIST |
| qos wrr <1-100> <1-100> <1-100> <1-100> <1-100> <1-100> | | 15 | INTERFACE_PORT_LIST |
| no qos wrr | | 15 | INTERFACE_PORT_LIST |
| qos shaper <uint> | | 15 | INTERFACE_PORT_LIST |
| no qos shaper | | 15 | INTERFACE_PORT_LIST |
| qos queue-shaper queue <0~7> <uint> [excess] | | 15 | INTERFACE_PORT_LIST |
| no qos queue-shaper queue <0~7> | | 15 | INTERFACE_PORT_LIST |
| qos tag-remark { pcp <0-7> dei <0-1> mapped } | | 15 | INTERFACE_PORT_LIST |
| no qos tag-remark | | 15 | INTERFACE_PORT_LIST |
| qos map cos-tag cos <0~7> dpl <0~1> pcp <0-7> | | 15 | INTERFACE_PORT_LIST |

| | | | |
|---|--|-------|---------------------|
| dei <0-1> | | | |
| no qos map cos-tag cos <0~7> dpl <0~1> | | 15 | INTERFACE_PORT_LIST |
| qos dscp-translate | | 15 | INTERFACE_PORT_LIST |
| qos dscp-classify { zero selected any } | | 15 | INTERFACE_PORT_LIST |
| no qos dscp-classify | | 15 | INTERFACE_PORT_LIST |
| qos dscp-remark { rewrite remap remap-dp } | | 15 | INTERFACE_PORT_LIST |
| no qos dscp-remark | | 15 | INTERFACE_PORT_LIST |
| qos storm { unicast broadcast unknown } <100-13200000> [fps] | | 15 | INTERFACE_PORT_LIST |
| no qos storm { unicast broadcast unknown } | | 15 | INTERFACE_PORT_LIST |
| qos qce { [addr { source destination }] [key { double-tag normal ip-addr mac-ip-addr }] } *1 | | 15 | INTERFACE_PORT_LIST |
| no qos qce { [addr] [key] } *1 | | 15 | INTERFACE_PORT_LIST |
| debug qos shaper cir { <100-3300000> [cbs <4096-258048>] } { [eir <100-3300000> [ebs <4096-258048>]] } | | debug | INTERFACE_PORT_LIST |
| no debug qos shaper | | debug | INTERFACE_PORT_LIST |
| debug qos queue-shaper queue <0~7> { cir <100-3300000> [cbs <4096-258048>] } { [eir <100-3300000> [ebs <4096-258048>]] } [excess] | | debug | INTERFACE_PORT_LIST |
| no debug qos queue-shaper queue <0~7> | | debug | INTERFACE_PORT_LIST |
| debug show qos shapers | | debug | EXEC |
| debug qos cmef [{ enable disable }] | | debug | EXEC |
| show rmon statistics [<1~65535>] | | 15 | EXEC |
| show rmon history [<1~65535>] | | 15 | EXEC |
| show rmon alarm [<1~65535>] | | 15 | EXEC |
| show rmon event [<1~65535>] | | 15 | EXEC |
| rmon alarm <1-65535> <word255> <1-2147483647> { absolute delta } rising-threshold <2147483648-2147483647> [<0-65535>] falling-threshold <2147483648-2147483647> [<0-65535>] { [rising falling both] } | | 15 | GLOBAL_CONFIG |
| no rmon alarm <1-65535> | | 15 | GLOBAL_CONFIG |
| rmon event <1-65535> [log] [trap <word127>] { [description <line127>] } | | 15 | GLOBAL_CONFIG |
| no rmon event <1-65535> | | 15 | GLOBAL_CONFIG |
| rmon collection stats <1-65535> | | 15 | INTERFACE_PORT_LIST |
| no rmon collection stats <1-65535> | | 15 | INTERFACE_PORT_LIST |
| rmon collection history <1-65535> [buckets <1- | | 15 | INTERFACE_PORT_LIST |

| | | | |
|---|---|----|---------------------|
| 65535>] [interval <1-3600>] | | | |
| no rmon collection history <1-65535> | | 15 | INTERFACE_PORT_LIST |
| show sflow statistics { receiver [<range_list>] samplers [interface [<range_list>] <port_type_list>]} | Use sflow statistics to show statistics for either receiver or sample interface. | 0 | EXEC |
| show sflow | Use show sflow to display the current sFlow configuration. | 0 | EXEC |
| clear sflow statistics { receiver [<range_list>] samplers [interface [<range_list>] <port_type_list>] } | Clearing statistics. | 15 | EXEC |
| sflow agent-ip {ipv4 <ipv4_addr> ipv6 <ipv6_addr>} | The agent IP address used as agent- address in UDP datagrams. Defaults to IPv4 loopback address. | 15 | GLOBAL_CONFIG |
| no sflow agent-ip | Sets the agent IP address used as agent-address in UDP datagrams to 127.0.0.1. | 15 | GLOBAL_CONFIG |
| sflow timeout [receiver <range_list>] <0- 2147483647> | Receiver timeout measured in seconds. The switch decrements the timeout once per second, and as long as it is non-zero, the receiver receives samples. Once the timeout reaches 0, the receiver and all its configuration is reset to defaults. | 15 | GLOBAL_CONFIG |
| no sflow timeout [receiver <range_list>] | Receiver timeout measured in seconds. The switch decrements the timeout once per second, and as long as it is non-zero, the receiver receives samples. Once the timeout reaches 0, the receiver and all its configuration is reset to defaults. | 15 | GLOBAL_CONFIG |
| sflow collector-address [receiver <range_list>] [<word>] | Collector address | 15 | GLOBAL_CONFIG |
| no sflow collector-address [receiver <range_list>] | | 15 | GLOBAL_CONFIG |
| sflow collector-port [receiver <range_list>] <1- 65535> | Collector UDP port. Valid range is 0- 65536. | 15 | GLOBAL_CONFIG |
| no sflow collector-port [receiver <range_list>] | Collector UDP port. Valid range is 0- 65536. | 15 | GLOBAL_CONFIG |
| sflow max-datagram-size [receiver <range_list>] <200-1468> | Maximum datagram size. | 15 | GLOBAL_CONFIG |

| | | | |
|--|---|----|---------------------|
| no sflow max-datagram-size [receiver <range_list>] | Maximum datagram size. | 15 | GLOBAL_CONFIG |
| sflow sampling-rate [sampler <range_list>] [<1-4294967295>] | Specifies the statistical sampling rate. The sample rate is specified as N to sample 1/Nth of the packets in the monitored flows. There are no restrictions on the value, but the switch will adjust it to the closest possible sampling rate. | 15 | INTERFACE_PORT_LIST |
| sflow max-sampling-size [sampler <range_list>] [<14-200>] | Specifies the maximum number of bytes to transmit per flow sample. | 15 | INTERFACE_PORT_LIST |
| no sflow max-sampling-size [sampler <range_list>] | Specifies the maximum number of bytes to transmit per flow sample. | 15 | INTERFACE_PORT_LIST |
| sflow counter-poll-interval [sampler <range_list>] [<1-3600>] | The interval - in seconds - between counter poller samples. | 15 | INTERFACE_PORT_LIST |
| no sflow counter-poll-interval [<range_list>] | The interval - in seconds - between counter poller samples. | 15 | INTERFACE_PORT_LIST |
| sflow [<range_list>] | Enables/disables flow sampling on this port. | 15 | INTERFACE_PORT_LIST |
| show smtp | Email information | 0 | EXEC |
| smtp delete { server username sender returnpath mailaddress <1-6> } | Delete email server | 15 | GLOBAL_CONFIG |
| smtp mailaddress <1-6> <word47> | Set email server | 15 | GLOBAL_CONFIG |
| smtp returnpath <word47> | | 15 | GLOBAL_CONFIG |
| smtp returnpath <word47> | | 15 | GLOBAL_CONFIG |
| smtp sender <word47> | | 15 | GLOBAL_CONFIG |
| smtp username <word31> <word31> | | 15 | GLOBAL_CONFIG |
| smtp server <word47> | | 15 | GLOBAL_CONFIG |
| smtp level <0-7> | | 15 | GLOBAL_CONFIG |
| show snmp | | 15 | EXEC |
| show snmp community v3 [<word127>] | | 15 | EXEC |
| show snmp user [<word32> <word10-32>] | | | |
| show snmp security-to-group [{ v1 v2c v3 } <word32>] | | | |
| show snmp access [<word32> { v1 v2c v3 any } { auth noauth priv }] | | | |
| show snmp view [<word32> <word255>] | | | |
| snmp-server | Enable SNMP server. | 13 | GLOBAL_CONFIG |
| snmp-server engine-id local <word10-32> | To specify SNMP server's engine ID. | 13 | GLOBAL_CONFIG |

| | | | |
|--|--|----|---------------------|
| | ifIndex(defined in IF-MIB) mapping \ information in the switch. | | |
| show snmp mib redefine | Use the show snmp mib redefine user EXEC command to display \ the redefined MIBs in the switch, that are different \ definitions from the standard MIBs. | 15 | EXEC |
| snmp-server trap | | 15 | GLOBAL_CONFIG |
| no snmp-server host <word32> | | 15 | GLOBAL_CONFIG |
| shutdown | | 15 | SNMPS_HOST |
| host { <ipv4_ucast> <hostname> } [<1-65535>] [traps informs] | | 15 | SNMPS_HOST |
| host <ipv6_ucast> [<1-65535>] [traps informs] | | 15 | SNMPS_HOST |
| no host | | 15 | SNMPS_HOST |
| version { v1 [<word127>] v2 [<word127>] v3 [probe engineID <word10-32>] [<word32>] } | | 15 | SNMPS_HOST |
| no version | | 15 | SNMPS_HOST |
| informs retries <0-255> timeout <0-2147> | | 15 | SNMPS_HOST |
| no informs | | 15 | SNMPS_HOST |
| traps [aaa authentication] [system [coldstart] [warmstart]] [switch [stp] [rmon]] | | 15 | SNMPS_HOST |
| no traps | | 15 | SNMPS_HOST |
| snmp-server host <word32> traps [linkup] [linkdown] [lldp] | | 15 | INTERFACE_PORT_LIST |
| no snmp-server host <word32> traps | | 15 | INTERFACE_PORT_LIST |
| show snmp host [<word32>] [system] [switch] [interface] [aaa] | | 15 | EXEC |
| show ip ssh | Use the show ip ssh privileged EXEC \ command to display the SSH status. | 15 | EXEC |
| ip ssh | Use the ip ssh global configuration command to \ enable the SSH. Use the no form of this \ command to disable the SSH. | 15 | GLOBAL_CONFIG |
| show network-clock | Show selector state. | 0 | EXEC |

| | | | |
|--|---|----|---------------|
| clear network-clock clk-source <range_list> | Clear active WTR timer. | 15 | EXEC |
| network-clock clk-source <range_list> nominate { clk-in {interface <port_type_id> } } | Nominate a clk input to become a selectable clock source. | 15 | GLOBAL_CONFIG |
| no network-clock clk-source <range_list> nominate | | 15 | GLOBAL_CONFIG |
| network-clock input-source { 1544khz 2048khz 10mhz } | Sets the station clock input frequency | 15 | GLOBAL_CONFIG |
| no network-clock input-source | | 15 | GLOBAL_CONFIG |
| network-clock output-source { 1544khz 2048khz 10mhz } | Sets the station clock output frequency | 15 | GLOBAL_CONFIG |
| no network-clock output-source | | 15 | GLOBAL_CONFIG |
| network-clock clk-source <range_list> aneg-mode { master slave forced } | Sets the preferred negotiation. | 15 | GLOBAL_CONFIG |
| no network-clock clk-source <range_list> aneg-mode | | 15 | GLOBAL_CONFIG |
| network-clock clk-source <range_list> hold-timeout <3-18> | The hold off timer value in 100 ms.Valid values are range 3-18. | 15 | GLOBAL_CONFIG |
| no network-clock clk-source <range_list> hold-timeout | | 15 | GLOBAL_CONFIG |
| network-clock selector { { manual clk-source <uint> } selected nonrevertive revertive holdover freerun } | Selection mode of nominated clock sources | 15 | GLOBAL_CONFIG |
| no network-clock selector | | 15 | GLOBAL_CONFIG |
| network-clock clk-source <range_list> priority <0-1> | Priority of nominated clock sources. | 15 | GLOBAL_CONFIG |
| no network-clock clk-source <range_list> priority | | 15 | GLOBAL_CONFIG |
| network-clock wait-to-restore <0-12> | WTR time (0-12 min) '0' is disable | 15 | GLOBAL_CONFIG |
| no network-clock wait-to-restore | | 15 | GLOBAL_CONFIG |
| network-clock ssm-holdover { prc ssua ssub eec2 eec1 dnu inv } | Hold Over SSM overwrite | 15 | GLOBAL_CONFIG |
| no network-clock ssm-holdover | | 15 | GLOBAL_CONFIG |
| network-clock ssm-freerun { prc ssua ssub eec2 eec1 dnu inv } | Free Running SSM overwrite | 15 | GLOBAL_CONFIG |
| no network-clock ssm-freerun | | 15 | GLOBAL_CONFIG |
| network-clock clk-source <range_list> ssm-overwrite { prc ssua ssub eec2 eec1 dnu } | Clock source SSM overwrite | 15 | GLOBAL_CONFIG |
| no network-clock clk-source <range_list> ssm-overwrite | | 15 | GLOBAL_CONFIG |
| network-clock option { eec1 eec2 } | EEC options | 15 | GLOBAL_CONFIG |

| | | | |
|---|--|----|---------------------|
| no network-clock option | | 15 | GLOBAL_CONFIG |
| network-clock synchronization ssm | SSM enable/disable. | 15 | INTERFACE_PORT_LIST |
| show logging [info] [warning] [error] [switch <switch_list>] | Use the show logging privileged EXEC command without keywords to display the logging configuration, or particularly the logging message summary for the logging level. | 15 | EXEC |
| show logging <1-4294967295> [switch <switch_list>] | Use the show logging privileged EXEC command with logging ID to display the detail logging message. OC_CMD_DEFAULT = | 15 | EXEC |
| clear logging [info] [warning] [error] [switch <switch_list>] | Use the clear logging privileged EXEC command to clear the logging message. | 15 | EXEC |
| logging on | Use the logging on global configuration command to enable the logging server. Use the no form of this command to disable the logging server. | 15 | GLOBAL_CONFIG |
| logging host { <ipv4_ucast> <hostname> } | Use the logging host global configuration command to configure the host address of logging server. | 15 | GLOBAL_CONFIG |
| no logging host | Use the no logging host global configuration command to clear the host address of logging server. | 15 | GLOBAL_CONFIG |
| logging level { info warning error } | Use the logging level global configuration command to configure what level of message will send to logging server. | 15 | GLOBAL_CONFIG |
| show clock | Show running system information | 0 | EXEC |
| show version | System hardware and software status | 0 | EXEC |
| password unencrypted <line31> | Use the password encrypted <password> global configuration command to configure administrator password with unencrypted password for the local switch access. | 15 | GLOBAL_CONFIG |
| password encrypted <word4-44> | Use the password encrypted <password> global configuration command to configure administrator password with encrypted password for the local switch access. | 15 | GLOBAL_CONFIG |

| | | | |
|--|---|----|---------------------|
| password none | Use the password none global configuration command to remove the administrator password. | 15 | GLOBAL_CONFIG |
| show system | Show system information | 0 | EXEC |
| system contact <line255> | To specify the system contact string. | 15 | GLOBAL_CONFIG |
| no system contact | To clear the system contact string. | 15 | GLOBAL_CONFIG |
| system location <line255> | To specify the system location string. | 15 | GLOBAL_CONFIG |
| no system location | To specify the system location string. | 15 | GLOBAL_CONFIG |
| system name <line255> | To specify the system mode name string. | 15 | GLOBAL_CONFIG |
| no system name | To specify the system model name string. | 15 | GLOBAL_CONFIG |
| show thermal-protect [interface <port_type_list>] | Shows thermal protection status (chip temperature and port status). | 15 | EXEC |
| thermal-protect prio <0~3> temperature <0-255> | Thermal protection configurations. | 15 | GLOBAL_CONFIG |
| no thermal-protect prio <0~3> | Sets temperature at which to turn ports with the corresponding priority off. | 15 | GLOBAL_CONFIG |
| thermal-protect port-prio <0-3> | Sets temperature at which to turn ports with the corresponding priority off. | 15 | INTERFACE_PORT_LIST |
| no thermal-protect port-prio | Sets temperature at which to turn ports with the corresponding priority off. | 15 | INTERFACE_PORT_LIST |
| show upnp | | 15 | EXEC |
| upnp | | 15 | GLOBAL_CONFIG |
| upnp ttl <1-255> | | 15 | GLOBAL_CONFIG |
| no upnp ttl | | 15 | GLOBAL_CONFIG |
| upnp advertising-duration <100-86400> | | 15 | GLOBAL_CONFIG |
| no upnp advertising-duration | | 15 | GLOBAL_CONFIG |
| username <word31> privilege <0-15> password unencrypted <line31> | Use the username <username> privilege <level> password encrypted <password> global configuration command to add a user with unencrypted password for the local switch access. | 15 | GLOBAL_CONFIG |
| username <word31> privilege <0-15> password encrypted <word4-44> | Use the username <username> privilege <level> password encrypted <password> global configuration command to add a user with encrypted password for the local switch access. | 15 | GLOBAL_CONFIG |
| username <word31> privilege <0-15> password | Use the username <username> | 15 | GLOBAL_CONFIG |

| | | | |
|--|---|-------|---------------------|
| none | privilege <level> password none global configuration command to remove the password for specific username. | | |
| no username <word31> | Use the no username <username> global configuration command to delete a local user. | 15 | GLOBAL_CONFIG |
| vlan protocol {{eth2 {<0x600-0xffff> arp ip ipx at}} {snap {<0x0-0xffff> rfc-1042 snap-8021h} <0x0-0xffff>} {llc <0x0-0xff> <0x0-0xff>} } group <word16> | | 13 | GLOBAL_CONFIG |
| switchport vlan mac <mac_ucast> vlan <vlan_id> | Use the switchport vlan mac command to associate a MAC address to VLAN ID. | 13 | INTERFACE_PORT_LIST |
| switchport vlan protocol group <word16> vlan <vlan_id> | Use the no form of this command to remove the group to vlan mapping. | 13 | INTERFACE_PORT_LIST |
| show vlan protocol [eth2 {<0x600-0xffff> arp ip ipx at}] [snap {<0x0-0xffff> rfc-1042 snap-8021h} <0x0-0xffff>] [llc <0x0-0xff> <0x0-0xff>] | Use the switchport vlan protocol group command to add group to vlan mapping. | 13 | EXEC |
| show vlan mac [address <mac_ucast>] | | 13 | EXEC |
| show vlan ip-subnet [id <1-128>] | | 13 | EXEC |
| switchport vlan ip-subnet id <1-128> <ipv4_subnet> vlan <vlan_id> | | 13 | INTERFACE_PORT_LIST |
| no switchport vlan ip-subnet id <1~128> | | 13 | INTERFACE_PORT_LIST |
| debug vcl policy <uint> | | debug | INTERFACE_PORT_LIST |
| no debug vcl policy | | debug | GLOBAL_CONFIG |
| debug show vcl policy | | debug | EXEC |
| switchport mode {access trunk hybrid} | Use the switchport mode command to define the type of the port. | 13 | INTERFACE_PORT_LIST |
| no switchport mode | | 13 | INTERFACE_PORT_LIST |
| switchport access vlan <vlan_id> | Use the switchport access vlan command to configure a port to a VLAN. Valid VLAN IDs are 1 to 4095. | 13 | INTERFACE_PORT_LIST |
| no switchport access vlan | | 13 | INTERFACE_PORT_LIST |
| switchport trunk native vlan <vlan_id> | Use the switchport native vlan command to configure a port VLAN ID for a trunk port. | 13 | INTERFACE_PORT_LIST |
| no switchport trunk native vlan | Set trunk mode characteristics of the interface | 13 | INTERFACE_PORT_LIST |

| | | | |
|---|--|----|---------------------|
| switchport hybrid native vlan <vlan_id> | Use the switchport native vlan command to configure a port VLAN ID for a hybrid port. | 13 | INTERFACE_PORT_LIST |
| no switchport hybrid native vlan | Set hybrid mode characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| switchport hybrid port-type { unaware c-port s-port s-custom-port } | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| no switchport hybrid port-type | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| switchport hybrid ingress-filtering | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| switchport hybrid acceptable-frame-type { all tagged untagged } | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| no switchport hybrid acceptable-frame-type | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| switchport hybrid egress-tag {none all [except-native]} | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| | | | |
| no switchport hybrid egress-tag | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| switchport trunk vlan tag native | Set trunk characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| switchport trunk allowed vlan {all none [add remove except] <vlan_list>} | Set trunk mode characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| no switchport trunk allowed vlan | Set trunk characteristics of the interface, | 13 | INTERFACE_PORT_LIST |
| switchport hybrid allowed vlan {all none [add remove except] <vlan_list>} | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| no switchport hybrid allowed vlan | Set hybrid characteristics of the interface | 13 | INTERFACE_PORT_LIST |
| vlan ethertype s-custom-port <0x0600-0xffff> | | 13 | GLOBAL_CONFIG |
| no vlan {{ethertype s-custom-port} <vlan_list>} | | 15 | GLOBAL_CONFIG |
| show interface <port_type_list> switchport [access trunk hybrid] | Use the show interfaces command to display the administrative and operational status of all interfaces or a specified interface. | 0 | EXEC |
| show vlan [id <vlan_list> name <vword32> brief] | Use the show vlan command to view the VLAN configuration. | 13 | EXEC |
| show vlan status [interface <port_type_list>] [combined admin nas mvr voice- | Use the show VLAN status command to view the VLANs configured for each | 13 | EXEC |

| | | | |
|---|---|----|---------------------|
| vlan mstp erps vcl evc gvrp all conflicts] | interface. | | |
| name <vword32> | Use the name <vword32> command to configure VLAN name. | 13 | CONFIG_VLAN |
| no name | The no form of this command will restore the VLAN name to its default. | 13 | CONFIG_VLAN |
| switchport forbidden vlan {add remove} <vlan_list> | Adds or removes forbidden VLANs from the current list of forbidden VLANs | 15 | INTERFACE_PORT_LIST |
| no switchport forbidden vlan | Allows for adding VLANs to an interface | 15 | INTERFACE_PORT_LIST |
| show switchport forbidden [{vlan <vlan_id> {name <word>}] | Lookup VLAN Forbidden port entry. | 0 | EXEC |
| voice vlan | Use the voice vlan global configuration command to enable voice vlan. Use the no form of this command to globally disable voice vlan. | 15 | GLOBAL_CONFIG |
| voice vlan vid <vlan_id> | Use the voice vlan vid global configuration command to configure voice vlan vid. | 15 | GLOBAL_CONFIG |
| no voice vlan vid | Use the no voice vlan vid global configuration command to restore the default voice vlan vid. | 15 | GLOBAL_CONFIG |
| voice vlan aging-time <10-10000000> | Use the voice vlan aging-time global configuration command to configure default voice vlan aging-time. | 15 | GLOBAL_CONFIG |
| no voice vlan aging-time | Use the no voice vlan aging-time global configuration command to restore the default voice vlan aging-time. | 15 | GLOBAL_CONFIG |
| voice vlan class { <0-7> low normal medium high } | Use the voice vlan class global configuration command to configure voice vlan class. | 15 | GLOBAL_CONFIG |
| no voice vlan class | Use the no voice vlan class global configuration command to restore the default voice vlan class. | 15 | GLOBAL_CONFIG |
| voice vlan oui <oui> [description <line32>] | Use the voice vlan oui global configuration command to set the oui entry for voice vlan. | 15 | GLOBAL_CONFIG |
| no voice vlan oui <oui> | Use the no voice vlan oui global configuration command to delete the oui entry. | 15 | GLOBAL_CONFIG |
| switchport voice vlan mode { auto force | Use the switchport voice vlan mode | 15 | INTERFACE_PORT_LIST |

| | | | |
|---|---|-------|---------------------|
| disable } | interface configuration command to configure to switchport voice vlan mode. | | |
| no switchport voice vlan mode | Use the no switchport voice vlan mode interface configuration command to restore the default switchport voice vlan mode. | 15 | INTERFACE_PORT_LIST |
| switchport voice vlan security | Use the switchport voice vlan security interface configuration command to configure switchport voice vlan security mode. Use the no form of this command to globally disable switchport voice vlan security mode. | 15 | INTERFACE_PORT_LIST |
| switchport voice vlan discovery-protocol {oui lldp both} | Use the switchport voice vlan discovery-protocol interface configuration command to configure to switchport voice vlan discovery-protocol. | 15 | INTERFACE_PORT_LIST |
| no switchport voice vlan discovery-protocol | Use the no switchport voice vlan discovery-protocol interface configuration command to restore the default switchport voice vlan discovery-protocol. | 15 | INTERFACE_PORT_LIST |
| show voice vlan [oui <oui> interface <port_type_list>] | Use the show voice vlan privilege EXEC command without keywords to display the voice vlan configuration, or particularly switchport configuration for the interface, or use the oui keyword to display oui table. | 15 | EXEC |
| debug gvrp protocol-state interface <port_type_list> vlan <vlan_list> | | debug | EXEC |
| debug gvrp msti | | debug | EXEC |
| debug gvrp statistic | | debug | EXEC |
| gvrp | | 15 | GLOBAL_CONFIG |
| gvrp time { [join-time <1-20>] [leave-time <60-300>] [leave-all-time <1000-5000>] }*1 | | 15 | GLOBAL_CONFIG |
| gvrp max-vlans <1-4095> | | 15 | GLOBAL_CONFIG |
| gvrp | | 15 | INTERFACE_PORT_LIST |
| gvrp join-request vlan <vlan_list> | | 15 | INTERFACE_PORT_LIST |
| gvrp leave-request vlan <vlan_list> | | 15 | INTERFACE_PORT_LIST |